

# *Consolidated Aircraft Supply Co., Inc.*

55 Raynor Ave Ronkonkoma, NY 11779

Phone: 631-981-7700 Toll Free: 800-422-6300 Fax: 631-981-7706

E-mail: CONSOL1291@aol.com

Web address: www.consolac.com

## **BOEING 777 CAPABILITY LISTING**

<b><u>PART NUMBER</u></b>	<b><u>ALT PART #</u></b>	<b><u>DESCRIPTION</u></b>
AV23B3146		VALVE
S210W110-1113		CHECK VALVE
S271Q732-1		PRESSURE SWITCH
S271W322-1		VALVE
S271W732-21		PRESSURE SWITCH
S282T004-10		INVERTER
S282T004-20		INVERTER
S282T004-30		INVERTER
S283W802-1		DIMMER
S283W802-2		DIMMER
10-0331-0165		LIGHT
10-0331-1		LIGHT
1024-1		DIMMER
1024-2		DIMMER
1024-3		DIMMER
1024-4		DIMMER
11225-1		COFFEE MAKER
140-025-2		SPEED TRANSDUCER
21C1-1-16B		PRESSURE SWITCH
21C1-6-7		PRESSURE SWITCH
21SN04-356D		PRESSURE SWITCH
21SN04-389B		PRESSURE SWITCH
21SN04-401		PRESSURE SWITCH
21SN04-403		PRESSURE SWITCH
212C139-3		PRESSURE SWITCH
25GB10-121		PRESSURE SWITCH
2612		VALVE
2-7680-2		FUSE
28823-ALL		WATER PUMP
30-2303-11		LIGHT
30-2303-13		LIGHT
30-2303-15		LIGHT

30-2303-17		LIGHT
30-2303-19		LIGHT
3202804-1		VALVE
32907144-9		VALVE
32907144-10		VALVE
3503788		STARTER
3505788		STARTER
3505814-3		STARTER
3505830-2		STARTER
3505830-3		STARTER
4100943	S210W003-4	FAN
4100943A	810219-1 S210W003-4	FAN
4100943B	810219-2 S210W003-8	FAN
4100943C	S210W003-8	FAN
4100943D	S210W003-8	FAN
4102107		FAN
4102107A		FAN
42TC12-2		PRESSURE SWITCH
4313200-90-66-00		OVEN
4321554		LIGHT
4321561		LIGHT
4321577		LIGHT
548376-6		CABIN TEMP CONTROL
568-1-29115-004		FUEL BOOST PUMP
60-4791-3		POWER SUPPLY
60B92001-5		PRESSURE SWITCH
60B92400-8		PRESSURE SWITCH
71234		HAND PUMP
72GP39-4		PRESSURE SWITCH
72GP39-5		PRESSURE SWITCH
732-16810-01		ACTUATOR
732-16810-03		ACTUATOR
732-16810-05		ACTUATOR
8D1011	10-60783-22	PRESSURE SWITCH
8D111-7	10-60523-27	PRESSURE SWITCH
8D136-1	10-60523-25	PRESSURE SWITCH
8D187-1	10-60783-16	PRESSURE SWITCH
8D187-2	10-60783-17	PRESSURE SWITCH
809581-2		ACTUATOR
810204		VALVE
811050-1		ENGINE
811050-2		ENGINE
811050-3		ENGINE

# *Consolidated Aircraft Supply Co., Inc.*

55 Raynor Ave Ronkonkoma, NY 11779

Phone: 631-981-7700 Toll Free: 800-422-6300 Fax: 631-981-7706

E-mail: CONSOL1291@aol.com

Web address: www.consolac.com

## **BOEING B747 (ALL MODELS)**

<b><u>PART NUMBER</u></b>	<b><u>DESCRIPTION</u></b>
AP15V-14-05	HYD. PUMP
AP15V-14-06	HYD. PUMP
AV11A1345	VALVE
AV11J3109-1	VALVE
AV14H5161	VALVE
AV14H5162	VALVE
AV14H5162-1	VALVE
AV14H5171	VALVE
AV14H5175	VALVE
AV14H5178	VALVE
AV14H5194	VALVE
AV16B1350	VALVE
AV16B1910C	VALVE
AV16B1950	VALVE
AV16B1965B	VALVE
AV16B2047C	VALVE
AV16B2060C	VALVE
AV16B2100B	VALVE
AV16B2105C	VALVE
AV16E1215-2	VALVE
AV16E1215-3	VALVE
AV16E1215-4	VALVE
AV16E1296	VALVE
AV16E1305	VALVE
AV16E3261C	VALVE
AV16E3261C-1	VALVE
AV17B1136	VALVE
A0643-089A	PUMP & MOTOR
A0643-089B	PUMP & MOTOR
A0643-089C	PUMP & MOTOR
A0643-089D	PUMP & MOTOR
A0643-089E	PUMP & MOTOR

A76602	VALVE
BPS7-3	BATTERY CHARGER
B429W	RELAY
B430Z	RELAY
CYLB50226-1	TEMP
CYLB50227-1	TEMP
C201-2500-40	VALVE
C3533-4	MOTOR
C5116-ALL	STARTER
C6589-11	MOTOR
C6589-12	MOTOR
DK1326M99-2	ACTUATOR
DL1020M159	ACTUATOR
DL1020M159-2	ACTUATOR
DL1020M186-5	ACTUATOR
DL1020M186-7	ACTUATOR
DL1326M119-2	ACTUATOR
DL1326M185-4	ACTUATOR
DL1326M99-2	ACTUATOR
DL2033M2-2	ACTUATOR
DL2033M4-2	ACTUATOR
DL2033M4-3	ACTUATOR
DL2033M4	ACTUATOR
D2063-1	ACTUATOR
D2063-7	ACTUATOR
D2067-ALL	ACTUATOR
D2067-3	ACTUATOR
D2067-4	ACTUATOR
D2070-1	ACTUATOR
D2401-11	ACTUATOR
D2401-12	ACTUATOR
D2401-13	ACTUATOR
D2401-14	ACTUATOR
D25BD	CONTACTOR
D31C	RELAY
ED728903-3	SOLENIOD
ED728903-5	SOLENOID
EVT3745A	FAN
E308AH	SENSOR
E316C	RELAY
G3122B	AMP INTERPHONE
G7406-14	CONTROL PANEL
HSV100MK2	SOLENOID
HTE9164	VALVE
HTE9164SK6803	VALVE
MA11A1114	ACTUATOR

MA11A1114-1	ACTUATOR
MA11A1129	ACTUATOR
MA11A1129-1	ACTUATOR
MA11A1142	ACTUATOR
MA11A1166	ACTUATOR
MA11A1173	ACTUATOR
MA11A1173-1	ACTUATOR
MA11A1174	ACTUATOR
MA11A1174-1	ACTUATOR
MA11A1194	ACTUATOR
MA11A1196	ACTUATOR
MA11A1198	ACTUATOR
MA11A1267	ACTUATOR
MA17A1012	ACTUATOR
MA17A2015	ACTUATOR
MA17A2015-3	ACTUATOR
MA20A1001-1	ACTUATOR
MF1-095-6	MOTOR
MS24140D1	RELAY
M6318-2	VALVE
NB10605	IGNITION EXCITER
PMP2V7D	HYDR. PUMP
PV3-240-10	PUMP
PV3-240-2E	PUMP
PV3-240-2F	PUMP
PV3-240-2G	PUMP
PV3-240-2H	PUMP
RR24640B	PUMP
RR24680	FUEL PUMP
RYL329-1	TEMP
R1053M18	MECH-LMT
R1053M18-1	MECH-LMT
R1053M18-2	MECHANISM
R1409M-ALL	ROTARY ACTUATOR
R1409M12-1	ACTUATOR
R1419M12	ACTUATOR
R1419M14	ACTUATOR
R4101-ALL	ACTUATOR
S1356A36	LIGHT ASSY
S1356B37	LIGHT ASSY
S1653-1L	LIGHT ASSY
S1653-1R	LIGHT ASSY
S1685-1	LIGHT ASSY
S1685-41	LIGHT ASSY
S1686A	LIGHT ASSY
S1686B	LIGHT ASSY

S21OU122-1		PRESSURE SWITCH
S271T452-20		PRESSURE SWITCH
S282T004		INVERTER
S282T004-10		INVERTER
S282T004-20		INVERTER
S282T004-30		INVERTER
S283T001-2		SKID CONTROL VALVE
S283T001-24		VALVE
S283T001-8		VALVE
S283T014-3		BATTERY CHARGER
S332T004-35		PRESSURE SWITCH
S353T010-ALL		ACTUATOR
S90G162		PRESSURE SWITCH
S90G183		PRESSURE SWITCH
TSG420-103		INVERTER
TYPEAF		PSU
TYPEAN		PSU
TYPEB		PSU
TYPEN		PSU
TYPEY		PSU
TYPEZ		PSU
V27200-363		SOL VALVE
V27200-3632		VALVE
XW21090	2311M84-1	MOTOR
XW21795-3		MOTOR W/S WIPER
XW21795-4		MOTOR W/S WIPER
024236		FAN
1-001-0102-0265		INVERTER
1-002-0102-0265		INVERTER
1-002-0102-2090		INVERTER
10-0331-0165		LIGHT
10-0331-1		LIGHT
10-0339-29		LIGHT
10-0432-5		SIGN
10-0476-101		LIGHT
10-0480-101		LIGHT
10-0584-101		LIGHT
1010099-6		WATER BOILER
10150		VALVE,FUEL DEICING
1020M186-6		ACTUATOR
10260-4		REGULATOR
10-2638-4		PRESSURE SWITCH
102650EG		MOTOR
102650EZ		MOTOR
102650E111		MOTOR
102842DB		ACTUATOR

102842MW	ACTUATOR
10-344-7	LIGHT
10-344-9	LIGHT
10-352680-1	ASSEMBLY
10-381160-2	IGNITOR
10-381160-2A	IGNITOR
10-381750-6	VALVE
10500-1	MOTOR
10-60551-3	VALVE
10-60551-5	VALVE
10-60552-1	PRESSURE SWITCH
10-60552-11	PRESSURE SWITCH
10-60552-15	PRESSURE SWITCH
10-60552-17	PRESSURE SWITCH
10-60552-18	PRESSURE SWITCH
10-60552-19	PRESSURE SWITCH
10-60552-24	PRESSURE SWITCH
10-60552-25	PRESSURE SWITCH
10-60552-31	PRESSURE SWITCH
10-60552-37	PRESSURE SWITCH
10-60552-38	PRESSURE SWITCH
10-60552-39	PRESSURE SWITCH
10-60552-40	PRESSURE SWITCH
10-60552-41	PRESSURE SWITCH
10-60552-42	PRESSURE SWITCH
10-60806-1025	BREAKER
10-61224-11	GEN. CONTROL UNIT
10-621630-1	EXCITER,IGNITION
106785A110	MOTOR
106785A117	MOTOR
106785B101	MOTOR
106785B105	MOTOR
106785B121	MOTOR
106785B125	MOTOR
106785B133	MOTOR
106785B133A	MOTOR
106788A140	ACTUATOR
106788A145	ACTUATOR
106788A205	ACTUATOR
106788A206	ACTUATOR
106788A225	ACTUATOR
106788A225A	ACTUATOR
106788B160	ACTUATOR
106788B200	ACTUATOR
107484-5	VALVE
107492-2	VALVE

107728A101	MOTOR
107728A130	MOTOR
107797A104	ACTUATOR
107967	VALVE
107968	VALVE
107969	VALVE
107971	VALVE
107971-1	VALVE
1088A	OVEN
109300-10	AIR DRIVEN PUMP
109300-12	PUMP
109522-2-1	ACTUATOR
109552-1-1	ACTUATOR
109552-2-1	ACTUATOR
109630-7-1	VALVE
109802-10-1	VALVE
111940A1	VALVE
11225-1	COFFEE MAKER
112260A1	VALVE
11290-1	VALVE
11290-2	VALVE
1176T100-3	ACTUATOR
1184-1A	INVERTER
123776-1-1	VALVE
1238T100-3	VALVE
123848-1	VALVE
125120	VALVE
125333	VALVE
125334	VALVE
125348	VALVE
125349	VALVE
125409	VALVE
125423	VALVE
125423B	VALVE
125424	VALVE
125424B	VALVE
125426	VALVE
125426B	VALVE
125442	VALVE
125442B	VALVE
125613A	VALVE
126236-3-3	ACTUATOR
126236-4-2	ACTUATOR
126344-1-1	UNIT DRIVE, LE FLAP
126344-17-1	UNIT, DRIVE LE FLAP
126344-23-1	UNIT, DRIVE LE FLAP



126344-25-1	DRIVE UNIT
126748-ALL	ACTUATOR
127038-3-1	ACTUATOR
129364-7-1	CONTROL TEMP
129666-2	VALVE
130002N	ACTUATOR
1332-1A	FLASHER
1387T100-5	ACTUATOR
1387T100-7	ACTUATOR
140-025-2	SPEED TRANSDUCER
145E1000-1	OVEN
148065	VALVE
148085	VALVE
15-0069-1	LIGHT ASSEMBLY
15-0069-17	LIGHT
15-0306-1	LIGHT ASSY, CARGO
1572T100-13	VALVE
1572T100-15	VALVE
1572T100-17	VALVE
1652	VALVE
1747	VALVE
18MT1-1A4BC2	MOTOR
18MT1-1A4BC2-4	MOTOR
187220-3-1	ELECTRIC HEATER
2B74-1A	TRANSFORMER
2B79-1A	TRANSFORMER
2CM9ADB9	TACH GENERATOR
2LA455453-00	LIGHT
2012-1	BATTERY CHARGER
2057	SWITCH
21B142-3	GCU
21B73-1-C	GCU
21B73-1-D	CONTROLLER
21B73-1-DM	CONTROL UNIT GEN
21B73-2A	UNIT GENERATOR CONTROL
21B73-2-A	GCU
21B73-2B	CONTROL UNIT, GEN.
21B77-1C	CONTROL UNIT
21B77-1-C	GCU
21B77-2A	CONTROL UNIT
21B77-2-A	GCU
21B77-2-B	CONTROL UNIT
21C1-1-16B	PRESSURE SWITCH
21SN04-CC24	PRESSURE SWITCH
21SN04-121	PRESSURE SWITCH
21SN04-148	PRESSURE SWITCH

21SN04-149	PRESSURE SWITCH
21SN04-19A	PRESSURE SWITCH
21SN04-19B	PRESSURE SWITCH
21SN04-20A	PRESSURE SWITCH
21SN04-223	PRESSURE SWITCH
21SN04-224	PRESSURE SWITCH
21SN04-225	PRESSURE SWITCH
21SN04-259	PRESSURE SWITCH
21SN04-260A	PRESSURE SWITCH
21SN04-33A	PRESSURE SWITCH
21SN04-334	PRESSURE SWITCH
21SN04-337A	PRESSURE SWITCH
21SN04-338	PRESSURE SWITCH
21SN04-339C	PRESSURE SWITCH
21SN04-34	PRESSURE SWITCH
21SN04-340	PRESSURE SWITCH
21SN04-341A	PRESSURE SWITCH
21SN04-352	PRESSURE SWITCH
21SN04-353	PRESSURE SWITCH
21SN04-354	PRESSURE SWITCH
21SN04-355	PRESSURE SWITCH
21SN04-401	PRESSURE SWITCH
21SN04-403	PRESSURE SWITCH
21SN04-58	PRESSURE SWITCH
21SN04-59	PRESSURE SWITCH
21SN04-70A	PRESSURE SWITCH
21SN04-71	PRESSURE SWITCH
21SN04-89	PRESSURE SWITCH
21SN41-1B	PRESSURE SWITCH
21SN41-13	PRESSURE SWITCH
21SN41-30	PRESSURE SWITCH
21SN41-42	PRESSURE SWITCH
21SN41-49	PRESSURE SWITCH
21SN41-5A	PRESSURE SWITCH
21SN41-53	PRESSURE SWITCH
21SN41-84	PRESSURE SWITCH
21SN41-88A	PRESSURE SWITCH
211C117-222	PRESSURE SWITCH
211C117-223	PRESSURE SWITCH
211C117-245	PRESSURE SWITCH
211C223-343	PRESSURE SWITCH
21185-000	ACT GRND SPOIL
212C117-75	PRESSURE SWITCH
212C139-1	PRESSURE SWITCH
213C50-5	PRESSURE SWITCH
213C50-6	PRESSURE SWITCH

214C40-1-115		PRESSURE SWITCH
214C40-1-77		PRESSURE SWITCH
214C50-2		PRESSURE SWITCH
214C50-68		PRESSURE SWITCH
218386-2		MOTOR ASSY
218386-3		MOTOR ASSY
218387		PUMP
224685		RELIEF VALVE
227565M1		VALVE
2363000-1		VALVE
24E507009G		WATER HEATER
240085		VALVE
2-418-04		TRANSFORMER
2-456		DIMMER LAMP
2-459-2		DIMMER
2-459-04		DIMMER
25GB10-108		PRESSURE SWITCH
25GB10-109		PRESSURE SWITCH
265567		PUMP & MOTOR
2660608		VALVE,CHECK
2660608M2		VALVE
2670005M7		VALVE
2670194		VALVE
2670282		VALVE
2670288-6		VALVE
2671T100-1	S256T004-14	ACTUATOR
2704202-1		MOTOR
2704202-2		MOTOR
2704202-3		MOTOR
2704202-4		MOTOR
2704202-5		MOTOR
2720021		VALVE
27241337		VALVE
2-7679-2		FUSE
2780536-101		VALVE
28B26313A		AC GENERATOR
28B263-13B		GENERATOR
28VS20044B2		RECTIFIER
28000-1		REGULATOR
28823-ALL		WATER PUMP
29340-3		ACTUATOR
298113		PUMP
299-005		PUMP
3BA16513		SWITCH
30-0331-2		LIGHT
30-0332-9		LIGHT ASSY

30-0332-10	LIGHT
30-0407-1	LIGHT
30-0408-3	ASSEMBLY
30-0454-3	LIGHT
30-0627-3	LIGHT
30-0809-11	LIGHT ASSY
30-0910-1	STROBE
30-0911-3	STROBE
30-1526	STROBE
30-1526-9	LIGHT ASSY
31-1253-13	LIGHT
3170284-1	VALVE
319405-16	SOLENOID
319405-18	SOLENOID
319405-20	SOLENOID
319675-12	SOLENOID
319675-17	SOLENOID
319675-30	SOLENOID
319675-38	SOLENIOD
319675-5	SOLENIOD
319675-51	SOLENIOD
319675-9	SOLENIOD
320362-ALL	SOLENOID SHUTOFF VALVE
3204958-4	VALVE
320625-4	PRESSURE VALVE
32-2684-007	SHUTOFF VALVE
32-2684-03	ANTI ICE VALVE
32-2684-04	SHUT OFF VALVE
3229173-1	VALVE
32-2963-001	VALVE
32-2963-002	VALVE
32-2963-003	ANTI ICE VALVE
32-2963-005	VALVE
32-2963-007	VALVE
32-2963-009	VALVE
32-2963-010	VALVE 335D-2 CARD
3291172-2	VALVE
3291172-3	VALVE
33-065-1	VALVE
33-065-2	VALVE
342381	PUMP
34265-ALL	LIGHT
346D1B	AMP PA
349-0001-13	COFFEE MAKER
349-0001-25-004	COFFEE MAKER
349-0001-5	COFFEE MAKER

3505945-9	STARTER
350880-5	PUMP
350880-6	PUMP
350880-7	PUMP
3603879-2-1	VALVE
36280	VALVE
36500	VALVE
369724	PUMP & MOTOR
369969	PUMP & MOTOR
373400	PUMP
373401-ALL	PUMP
382400	PUMP
382401-ALL	PUMP
382486	GENERATOR
3862160-10	A.P.U. COOLING FAN
3862160-3	A.P.U. COOLING FAN
3862160-4	A.P.U. COOLING FAN
3862160-5	A.P.U. COOLING FAN
3862160-9	A.P.U. COOLING FAN
3880371-2	PUMP
389400	PUMP
389401-ALL	PUMP
39B168-1B	SUPPLY
39B168-1-B	INVERTER
39B168-1C	INVERTER
39-617	SKID CONTROL VALVE
398310-3-1	BUTTERFLY VALVE
398310-5-1	VALVE
4BA11426	VALVE
40TP17	MOTOR
40-0149-1	LIGHT
40-0149-2	BEACON
40-0149-3JL	UPPER ANTICOLL
40-0150-7	LOWER ANTICOLL
4003218-908	LIGHT
40-805	WHEEL SPEED SENSOR
40-80570	WHEEL SPEED SENSOR
40884	VALVE ASSY
40884-3	VALVE ASSY
40885	UNIT ASSY,CONTROL
40885-2	CONTROL UNIT
40885-22	CONTROL UNIT
40885-4	CONTROL UNIT
41SG118-2	TRANSDUCER
41SG265-1	PRESSURE SWITCH
41SG287-1	PRESSURE SWITCH

4100149A	FAN
411-0001-131	COFFEE MAKER
420365-1	VALVE
42-189-7	ANTI-SKID
426V600	VALVE
43343EA	VALVE
43572	EXCITER
43925	EXCITER
44060	EXCITER
44760	EXCITER
4500A2	BRAKE VALVE
4500S-A2	BRAKE VALVE
472183	GENERATOR
472190	GENERATOR
4723	GENERATOR
472932	FIRE DETECTOR
472933	FIRE DETECTOR
472934	FIRE DETECTOR
472935	FIRE DETECTOR
472940	FIRE DETECTOR
473630	FIRE DETECTOR
4801-41	VALVE
4802-43	VALVE
4812-1-18	PUMP & MOTOR LAV
48387-7	MOTOR
49731	EXCITER
50E99-1	VALVE
515090-4	MOTOR,L/E FLAP ELEC.
515531R	POS LIGHT
515562-ALL	AC MOTOR
516038	MOTOR
516531L	POS LIGHT
516531R	POS LIGHT
519022-3	MOTOR
519022-4	MOTOR
519022-5	MOTOR
519022-6	MOTOR
519022-7	MOTOR
519022-8	MOTOR
519802-2	MOTOR
519802-3	MOTOR
519802-4	MOTOR
519802-5	MOTOR
519802-6	MOTOR
519806-2	STARTER
519806-3	STARTER

519860-1	MOTOR
519860-2	MOTOR
519860-3	MOTOR
519860-4	MOTOR
544286-ALL	ACTUATOR
544646-ALL	ACTUATOR
544646-1	ACTUATOR
544646-7	ACTUATOR ROTARY
544952-2	ACTUATOR
544800-2	ACTUATOR
5500300-17	ACTUATOR
5500400-1	ACTUATOR
56193	PUMP
57186-ALL	PUMP
58173	MOTOR
59350	VALVE
5852A	OVEN
6F2602	VALVE
6RS992F6	POWER SUPPLY
60B00010-27	CONTROL UNIT
60B00010-31	GCU
60B00010-32	GCU
60B00010-7	CONTROL UNIT
60B00020-6	PRESSURE SWITCH
60B00020-7	PRESSURE SWITCH
60B00021-8	PRESSURE SWITCH
60B00021-9	PRESSURE SWITCH
60B00022-8	ACTUATOR
60B00026-ALL	VALVE
60B00207-2	VALVE
60B00207-5	VALVE
60B00255-2	VALVE
60B00256-4	HYDRAULIC PUMP
60B00256-5	HYDRAULIC PUMP
60B00258-4	VALVE
60B00279-1	PRESSURE SWITCH
60B00305-11	ACTUATOR
60B00305-14	ACTUATOR
60B00305-25	ACTUATOR
60B40019-1	BATTERY CHARGER
60B40024-1	DIMMER LAMP
60B40024-6	DIMMER
60B40027-15	WHEEL SPEED SENSOR
60B40027-24	WHEEL SPEED SENSOR
60B40031-7	VALVE
60B40043-4	HEATER

60B40057-17		LIGHT ASSY
60B40099-2		INVERTER
60B50037-36		LIGHT ASSY
60B50037-37		LIGHT ASSY
60B50037-38		LIGHT ASSY
60B50037-39		LIGHT ASSY
60B50037-40		LIGHT ASSY
60B50037-41		LIGHT ASSY
60B60014-7		ACTUATOR
60B60014-9		ACTUATOR
60B80019-11		ACTUATOR
60B80019-12		ACTUATOR
60B80019-13		ACTUATOR
60B80019-14		ACTUATOR
60B92001-3		PRESSURE SWITCH
60B92001-4		PRESSURE SWITCH
60B92406-32		ACTUATOR
60B92602-14		CONTROL UNIT
60B92602-17		CONTROL UNIT
60B92602-9		CONTROL UNIT
60B92603-ALL		FUEL PUMP
60B96212-ALL		ROTARY ACTUATOR
60B98803-1		ACTUATOR
60B98805-4		VALVE
60B98805-5		VALVE
60-1211-1		POWER SUPPLY
60-1211-1RF		POWER SUPPLY
601300-11	60B80031-10	ACTUATOR
602V100-4		VALVE
60213-1		VALVE
60213-13		VALVE
60213-17		VALVE
60213-20		VALVE
60273		PUMP
60281		VALVE
6042H145		RELAY
6042H146		RELAY
6042H155		RELAY
6042H167		RELAY
6042H21		RELAY
6042H501		RELAY
605457-7		CENTRIFUGAL FAN
6062H501		RELAY
606802-2		BLOWER
60-703		FUEL PUMP
60-703-113		PUMP



60-703104	PUMP
60-703200	HOUSING ASSY
60-721	FUEL PUMP
60-72101	PUMP
60-723	FUEL PUMP
60-72301	FUEL PUMP
60-75504	PUMP
60-98976-1	FUEL PUMP
60-98976-4	FUEL PUMP
617154-5	WINDOW HEAT CONTROL
623272	PUMP
623977	PUMP
645980-1	FAN
65B01500-5	ACTUATOR
65B01504-13	ACTUATOR
65B01504-14	ACTUATOR
65B01522-1	BARREL
65B01539-5	ACTUATOR
65B01539-7	ACTUATOR
65B2899-15	PSU
65B43400-5	LIGHT
65B47528-1	DIMMER
65B50254-204	PSU
65B50254-316	PSU
65B50254-320	PSU
65B50254-356	PSU
65B50255-172	PSU
65B52899-15	PSU
65066-05	HYDRAULIC PUMP
65066-06	HYDRAULIC PUMP
6577-1	BLOWER
67-2951-001	SHUT OFF VALVE
67-2985-001	VALVE
67-2985-003	SHUT OFF VALVE
67-3139-002	VALVE
67-3139-002M	VALVE
67-3139-003	VALVE
67-3139-004	VALVE
69-14217-2	VALVE
69B80358-25	ACTUATOR
69B80358-26	ACTUATOR
69B80359-2	ACTUATOR
69B80187-3	VALVE
696V300	VALVE
698870	CSD
7G148	SWITCH

700312-1	SIGN EXIT
701284	LIGHT
701285	POWER SUPPLY
705117	CSD
705117K	CSD
705117L	CSD
705401-37-36-34	PUMP
705501-37-36-34	PUMP
706800	PUMP
706801-ALL	PUMP
707088C	PUMP
7110-09-0000	OVEN
71234	PUMP
71577-2	VALVE
71577-3	PUMP
71577-4	PUMP
71577-5	PUMP
715995-3	VALVE
717998-4	VALVE
719201	VALVE
719218-ALL	VALVE
719223-4	VALVE
719224-3	VALVE
719224-4	VALVE
71985-2	VALVE
71998	VALVE
72022	PUMP
720613-3	VALVE
720613-6	VALVE
72071000	OVEN
72086	PUMP
721-1-000	COFFEE MAKER
72184100	WATER HEATER
72-21-01-13	OVEN
72-21-01-15A	OVEN
724282-1	VALVE
724282-2	VALVE
724912-18	GENERATOR
726574-7	STARTER
729490	IDG/CSD
731966	PUMP ASSY
732-13870-ALL	ACTUATOR
732-16810-01	ACTUATOR
732-16810-03	ACTUATOR
732-16810-05	ACTUATOR
732-16830-02	ACTUATOR

732-16830-03		ACTUATOR
732591E		FAN
737109-7		VALVE
738362-20		VALVE
738362-21		VALVE
738362-22		VALVE
739515C		IDG
740179-5		STARTER
740179-6		STARTER
740179-11		STARTER
740179-12		STARTER
740179-13		STARTER
742868-3		AIR VALVE
742868-5		ACTUATOR
745329C		IDG
746066-1		VALVE
747-5700-2-0	60B00166-2	ACTUATOR
747-5826-1-0		AC MOTOR
749109-12		STARTER
75-0147-9A		PANEL
763569-6		STARTER
764476-2		VALVE
767-1		INVERTER
767-1A		INVERTER
774400		VALVE
774860A4		STARTER
775550-3		STARTER
792755-16		PRESSURE REGULATOR
792999-10		VALVE
8C167		VALVE
8C176-2		VALVE
8D111-2	10-60523-12	PRESSURE SWITCH
8D1370	S332T004-22	PRESSURE SWITCH
8D1371	S332T004-23	PRESSURE SWITCH
8D1469	S332T004-34	PRESSURE SWITCH
8D1473	S332T004-33	PRESSURE SWITCH
8D1494	S332T004-35	PRESSURE SWITCH
8D1495	S332T004-36	PRESSURE SWITCH
8D168	10-61267-8	PRESSURE SWITCH
8001-07-0000		OVEN GALLEY
80-025-05		VALVE
802-1A		DIMMER
8054-19-0000		OVEN
8056-01-0000		OVEN
811050-1		STARTER
813640-401		OVEN

813640-403	OVEN
813640-405	OVEN
813640-407	OVEN
8204M2	AIR COMPRESSOR
8204M3	AIR COMPRESSOR
8204M4	AIR COMPRESSOR
8800-01-0000	OVEN
8921340G1	HEATER
8921560G1	HEATER
8921560G3	HEATER
8-930-03	BATTERY CHARGER
895004	FIRE DETECTOR
895157	FIRE DETECTOR
895312	FIRE DETECTOR
895349	FIRE DETECTOR
805396	FIRE DETECTOR
895297	FIRE DETECTOR
895398	FIRE DETECTOR
895899	FIRE DETECTOR
896770	FIRE DETECTOR
896771	FIRE DETECTOR
896772	FIRE DETECTOR
896773	FIRE DETECTOR
896774	FIRE DETECTOR
896775	FIRE DETECTOR
896980	FIRE DETECTOR
8972146063	HEATER
897450	FIRE DETECTOR
897807	FIRE DETECTOR
898108-6-1	VALVE
898148	FIRE DETECTOR
898149	FIRE DETECTOR
898626-3	VALVE
899172	FIRE DETECTOR
90G183	PRESSURE SWITCH
90G233	PRESSURE SWITCH
90G235	PRESSURE SWITCH
90G236	PRESSURE SWITCH
90G237	PRESSURE SWITCH
90G37	PRESSURE SWITCH
90G97	PRESSURE SWITCH
90G97-1	PRESSURE SWITCH
90020-7	FLOOD LIGHT
9036-3-2	VALVE
9036-5-2	VALVE
9131-8505	RELAY

915F369-3	POWER CONTROL UNIT
94P10	PRESSURE SWITCH
94P12	PRESSURE SWITCH
94P27	PRESSURE SWITCH
94P28	PRESSURE SWITCH
94P29	PRESSURE SWITCH
94P30	PRESSURE SWITCH
94P31	PRESSURE SWITCH
94P32	PRESSURE SWITCH
94P7	PRESSURE SWITCH
94P8	PRESSURE SWITCH
94P9	PRESSURE SWITCH
942D023-2	BREAKER
942D023-3	BREAKER
942D023-4	BREAKER
942D023-6	BREAKER
942D055-2	POWER CONTROL
948F458-1	GEN. CONTROL UNIT
948958-ALL	A.P.U. CONTROL UNIT
949848-7	FAULT MODULE
95300-5003	VALVE
961-7017-003	TEMP CONTROL
967167-3	VALVE
967167-4	VALVE
968348-5	PUMP
9750145-007	SWITCH
977J003-11	CONT UNIT-GEN
978602-4-1	VALVE
978692-2	VALVE
979182-1-1	VALVE
979826-11	VALVE
979858-5	VALVE
980-4500-003	PANEL

# *Consolidated Aircraft Supply Co., Inc.*

55 Raynor Ave Ronkonkoma, NY 11779

Phone: 631-981-7700 Toll Free: 800-422-6300 Fax: 631-981-7706

E-mail: CONSOL1291@aol.com

Web address: www.consolac.com

## **BOEING 737 (ALL MODELS) CAPABILITY LISTING**

<b><u>PART NUMBER</u></b>	<b><u>DESCRIPTION</u></b>
ACR-EMI	BULLHORN
AD969T-RS	ARRESTER
AE7693-127N2	FLUID CONTROL
AE961566	SWIVEL JET
APCO	BOTTLE
AP10V68-02	PUMP
AR6460M2	ACTUATOR
AR6460M2MOD2	ACTUATOR
AR6460M2MOD3	ROTARY ACTUATOR
AR7077M1	ROTARY ACTUATOR
AR7077M2	ACTUATOR
AS19570-ALL	HYDRAULIC PUMP
AS664-L-S-666	PUMP
AS-66651-L8	HYDRAULIC PUMP
AS-66651-L8A	HYDRAULIC PUMP
AVR869	RELAY
AV10B2201	SWITCH
AV11A113CN	VALVE
AV13J5100	VALVE
AV13J5101	3 WAY VALVE
AV13J5105	VALVE
AV13J5144	VALVE
AV13J5145	VALVE
AV13J5147	VALVE
AV16B1330D	VALVE
AV16B1331C	VALVE
AV16B1350	SHUT OFF VALVE
AV16B1519D	VALVE
AV16B1520C	VALVE
AV16B1965B	VALVE
AV16B1966B	VALVE
AV16E1187D	VALVE

AV16E1209D	VALVE
AV168-1350	GATE SHUT OFF VALVE
AV18B1018	RELIEF VALVE
AV24B4001C3	
AV24E1144	VALVE
AV24E1144-2	VALVE
AV24F1144	VALVE ASSY
AW2835AB01	INDICATOR
A3A110-10-016	ALTIMER
A-32058-111	CONTAINER
A41869-10-016	INDICATOR
A418691-0015	INDICATOR
A420-060283-05	SOLENOID
A60087-CD6	VALVE
A61146-1	VALVE
A61146-2	VALVE
A61146-3	VALVE
A61143-4	VALVE
A61498	VALVE
A61499	VALVE
A61681	VALVE
A62028-1	VALVE
A62080-6	VALVE HYD
A63193	VALVE
A8985-5	LIGHT
A91006-2	SWITCH
BC10-3207-1	SWITCH
BF23D-FS	02 CYL.
BPS7-3	BATTERY CHARGER
B0707-10008	SWITCH
B484	RELAY
B711-6	INDICATOR
B-9215-3	LIGHT
B9735-1-1385	FLOOD LIGHT
B9845-8-1165	LIGHT
CNA73FB	ADF. CONT.
C201-1500-1	SOLENOID
C96B69-1344	SWITCH
DD468AS	COFFEE POT
DH7BC	CONTACTOR
DMN23-1B	ANTENNA
DP1-1-G	TRANSM.
DR4-0008-1	WATER HEATER
DS1000	OVEN
D1845-3	ACTUATOR
D1845-7	ACTUATOR

D31C	RELAY
EA1093A-2408	QTY. TANK
EA1093A3679	TRANSM.
ED742986-19	PANEL
ED743830-2	SWITCH
E311P	RELAY
E329E	RELAY
E-6015M20	ROTARY ACTUATOR
E60200M320-1	ROTARY ACTUATOR
F61D0236M4	SHUT OFF VALVE
F74298	SWITCH
F74832-2	SWITCH
G-1278	PANEL
GA21-2E	EXTING.
GA7396	VALVE
GRS992F6	TRANSM.
G1248B1	PANEL
G1248D-1	INDICATOR
G1249D-1	INDICATOR
G2086B	PANEL
G2295	PANEL
G2297	PANEL
G2298	PANEL
G2298A	PANEL
G2299	PANEL
G2300	PANEL
G2344	PANEL
G2345	PANEL
G2348	PANEL
G2471	PANEL
G2581	PANEL
G2587	PANEL
G2647	PANEL
G2977	NAV. PANEL
G2977A	PANEL
G3724	PANEL
G3725	PANEL
G3725A	PANEL
G3746A	PANEL
G4457	PANEL
G-477	AUDIO CONTROL
G515D	SPEAKER
HD5-27136-1A	PANEL
HE67251	OVEN
HL08700-0N	HYDROLOCK
HL1400-32-B	HYDROLOCK



H10-1026-1		SWITCH
H10-1026-2		SWITCH
H10-1027-1		SWITCH
H61C0538M1		DRAIN VALVE
H61C0551		VALVE
H61C0552M1		VALVE
H6100552MN		VALVE CHECK
H81C0552		VALVE
IG386		SWITCH
K-1248-8-1		VALVE
LL01500-0.3A		HYDROLOCK
LRC16M5		CONTACTOR
LU1225		VALVE
L11AT25		SWITCH
L20118-3		LIGHT ASSY
L6F110		VALVE
MA20A1001-1		ACTUATOR
MA20A2027		ACTUATOR
MA30A1001		ACTUATOR
MF9-3911-30ZE		HYD MOTOR
MPEV1-060-2		PUMP
MPEV3-056-10A		PUMP
MPEV3-056-7A		PUMP
MPEV3-056-9A		PUMP
MS24254-16P		CONTACTORS
MS24524-22		SWITCH
MS25038-4		TACH GENERATOR
MS28916-1		LIGHT ASSEMBLY
MS9-3911-30ZE		HYDRAULIC PUMP
MS9-3911-30ZE-4C		HYD. MOTOR
MS9-3911-302E		HYD. MTR.
M503-2		VALVE
M913-1		VALVE
PC14BA		INVERTER
PDC1-1B16		SWITCH
PMP2V-7D-07	57186-07	PUMP, HYD, ELECTRIC
PMP2V7D		HYDR. PIMP
PV3-160-4		HYDRAULIC PUMP
PV3-160-4A		PUMP
PV3-160-4B		PUMP
PV3-160-4C		PUMP
PV3160-8		PUMP
P134-395-1		VALVE
Q4559X		LANDING LIGHT
R1053M17-1		MECHANISM
R1053M17-2		ACTUATOR

R1053M18	MECH-LMT
R1053M18-1	MECH-LMT
R1053M18-2	MECHANISM
R1053M2-1	ACTUATOR-LIMITER
R1053M2-2	ACTUATOR-LIMITER
R11053M2-1	SWITCH LIMITER
R15048	ACTUATOR
R1597-23	ACTUATOR, ELECTRO MECH
R1631	ACTUATOR, ELECTRO MECH
R1633M3	STAB ACTUATOR
R5303-3	ACTUATOR
R5303-5	ACTUATOR
R5303-51	ACTUATOR
R5303-51	ACTUATOR
R5303M1	ACTUATOR
R6166M1	ACTUATOR
R6200M3-ALL	ROTARY ACTUATOR
SSGT-6DB-50	VALVE
S1686A	LIGHT ASSY
S1686B	LIGHT ASSY
S210U122-2	PRESSURE SWITCH
S210U122-3	PRESSURE SWITCH
S271T452-1	PRESSURE SWITCH
S271T452-10	PRESSURE SWITCH
S271T452-11	PRESSURE SWITCH
S271T452-12	PRESSURE SWITCH
S271T452-13	PRESSURE SWITCH
S271T452-15	PRESSURE SWITCH
S271T452-16	PRESSURE SWITCH
S271T452-17	PRESSURE SWITCH
S271T452-18	PRESSURE SWITCH
S271T452-19	PRESSURE SWITCH
S271T452-3	PRESSURE SWITCH
S271T452-5	PRESSURE SWITCH
S271T452-6	PRESSURE SWITCH
S271T452-7	PRESSURE SWITCH
S271T452-8	PRESSURE SWITCH
S271T452-9	PRESSURE SWITCH
S282T004	INVERTER
S282T004-10	INVERTER
S282T004-20	INVERTER
S282T004-30	INVERTER
S283T014-3	BATTERY CHARGER
S283W802-1	DIMMER
S283W802-2	DIMMER
S332A002-2	VALVE

S332A002-3		VALVE
S332A101-5		VALVE
S332A101-6		VALVE
S332A101-7		VALVE
S332A101-8		VALVE
S332T004-26		PRESSURE SWITCH
S332T004-27		PRESSURE SWITCH
S332T004-7		PRESSURE SWITCH
S343T003-66		ACTUATOR
TD1514-1002		TOIL. TMR.
TD715-1002		TOIL. TMR.
T10470-2		PUMP
VA31-0003-1		MOTOR
V14307		VALVE
V5000-40		SHUT OFF VALVE
V5000-43		VALVE
V8500-40		VALVE
V8500-72		VALVE
XW020548M1A-3		MOTOR ASSY
XW20345-ALL		WIPER GEARBOX
XW20369-425-80		CONVERTER
XW20548-MIA		ELECTRIC MOTOR
XW20548-MIA-3		MOTOR
XW21181-16		MOTOR
XW21181-17		MOTOR CONVERTER ASSY
XW21181-18		MOTOR
XW23629-1		WINDSHIELD MOTOR
XW23629-2		WINDSHIELD MOTOR
XW23629-4		WINDSHIELD WIPER DRIVE
ZZL4020-362T		CONTACTOR
030-1082-001		CONTACTOR
030-1134-000		CONTACTOR
030-20325-01		POWER SUPPLY
0493-06-0000		GALLEY
066-1056-001		TRANSPONDER
080-20325-01	20325-01	POWER SUPPLY
0-0906-4		STROBE LIGHT
009-1377-000		FAN
097637-0201		TRANSPONDER
1FA14012-8		ACTUATOR
1G196		PRESSURE SWITCH
1G259-1		SWITCH
1G386		PRESSURE SWITCH
1U1065		COMPENSATOR
1U1136		SOL. VALVE
1U1150-1		UNIT

1U1154	VALVE
1U1220-2	ACTUATOR
1U1222	ACTUATOR
1U1225	SOLENOID
10MT-1530-AM	MOTOR GENERATOR
1000020-1	RECEIVER
10-0015-1	LIGHT ASSY
100020-1	RECEIVER
10-0035-1	LIGHT
10-0046-1F	LIGHT
1-001-0102-0265	INVERTER
100170	MAGAZINE
1-002-0102-0611	INVERTER
1-002-0102-0265	INVERTER
1-002-0102-2090	INVERTER
10050-3	MECHANISM
10-0067-9	LIGHT ASSY
100865	EMERG. POWER SUPPLY
10-0050-51	READING PAX
10-0050-52	READING PAX
10-0067-3	LIGHT
10-0067-71-9	EMERGENCY LIGHT
10-0067-9	LIGHT
10-0171-1	LIGHT
10-0171-101	LIGHT
10-0171-103	LIGHT
10-0171-104	LIGHT
10-0171-108	LIGHT
10-0171-109	LIGHT
10-0171-113	LIGHT
10-0171-114	LIGHT
10-0171-116	LIGHT
10-0171-15	LIGHT
10-0171-2	LIGHT
10-0171-8	LIGHT
10-0171-1	LIGHT
1-002-0102-0611	INVERTER
1-002-0102-2089	STATIC INVERTER
100413	CONTACTORS
10-0439-1	LIGHT
10-0439-5	LIGHT
10-0814-1	LIGHT
10-0873	LIGHT ASSY
10-1007-29	LIGHT ASSY
10-1113-3	DOME LIGHT
101136	VALVE, SOLENOID

10-1722		RELAY
10-1803-35		LIGHT
1024-1		DIMMER
1024-2		DIMMER
1024-3		DIMMER
1024-4		DIMMER
1026AY02		PRS. VALVE
10-2638-4		PRESSURE SWITCH
102650EG		MOTOR
102842DB		ACTUATOR
102842LX		ACTUATOR
10-3067-502	42D275-1	FUEL PRESS SWITCH
103154-909-2		SAFETY VALVE
10-319648-1		IGN. LEAD
10-3200-6		VALVE
10-3204-5		VALVE
10-3204-7		FLOW VALVE
10-3204-9		FLOW LIMITER
10-3207-1		SWITCH
10-3223-33		INDICATOR
10-3257-5		POWER SUPPLY
10-3257-6		TRANSFORMER RECTIFIER
10-3269-12		PRESSURE SWITCH
10-3269-13		PRESSURE SWITCH
10-3269-8		PRESSURE SWITCH
103280-5-1		VALVE
10-353875-4		EXCITER
103610-1		CVR MIC
103624-2		VALVE
10-381550-4		EXCITER
10-381750-11		IGNITION EXCITER
10-381750-6		IGNITION
1040-001		INDICATOR
1044581-7		S/O VALVE
10470-ALL		PUMP & MOTOR-HYDRAULIC
10-4908		VALVE & ACTUATOR
10500-1		ELEC HYD PUMP
10-60091-101		EXT. LIGHT
10-60246-10		HYDRAULIC PUMP
10-60246-8		HYDRAULIC PUMP
10-60467-14		FUEL TANK
10-60467-2		FUEL CELL
10-60467-3		FUEL CELL
10-60470-13		HYDRAULIC PUMP E.D
10-60495-6		VALVE
10-60495-7		SHUT OFF VALVE

10-60508-1		VALVE
10-60508-2		VALVE, CHECK
10-60523-11		DRAIN VALVE
10-60523-21		DRAIN VALVE
10-65523-24		VALVE
10-60525-1		DRAIN VALVE
10-60526-14		VALVE
10-60526-3		VALVE
10-60526-4		VALVE
10-60529-1		VALVE
10-60529-10		VALVE
10-60529-11		VALVE
10-60529-2		FUEL SHUTOFF VALVE
10-60529-3		FUEL SHUT OFF VALVE
10-60529-4		VALVE
10-60529-5		VALVE
10-60529-6		VALVE
10-60529-7		VALVE
10-60529-8		VALVE
10-60529-9		VALVE
10-60533-ALL		FUEL BOOST PUMP
10-60533-1	258000	FUEL BOOST PUMP
10-60551-1		VALVE
10-60551-2		VALVE
10-60551-3		VALVE
10-60552-1		PRESS SWITCH
10-60552-11		PRESSURE SWITCH
10-60552-20		PRESSURE SWITCH
10-60552-21		PRESSURE SWITCH
10-60552-22		PRESSURE SWITCH
10-60552-26		PRESSURE SWITCH
10-60552-27		PRESSURE SWITCH
10-60552-28		PRESSURE SWITCH
10-60552-29		PRESSURE SWITCH
10-60552-30		PRESSURE SWITCH
10-60552-34	1125P0028	PRESSURE SWITCH
10-60552-8		PRESSURE SWITCH
10-60552-9		PRESSURE SWITCH
10-60553-2		SOLENOID VALVE
10-60555-3		CAS DRAIN FILTER
10-60555-3		VALVE
10-60557-3		VALVE
10-60560-1		COMPENSATOR
10-60561-2		VALVE MTR.
10-60564-1		HYD. VALVE
10-60564-1		VALVE

10-60565-4	PANEL
10-60590-ALL	STEERING VALVE
10-60593-1	FLUID CONTROL
10-60656-35	PUMP
10-60704-6	VALVE
10-60707-10	BATTERY
10-60710-6	VALVE
10-60721-3	BRAKE
10-60747-6	SWITCH
10-60763-1	LIGHT
10-60783-3	DRAIN VALVE
10-60811-9	VALVE
10-60855-1	FAN
10-60914-37	READING PAX
10-60914-38	READING PAX
10-61B03-20	LIGHT ASSY
10-61043-3	HEAT CONTROL
10-61068-1	POT HEATER
10-61093-181	WHEEL SPEED TRANSDUCER
10-61209-23	VALVE
10-61214-2	ACTUATOR
10-61223-1	CSD
10-61223-2	CSD
10-61224-2	G.C.U
10-61224-3	G.C.U
10-61224-4	G.C.U
10-61224-7	TRANSFORMER
10-61245-14	HYDRAULIC FUSE
10-61245-16	HYDRAULIC FUSE
10-61286-1	ACTUATOR
10-61292-6	PUMP
10-61329-13	MOTOR
10-61329-16	MOTOR CONVERTER ASSY
10-61329-21	W/SHD MTR.
10-61329-22	W/SHD MTR.
10-61330-19	LAMP
10-6133-1	LIGHT ASSY PH
10-61335-3	FWD LAV LIGHT
10-61343-3	ACTUATOR
10-61359-2	ACTUATOR
10-61359-3	ACTUATOR
10-61472	ACTUATOR
10-61472-5	ACTUATOR
10-61794-1	HYDRAULIC PUMP
10-617980-1	EXCITER
10-61803-312	LIGHT

10-61803-89	LIGHT
10-61816-2	ACTUATOR LIMITER
10-61833-1	WINDOW HEAT CONTROLLER
10-61985-5	ACTUATOR
10-62033-2	ROTARY ACTUATOR
10-62033-3	ACTUATOR
10-631045-1	EXCITER
10-631045-1A	IGNITION EXCITER
10-631045-2	EXCITER
106785	SOL.VALVE
106785B101	MOTOR
106785B114	MOTOR
106788A144	ACTUATOR
106788A103	ACTUATOR
106788A128	ACTUATOR
106788A131	ACTUATOR
106788B153	ACTUATOR
107484-5	REGULATOR
107484-6	HIGH STAGE REGULATOR V
107484-7	REGULATOR
107492-2	BLD AIR REG
107492-3	REGULATOR
107492-5	BLD AIR REG
107492-6	REGULATOR
107996-33-1	THERMOSTAT
108136-25-1	REGULATOR
10857	MOTOR
109382-17-1	CONTROL VALVE
109382-35-1	VALVE
1094	VALVE
109468-1-1	BLEED VALVE
109486-1-1	VALVE
109486-5-1	VALVE
109486-6-1	VALVE ASSY
109854-5	SURGE VALVE
11-0283-3	EXIT LIGHT
110-61068-1	LAV WATER HEATER
1111-568266	VALVE ASSY
1-111715-2	TOILET
1121S-10-7-2	HYDRAULIC VALVE
1121S4-0-20	FLOW LIMITER
112156-1-5	HYD VALVE REG
1122514	TRANSM.
1125P0028	SWITCH, PRESSURE
11290-1	CHECK VALVE
11290-2	VALVE



112902-2	VALVE CHECK EQUIP BLOWER
11400-1	HYDRAULIC PUMP
11-6537	PSU ASSY
11-6537-1	PSU ASSY
11-6537-3	PSU ASSY
11-6537-5	PSU ASSY
11-6537-7	PSU ASSY
11-6537-9	PSU ASSY
11-6612	PSU ASSY
11-6612-1	PSU ASSY
11-6612-3	PSU ASSY
11-6612-5	PSU ASSY
117391-2T	THERMOSTAT
12D117-4	VALVE
12D124-3	VALVE
1200-066-5	BREAKER
121664-5	ACTUATOR
121-666-3	ACTUATOR
1225P0028	PRESSURE SWITCH
1225P11	PRESSURE SWITCH
1225P14	PRESSURE SWITCH
1225P39	SWITCH
1225P41	PRESSURE SWITCH
1225P6-1	SWITCH
1225P6-2	SWITCH
1232168-1-1	VALVE CHECK
123266-1-1	VALVE
123266-2-1	PNEUMATIC VALVE CHECK
123268-1-1	AIR, CHECK VALVE
123269-1-1	VALVE
123533-2-1	VALVE
123558	CK VALVE
123558-1-1	CK VALVE
123558-1-3	CK VALVE
123558-1-4	VALVE
125334D1	VALVE
127032-001	RELAY
128775	VALVE
129240-1-1	THERMOSTAT
129475	VALVE
129552-1-1	THERMOSTAT
129666-2	SENSOR ASSY
129666-3	SENSOR ASSY
130395	CHECK VALVE
130502-7	PANEL CABIN PRESS
130595	VALVE

1311-126	VALVE
140-025-2	SPEED TRANSDUCER
1404100-1	OVEN
1433	OVEN
145765-1	MOTOR
149455	VALVE SHUT OFF
150T193-1	PROBE
15-007-89	UTILITY LIGHT
15-0093-5	LIGHT ASSY
15-0129	LITE
152BL801E	INDICATOR
152B1801A	INDICATOR
1552002-9	VALVE
155665-ALL	FLOW CONTROL VALVE
156210-1-1	HEATER
15625	DAT. INDIC.
158300-101	ACTUATOR
16000-100	TOILET
162BL501	INDICATOR
162BL801	INDICATOR
162BL802	INDICATOR
165W1003-4	HYD. PUMP
165W01007-ALL	PUMP
165W01020	PUMP STANDBY
1651	PRESSURE VALVE
1652	RELIEF VALVE
1667	VALVE RELIEF ENGINE BLD
1697EA	VALVE
1707C	FIRE DETECTOR
171019-13	VALVE
172625-5	VALVE
172625-6	VALVE
172625-7	VALVE
172934-001	SELECTOR SWITCH
172938-001	RELAY
173-1902-1	ACTUATOR
173-1902-503	ACTUATOR
18-1542	INDICATOR
18-1542-2	INDICATOR
18-1738-1	TRANSMTR.
18-1739-4	INDICATOR
1801	CONTROL
180-146	COFFEE HEATER
188911	PUMP
1908-01	ARR.LTNG.
19911-1C	GYRO.-VERT.

19913-1B	GYRO.-VERT.
19913-2C	GYRO.-VERT.
2CM9	BATTERY CHARGER
2CM9ABH7	TACH GENERATOR
2CM9ABY7	TACH GENERATOR
2CM9ABY7-1	TACH GENERATOR
2EN19-RB	MICRO SWITCH
2J8000-3	PUMP
2S2474L	VALVE
20C144-3	VALVE
20C144-4	VALVE
200-0123-02	CARD
20115	ANTI ICE VALVE
201207-403	VALVE
2012-1	BATTERY CHARGER
20325	POWER SUPPLY
20326-01	POWER SUPPLY
2038081-0501	POWER SUPPLY ASSY
2038768-0501	POWER SUPPLY
204050-11	ACM
20414234-3408	RECEIVER
206001-003	FILTER
206408-0501	CARD
2064542-0501	CARD
2064602-0501	AMPLIFIER
2064612-0501	AMPLIFIER
2064676-0501	POWER SUPPLY
206735-0703	RECEIVER
2067593-2638	RECEIVER
2067635-5121	INDICATOR
20705-01	TRANSFORMER RECTIFIER
2070945-4305	RECEIVER
2083-06-1	INDICATOR
2083-08-1	INDICATOR
2087179-0501	ANTENNA
2087786-7302	RECEIVER
21B73-2-A	GCU
21B77-1C	BUS. CONTR.
21C1-1-16B	PRESSURE SWITCH
21SN04-98-1	PRESSURE SWITCH
21SN04-104E	PRESSURE SWITCH
21SN04-158C	PRESSURE SWITCH
21SN04-159C	PRESSURE SWITCH
21SN04-180	PRESSURE SWITCH
21SN04-183	PRESSURE SWITCH
21SN04-209	PRESSURE SWITCH

21SN04-209A	PRESSURE SWITCH
21SN04-211	PRESSURE SWITCH
21SN04-211A	PRESSURE SWITCH
21SN04-226	PRESSURE SWITCH
21SN04-226A	OIL PRESSURE SWITCH
21SN04-23J	PRESSURE SWITCH
21SN04-268	PRESSURE SWITCH
21SN04-269	PRESSURE SWITCH
21SN04-306B	PRESSURE SWITCH
21SN04-323A	PRESSURE SWITCH
21SN04-324	PRESSURE SWITCH
21SN04-325	PRESSURE SWITCH
21SN04-333	PRESSURE SWITCH
21SN04-334	PRESSURE SWITCH
21SN04-335	PRESSURE SWITCH
21SN04-337A	PRESSURE SWITCH
21SN04-338	PRESSURE SWITCH
21SN04-339C	PRESSURE SWITCH
21SN04-340	PRESSURE SWITCH
21SN04-341A	PRESSURE SWITCH
21SN04-352	PRESSURE SWITCH
21SN04-353	PRESSURE SWITCH
21SN04-354	PRESSURE SWITCH
21SN04-355	PRESSURE SWITCH
21SN04-356D	PRESSURE SWITCH
21SN04-389B	PRESSURE SWITCH
21SN04-391A	PRESSURE SWITCH
21SN04-401	PRESSURE SWITCH
21SN04-403	PRESSURE SWITCH
21SN04-405	PRESSURE SWITCH
21SN04-42	PRESSURE SWITCH
21SN04-52	PRESSURE SWITCH
21SN04-70A	PRESSURE SWITCH
21SN04-71	PRESSURE SWITCH
21SN04-84	PRESSURE SWITCH
21SN41-52	PRESSURE SWITCH
21SN41-82	PRESSURE SWITCH
21SN41-83	PRESSURE SWITCH
21SN41-84	PRESSURE SWITCH
211C117-185	PRESSURE SWITCH
211C117-197	PRESSURE SWITCH
211C223-199	PRESSURE SWITCH
211C223-200	PRESSURE SWITCH
211C223-214	PRESSURE SWITCH
211C223-278	PRESSURE SWITCH
211C223-296	PRESSURE SWITCH

211C223-297	PRESSURE SWITCH
211C223-301	PRESSURE SWITCH
211C223-319	PRESSURE SWITCH
211C223-320	PRESSURE SWITCH
211C223-321	PRESSURE SWITCH
211C223-322	PRESSURE SWITCH
211C223-323	PRESSURE SWITCH
211C223-324	PRESSURE SWITCH
211C223-326	PRESSURE SWITCH
211C223-327	PRESSURE SWITCH
211C223-341	PRESSURE SWITCH
211C276-14	PRESSURE SWITCH
21197	SWITCH
214C40-1-110	PRESSURE SWITCH
214C40-1-113	PRESSURE SWITCH
214C40-1-115	PRESSURE SWITCH
214C40-1-71	PRESSURE SWITCH
214C40-1-75	PRESSURE SWITCH
214C40-1-77	PRESSURE SWITCH
214C50-2	SWITCH, ALTITUDE
214C50-68	PRESSURE SWITCH
21520-1	FAN, MIXED FLOW
217200-4	VALVE
217500-1	VALVE
218066-3	VALVE
220AGEE	VALVE ASSY
220T6EE	CHECK VALVE
2206EE	VALVE ASSY
224685	VALVE
2279-003-11	VALVE
2279005-1	VALVE
2-299	TRANSFER
2-299-3	POWER SUPPLY
2-301	BATTERY CHARGER
2-301-3	BATTERY CHARGER
231-2	WINDOW HEAT CONTROL
23186	BATTERY
233A2228-1	MOD
233145	VALVE
239YC16	MOTOR
24C225	VALVE
24C226	VALVE
240863	PUMP
241YH35	MOTOR
241YH36	AIR STARTER MOTOR
243YH27	CARGO DOOR MOTOR

243600	F. PUMP. ASSY
243800	FUEL PUMP
2-462	SWITCH
252072	CHECK VALVE
2524F9	CARGO DOOR MOTOR
25582-3	BATTERY
258000-3	FUEL BOOST PUMP
258000-5	FUEL BOOST PUMP
2585703-2	AMP. SLV.
2588722-4	COMP. CUOP.
2588880-901	COUPLER
2589419-901	FLUX VALVE
2593564-906	ALERTER
2596050-901	COUPLER
2600-03-1	CLOCK
2600-04-1	CLOCK
2600163	VALVES
2600360	WHEEL MN.
2601042-5	BRAKE MN.
2601045-2	WHEEL ASSY
2601449	WHEEL ASSY
260157-1	WHEEL ASSY
260304-4E	WHEEL ASSY
260304-4G	WHEEL ASSY
260304-6E	WHEEL ASSY
260304-6G	WHEEL ASSY
260304-6H	WHEEL ASSY
260304-6L	WHEEL ASSY
2607046-1	WHEEL ASSY
2607047-1	WHEEL ASSY
262-044-010	INDICATOR
2640628M2	VALVE CHECK
2650102	VALVE
2650195	VALVE
2650289	ADAPT. FUEL
2651-311-6	VALVE
2670054	ADAPT. FUEL
2670064-409	VALVE
2670136	VALVE
26800337	VALVE
268679	PUMP
268737	HYDRAULIC PUMP
2700058	FLAPPER CHECK VALVE
2700100	VALVE
2704482-3	STARTER
2730426	VALVE STR.

2740028-2	ACTUATOR
27550-1	VALVE
2760000-101	ENG BLEED SHUT OFF VALVE
2-7680-2	HYDRAULIC FUSE
2-7681	FUSE ASSY
2-7737	FUSE ASSY
279T6EE	VALVE
2790475-102	VALVE
2790475-103	VALVE
27916EE	VALVE
279952	HYDRAULIC PUMP
28B545-7	GENERATOR
28B263-13A, B	GENERATOR
2-8020-11	FUSE
2820095-101	VALVE
28410	VALVE
28420	VALVE
29650102	VALVE
3-114115-2	VALVE
3S2060DV108B1	STATIC INVERTER
3S2060DV109B1	STATIC INVERTER
30-0127-9-1683	LIGHT ASSY
30-0213-11	LIGHT ASSY
30-0213-12	LIGHT ASSY
30-0234-1-4174	FWD POSITION LIGHT
30-0234-2	LIGHT
30-0234-2L4174	FWD POSITION LIGHT
30-0432-1	LIGHT
30-0432-11	LIGHT ASSY
30-0432-12	EMERGENCY LIGHT
30-0432-13	EMERGENCY LIGHT
30-0593-1	LIGHT ASSY
30-0837-5	ANTI COLLISION LIGHT
30-0837-15	STROBE LIGHT
30-0837-19	BEACON
30-0837-21	STROBE LIGHT
30-0837-33	BEACON
30-0837-35	BEACON
30-0837-5	LIGHT STROBE
30-0837-6	A.C. LIGHT
30-0837-9	BEACON
30-0906-10	STROBE LIGHT
30-0906-101	LIGHT ASSY STROBE LH
30-0906-104	RH LIGHT
30-0906-105	LIGHT, RECOGNITION
30-0906-110	STROBE LIGHT

30-0906-4	STROBE LIGHT
30-0906-5	STROBE LIGHT
30-0909-1	STROBE
30-0909-101	STROBE
30-0909-201	STROBE LIGHT
30-0909-3	STROBE
30101-7	BEACON
30-1401-3	LIGHT
30-1951-3	LIGHT
30-2506-3	LIGHT ASSY
30-2683-	LIGH
30-2683-1	LIGHT
30-2683-10	LIGHT
30-2683-11	LIGHT
30-2683-12	LIGHT
30-2683-13	LIGHT
30-2683-14	LIGHT
30-2683-2	LIGHT
30-2683-5	NAV LIGHT
30-2683-9	LIGHT
30-2685-6	NAV LIGHT
30469	VAL THERMOSTATIC
305080-1C	SWITCH
3052600-2	MODULE
305593-3	SWITCH
305593-7	SPEED SWITCH ASSY
31147-4	SOLENOID
316365	HYD RELIEF VALVE
316525	PUMP
316565	VALVE
316841	HYDRAULIC PUMP
317-631-1001-002	LIGHT ASSY
317-631-1001-005	LIGHT ASSY
317-631-1001-006	LIGHT ASSY
317-631-1002-001	LIGHT ASSY
317-631-1002-003	LIGHT ASSY
31-92330-204	PANEL ASSY
319545-86	VALVE
319545-96	VALVE
319995-1	VALVE
320115	VALVE
320115-14	VALVE
3214446-ALL	VALVE
3214552-5	VALVE
3215618-ALL	VALVE
32-2604-003	ROTARY ACTUATOR



32-2604-002	VALVE
32-2684-003	VALVE
32-2684-004	VALVE
32-2861-001	ATR SHUT OFF VALVE
32C171	VALVE
32EN14-4	MICRO SWITCH
3200-1	STROBE LIGHT
3200-10	MOTOR
3200-12	STROBE LIGHT
3200-16	TOILET PUMP
3200-19	TOILET PUMP
320115	VALVE
320115-16	VALVE
320115-3	VALVE
320115-4	VALVE
320115-5	VALVE
3202096-2	VALVE
3202222-1	CHECK VALVE
3202444-1	VALVE
3202446-1	VALVE
320362-ALL	VALVE
3205	A.C. MOTOR
3214446-4	VALVE
3214552-5	VALVE
321464-2-1	ANTI ICE VALVE
321464-5-1	VALVE
3214972-1	VALVE
32164-000	TACH GENERATOR
321942-1-1	S/O VALVE
323636	HYDRAULIC PUMP
324495	VALVE
325300	BOOST PUMP
32785-1-1864	LIGHT ASSY
32785-313	ANNUNCIATOR
3285	SPOT LIGHT
3289562-3	VALVE
3289562-4	PRECOOL VALVE
3289562-5	VALVE
3289630-1	VALVE
3289630-2	VALVE
3289630-3	VALVE
3290050	VALVE
3290662-1	VALVE
3291214-2	BLEED VALVE
34265-ALL	LIGHT
34265-8	LIGHT ASSY

347001083	INTERROG.
3505526-4-1	STARTER
3505526-5-1	STARTER
3505526-9-1	STARTER
3505582-45	STARTER
3505716-ALL	STARTER
3505716-3	STARTER
3505716-5	STARTER
3505716-6	STARTER
3505945-10	STARTER
35805-0	FIRE CONTROL UNIT
358200	FUEL PUMP
3601030-10-1	MOTOR
3605812-13	STARTER
36-11815-64	VAL SO STARTER
3616140-4	COOLING FAN
3600-1-1	VALVE
3601030-10-1	SWITCH
3602310-32-1	CONTROL
3602310-4	CONTROL
3604524-22	CAN
3605239-2	VALVE
3605812-1	STARTER
3605812-1-1	STARTER
3605812-16	STARTER
3605812-16-1	STARTER MOTOR
3605812-17	STARTER
3605812-22	A.P.U. STARTER
3609480-ALL	A.P.U. SPEED SWITCH
363182-1-2	VALVE
364404	PUMP
371380	HYDRAULIC PUMP
3718649-001	ANTEN. DISH
372697-9	STARTER APU
373048-1	VALVE
378001	PUMP
379580-150	PUMP
379580-650	PUMP OIL APU
380-0001-5	COFFEE MAKER
380428-1-2	APU
382300-1	FUEL BOOST PUMP
382300-2	FUEL BOOST PUMP
382300-3	FUEL BOOST PUMP
383152-1-2	HYDRAULIC PUMP
383152-16-1	STARTER
383152-19-1	STARTER

383342-1-1	STARTER
383343-1-1	STARTER
384300	FUEL PUMP
39B168-1-B	INVERTER STATIC
39B168-1C	INVERTER
391041-05007	COMPENS.
391046-04128	UNIT
391046-04135	UNIT
391046-04138	UNIT
391046-251	TRANSMITTER
391097-16005	PROBE
391097-16015	PROBE
3926644-1-1	VALVE
392664-1-1	VALVE
392664-2-1	VALVE
392678-1-1	VALVE ASSY
392678-3-1	VALVE
392686-3-1	REGULATOR ASSY
392688-1-1	STARTER VALVE
392708-1-1	THERMOS VALVE
392716-1	VALVE SO PNEU
392716-1-1	VALVE
3927216-1-1	VALVE SO PNEU
392734-1-5	VALVE
393020-01789	OIL INDICATOR
393026-01838	INDICATOR
393026-044	INDICATOR
393027-010	INDICATOR
39-353	SKID VALVE
396064-1	VALVE
396064-1-1	FLOW CONTROL VALVE
396442-1	PACK CONTROL VALVE
396608-1	VALVE
397802-7	VALVE
397868-1-1	VALVE
398116-1-1	BUTTERFLY VALVE
398188	VALVE DRAIN ASSY
398908-2	TEMPERATURE CONTROL V
398908-3	VALVE ASSY
4B3500-1C	INVERTER
4PTF15A210A150	SWITCH
4TB-2	EXTING.
40TP13-5	C MOTOR
40-0112-1	TAIL STROBE
40-0135-3	LIGHT ASSY
40-0135-4	NAV. LIGHT

40-0173-2	LIGHT ASSY
40-0196-11	LIGHT
40057-1	SWITCH ASSY
40-817	WHEEL SPEED TRANSDUCER
40F104	VALVE
40-0196-11	ANTI COLLISION BEACON
400196-13	BEACON
40022-1	VALVE
400220-1	VALVE
40028	OVEN MOTOR
40057-1	SWITCH
40064	MOTOR OVEN
4024400-3	RECORDER
4024400-5	RECORDER
4024400-7	RECORDER
4024570-3	RECORDER
40476	CONTAINER-ICE
40-553	WHEEL TRANSDUCER
40574	ACTUATOR
40574-2	FUEL SHUT OFF VALVE
407812-5	A/C MOTOR
40-817	SPEED TRANSDUCER
41SG118-1	PRESSURE SWITCH
41SG118-2	PRESSURE SWITCH
41SG265-1	PRESSURE SWITCH
41SG287-1	PRESSURE SWITCH
4101054	AXIAL FAN
4105DA	CONTROL VALVE HYD
4129RA-ALL	STEERING VALVE
4129RA1	VALVE
4129RA7	ACTUATOR
4129RA9	ACTUATOR
416-1001-49	COFFEE MAKER
4163DA	HYD CONTROL VALVE
417N3100-132SP	PASSENGER SERVICE UNIT
417N3100-295G	PASSENGER SERVICE UNIT
417N3100-332A	PASSENGER SERVICE UNIT
417N3140-1BCABB	PSU
42D107A1	PRESSURE SWITCH
42D107A2	PRESSURE SWITCH
42D185	SWITCH
42D223	SWITCH
420110	TOW OIL PRESS SWITCH
42066-9	SWITCH
42074	EXCITER
421495	VALVE

4215-01	TRIM LIGHT
42-265	ANTI-SKID
423-0001-5	COFFEE MAKER
42-397-1	ABS CONTROL BAX
424244	PUMP
425-0001-4	COFFEE MAKER
42500015	COFFEE MAKER
42-651-01	CONTROL BOX
4311500-00-55-00	OVEN
43-1749-1	HEATER
4323100-00-66-22	OVEN
4360004-88-0018	WATER HEATER
43663	IGNITER BOX
43667	INDICATOR
446469	HEATER
4472R180	BRAKE ASSY
449211	DRIVE
45-0083-2	LIGHT
45-0083-3	LANDING LIGHT
45-0083-5	LIGHT
45-0083-7	LANDING LIGHT
45-0351-ALL	LIGHT
4556	VALVE
46366-1	MOTOR
46366-2	MOTOR
4639	LANDING LIGHT
4812-70	MOTOR ASSY
4951957	STARTER
49965	EXCITER
49988	EXCITER
50E99-1	VALVE
50-0117-1	LIGHT
50-0128-1	LIGHT
50-0128-1MA	LIGHT
50-0128-3MA	LIGHT
50-0199-9	LIGHT
500-323-1A	COFFEE MAKER
500702-4620	FAN
50086-003	CIRCUIT BREAKER
5009-4-23	VALVE
50103-505	SEAT
50137-002	RELAY
50179-3A	BRAKE
5059	VALVE
5060-4	VALVE
5073	MASK

51VM1-3	PRESSURE SWITCH
511000	VALVE
5142-1	SPEAKER ASSY
515107	PUMP ASSY-MAIN OIL
516029-2-1	MOTOR
516038	MOTOR
516120-4	MOTOR
518367	PLU
520A60B50	RELIEF VALVE
522-0875-006	AMPLIFIER
522-2357-00	PANEL
522-2450-014	RECORDER
522-2788-015	COMPAR.
522-3120-004	INDICATOR
522-3121-185	COMPUTER
522-3138-004	INDICATOR
522-3487-002	INDICATOR
522-3487-004	INDICATOR
522-4025-001	ALT. ALERT.
522-4209-001	INTERROG.
522-4363-004	INDICATOR
522-4538-002	INDICATOR
522-4655-001	PANEL
522649	HEATER
5283D100-27	STARTER
5374AD	COFFEE MAKER
540594-3-1	ACTUATOR
541674-XX-4	RAM AIR LINEAR ACT
541674-1	ACTUATOR
541674-1-1	ACTUATORS
541674-3	ACTUATOR
541674-4	ACTUATOR
541674-4-1	ACTUATOR
541674-5	ACTUATOR
541674-6	ACTUATOR
541932-1	ACTUATOR
541932-1-1	ACTUATOR ROTARY
548376-5	TEMPERATURE CONTROL
548376-6	TEMPERATURE CONTROL
548384-1	SENSOR
548388-1	SENSOR
548620-2	SWITCH TEMP
55-0331-3	STROBE LIGHT
55076-ALL	PUMP
55098	HYDRAULIC PUMP
55098-01	PUMP

55098-08	HYDRAULIC PUMP
56B17C	BUL
5600-1C1A-F20B	CYLINDER
56019-003	ROTARY ACTUATOR
56019-005	ACTUATOR
56024-004	ACTUATOR
56193	PUMP
5669-7	VALVE ASSY
568-1-26713-003	FUEL BOOST PUMP
568-1-26713-004	FUEL BOOST PUMP
568-1-26713-005	PUMP
569653	PUMP
57186-ALL	PUMP
572757-1	SWITCH
5796	OVEN
58120-1	ACTUATOR
5831	WATER HEATER
59600-5003	VALVE ASSY
59600-5011	VALVE
5995	COFFEE MAKER
60B50037-38	LIGHT ASSY
60B50037-39	LIGHT ASSY
600-0108-3	OVEN
60-1177-9	BATTERY
601200-01	ACTUATOR
60125	VALVE
60127	VALVE
60128	VALVE
60-1321-1	BA. PWR. S.
6042H152	RELAY
60470	ACTUATOR
60-4983-3	POWER SUPPLY
60-4984-3	POWER CABLE
60-4984-15	POWER CABLE
60-540-1	EMERGENCY LIGHT
606802	BLOWER
606802-2	BLOWER
606850-2	FAN
607400-ALL	SELECTOR
607510-2	TEMP CONTROLLER
607714-6-2	TEMP CONTROL BOX
610318	OVEN CONTROL MODULE
61-0478-9	BATTERY PACK
61-0479-1	POWER SUPPLY
61163	VALVE
61183	VALVE

61185		FUEL SHUT OFF VALVE
61-20200-6		HARNESS
61-46-1		RELAY
61-47-1		VALVE LIMITER
61185		VALVE
616530		VALVE
6172		VALVE
6174-1		VALVE
6174-2		VALVE
6212-1		ACTUATOR
6213-3		FUSE HYD
6213-5		FUSE
622-0075		AMPLIFIER
622-5342-001		PASSENGER ADDRESS
623337		PUMP
623339		PUMP
6252		FUSE
6257		HYDRAULIC FUSE
626447		VALVE
6271		HYDRAULIC FUSE
62735		MOTOR
6274-1		HYDRAULIC FUSE
637-15	G37-15	SWITCH
6373-2		REGULATOR
6379-2C		CYLINDER
641137-1		SWITCH
645055-3		FAN
645172-1		BLOWER
645172-2		BLOWER
645405-1		FAN
645405-2		FAN ASSY
645705-1		FAN
64769-001		COFFEEMAKER
64769-005		COFFEEMAKER
65C16839-121DH		PASSENGER SERVICE UNIT
65C16839-124		PASSENGER SERVICE UNIT
65C16839-124DH		PASSENGER SERVICE UNIT
65W01025		PUMP
65-0294-21		LIGHT ASSY
65-0294-7		LAMP
65075-06		HYDRAULIC PUMP
65-17825-1		VALVE
65-2099B		S. VALVE AS.
65-21630-92		FLAP
65-24917-367		ACCESSORY
65-24918-367		RECEIVER



65-26578-39	LENS
65-26578-40	LENS
65-34780-52	FENCE
6535	VALVE
65-37559-7	ACTUATOR
65-44521-4	VALVE
65-44551-5	ACTUATOR
65-44551-6	ACTUATOR
65-44561-10	ACTUATOR
65-44561-5	ACTUATOR
65-44561-7	ACTUATOR
65-44581-2	VALVE S/O
65-44581-7	VALVE S/O
65-44651-11	ACTUATOR
65-44651-13	ACTUATOR
65-44651-16	ACTUATOR
65-44651-6	ACTUATOR
65-44651-7	ACTUATOR
65-44651-8	ACTUATOR
65-44651-9	ACTUATOR
65-44689-3	HYDRAULIC VALVE
65-44731-2	ACTUATOR
65-44741	ACTUATOR
65-44828-4	VALVE
65-44851-7	ACTUATOR
65-44861-4	UNIT
65-44891	MODULE
65-44891-7	MODULE
65-44894	HYD VALVE
65-44898-2	DAMPER
65-44899-2	HYD VALVE
65-44910-7	ACTUATOR
65-44931-12	VALVE ASSY
65-45132-10	COMPUTER
65-5260-148	PSU
65-45871-55	PANEL
65-46202-2	LINK
65-46220-4	LINK
65-46421-107	SLAT
65-46421-168	SLAT
65-46422-194	SLAT
65-46422-950	SLAT
65-46423-175	SLAT
65-46430-2	FLAP ASSY
65-46430-77	FLAP
65-46451-23	SPOILER

65-46451-25	SPOILER
65-46486-509	EDGE ASSY
65-46557-519	TAIL CONE
65-47836-12	TOGGLE
65-49539-256	PANEL ASSY
65-49808-18	RELAY
65-49808-19	MODULE F
65-49808-21	MODULE F
65-49970	JACKSCREW
65-50251-7	FLAP TRAN
65-50258-5	TRANS.
65-5094-271	COWL APU
65-51602-3	VALVE
65-51602-7	CONTROL
65-52201-87	DOOR ML
65-52801-24	CONTROL
65-52802-1	BOX
65-52803-1	W/HT CTR.
65-52803-8	W/HT CTR.
65-52804-15	ACCESSORY
65-52804-79	AUDIO ACC.
65-52805-141	ACCY. UNIT
65-52806-33	UNIT
65-52808-3	UNIT
65-52809-15	UNIT
65-52810-6	A/C RELAY
65-52811-115	ACC. UNIT
65-52812-54	ACCESS
65-52813-16	P/S TEST
65-52814-5	MODULE
65-53761-5	ROD
65-54465-30	RADOME
65-54499-12	BOX
65-5531-7	DUCT ASSY
65-55583-1	PANEL
65-55583-2	PANEL
65-58163-118	CARD ASSY
65-58163-127	CARD ASSY
65-60210-11	ACCESSORY
65-60210-14	AUD/ACC
65-60212-11	POS. XMTR.
6563	VALVE
65-63696-1	PANEL
65-67221-21	STANCHION
65-68935-4	VALVE COOLING AIR
65-69584-3	FITTING

65-69630-1	SUPPORT
65-69646-1	PANEL
65-70947-23	PANEL
65-71902-1	FLAP
65-71926-1	FLAP
65-71970-2	FLAP
65-73606-29	UNIT
65-73606-5	UNIT
65-73734-2	AILERON
65-73761-13	MLG
65-73761-14	MLG
65-73762-7	GR/NOS
65-73784-5	ELEVATOR
65-73787-15	L. NOSE
6577-1	FAN
6577-2	BLOWER
65-79164-125	PSU
65-79164-126	PSU
65-79164-127	PSU
65-79164-128	PSU
65-80049-10	MOTOR GEARED
65-80051-11	BRACE
65-86413-39	PSU
65C12932-10	CYLINDER
65C25675-37	MOD. KIT
65W01025	HYDRAULIC PUMP
65W01025	POWER DRIVEN HYD PUMP
650-75-02AD101-68A	PUMP
65075-06	HYDRAULIC PUMP E.D.
6513F	ACTUATOR
651300-08	ACTUATOR
6562	FUEL SHUTOFF VALVE
6563	FUEL SHUTOFF VALVE
6563	VALVE
6568	FUEL SHUTOFF VALVE
66030-5	VALVE
66079	GENERATOR
66087	PUMP
6635	CHECK VALVE
66940	VALVE
67-0033-1	ACTUATOR
67251	OVEN
67-2905-001	SHUTOFF VALVE
67-2906-002	VALVE
67-2906-01	VALVE
680-20705-01	TRANSFORMER RECTIFIER

69-1120-03	CONTACTOR
692525-9	SWITCH
69-35336-1	TOGGLE
69-37307-52	PANEL
69-37314-16	PANEL
69-37314-19	PANEL
69-37317-37	HYDRAULIC PUMP
69-37319-45	A/C
69-37319-60	MODULE
69-37321-5	EL. MOTOR
69-37325-28	PANEL
69-37325-36	MODULE
69-37325-51	PANEL
69-37328-5	LIGHT
69-37357-16	MODULE
69-54499-1	VALVE
69-54600-3	CYLINDER
69-55179-25	DIMMER MODULE
69-59895-3	LINK
69-58997-1	ROD
69-60035-1	CARD
69-61912-5	CRANK
692545-1	VALVE
692546-1	VALVE-PNEUMATIC
69301-1	HEAT CONTROL
696233B	C.S.D.
698430-1	LOW OIL PRESSURE SWITCH
698430-2	SWITCH-SEQUENCING OIL
698788-2	APU
699647	C.S.D.
699647A	C.S.D.
699647B	C.S.D.
699647C	C.S.D.
7G110-6	PRESSURE SWITCH
70-0240-5	LIGHT MODULE
700842A	CSD
7026-1	SWITCH
70507-2	METERING V
708600-1	FUEL PUMP
711003-3	VALVE
71234	HAND PUMP
71577-2	PUMP
71577-3	PUMP
71577-4	PUMP
71577-5	PUMP
71998	VALVE, HYD

7206700		OVEN
72067002		OVEN
72067750		OVEN
72068050		OVEN
720737-2		VALVE
720737-4		VALVE
720737-5		VALVE
72110001B		MAKER
72184007B		COFFEE MAKER
72184012B		WATER BOILER
72184015B		WATER BOILER
72340		VALVE
724234		VALVE
724234-2		VALVE
724234-3		VALVE
726218		VALVE
72909		VALVE
72926-1		VALVE
731753		CSD
732-1660-01		VALVE
735511A		CSD
736808		FUEL PUMP
75-0123-7		LIGHT ASSY
75-0123-9		LIGHT ASSY
75-0147-9A		LIGHT SET
75-0149-7		VALVE
75-0149-9		LIGHT PANEL
7501-6		BOOST PUMP MOTOR
7505639		PANEL
75130		VALVE ASSY
754317		VALVE BLEED 8 STG
7551868		CAS DRAIN FILTER
761574B		I.D.G.
776655		HYDRAULIC PUMP
777-1083-002		IND. APU
787-6226-001		INDICATOR
792-6357-002		INDICATOR
793T100-5		DRIVE UNIT
793T100-7		DRIVE UNIT
8C237		VALVE
8DJ588LWN		INDICATOR
8DJ81WAG		INDICATOR
8DJ88LWD		INDICATOR
8D1004	S341A001-11	PRESSURE SWITCH
8D111	10-60523-1	PRESSURE SWITCH
8D111-1	10-60523-11	PRESSURE SWITCH

8D111-2	10-60523-12	PRESSURE SWITCH
8D111-5	10-60523-24	PRESSURE SWITCH
8D111-7	10-60523-27	PRESSURE SWITCH
8D112-1	10-60523-21	PRESSURE SWITCH
8D115-2	10-60783-2	PRESSURE SWITCH
8D115-3	10-60783-3	PRESSURE SWITCH
8D115-4	10-60783-7	PRESSURE SWITCH
8D118-2	10-60784-2	PRESSURE SWITCH
8D182-7	10-60523-7	PRESSURE SWITCH
8D182-8	10-60523-8	PRESSURE SWITCH
8T58GAND		P.S.
8T588GAP-1		P.S.
8001-06-0000		OVEN
801240-ALL		TURBO FAN
801307-04		OXYG./CYL.
801308-31		VALVE
80414		ACTUATOR GATE
80415		ACTUATOR GATE
8054-01-0000		OVEN
807926-401		ACTUATOR
807926-403		ACTUATOR
807926-405		ACTUATOR
807962-401		ACTUATOR, AIRSTAIR
807962-403		ACTUATOR, AIRSTAIR
808512-401		LIGHT
809044-7		ACTUATOR
809044-8		ACTUATOR
809500-17		EXTINGUISHER
81000-17501		LIGHT ASSY
81000-37601		LIGHT
8136-3		FAN ASSY
83000-05602		CONTROLLER
83752-1		VALVE
851CM		P. TUBE
857-1		A.A. SYST.
861C0552M1		VALVE
86782-2		TRANS.
870905		EXTINGUISHER
871138		HYDRAULIC PUMP
887477		PUMP
887479		PUMP
887480		PUMP
887692		VALVE
8921082G1		TACH INDICATOR
8921082G5		WATER HEATER
892480		EXTINGUISHER

8-930-03	BATTERY CHARGER
893635	ACTUATOR, AIRSTAIR
895899	SENSOR
898230-1	VALVE
899981-1	ATOM. APU
9JY20A1	CUR/TRANS
9JY21AK1	CUR/TRANS
90G183	SWITCH LP
90G235	PRESSURE SWITCH
90G37	PRESSURE SWITCH
9011520100	ATTENUAT
906D896-1	TRANSFORMER
906D896-3	TRANSFORMER ASSEMBLY
907D621-1	A/C MOTOR
9123-8056	RELAY
9123-8071	RELAY
9124-8074	RELAY
9125-2ZC7C4-001	GENERATOR
915F212-3	BUS PROT PANEL
915F212-4	GCU
915F212-5	GCU
915F213-ALL	BUSS CONTROL `
915F213-3	PROT. PANEL
922D025-1	AIR STAIRS MOTOR
9238M66P07	IGNITION EXCITER
9274-6686	RELAY
930D113-1	A/C MOTOR
939548	PUMP ASSY
94BF458-1	GENERATOR
94P1-1	PRESSURE SWITCH
94P17	PRESSURE SWITCH
94P18	PRESSURE SWITCH
94P24	PRESSURE SWITCH
941D335-2	RELAY
941D335-2B	CONTACTOR
941D335-4	CONTACTOR
941D340-1	TRANSFORMER
941D347-2	CIRC/BRD
941D631-2	MOTOR AC
942D025-1	MOTOR DC
948F458-1	GENERATOR CONTROL UNIT
948F458-5	GENERATOR CONTROL UNIT
948894-4-1	SWITCH
948894-2-2	VALVE
948894-5	SWITCH
9543344	PRESS CONTROL VALVE

9550339	TRANSDUCER
9550604L	VALVE
9561006-1	SKID CONTROL BOX
9561006-2	SKID CONTROL UNIT
9561006-3	UNIT
9561006-3R	CONTROL BOX
966-0013-003	TRANSMIT.
96774-18-1299-6	INDICATOR
968390-1	VALVE
9700C1A-BF230	CYLINDER
975-0062-001	SWITCH
976J119-12	GENERATOR
976J119-6	GENERATOR
976J119-8	GENERATOR
976J252-6	GENERATOR
976J252-8	GENERATOR
976J497-1	ALTERNATOR
976J498-1	GCU
976J498-2	GENERATOR
976J597-1	ALTERNATOR
976J598-1	ALTERNATOR
976036-2	TANK
9765498-1	GENERATOR
979070-7-1	VALVE
979078-1-1	VALVE
979078-2-1	VALVE
979102-1-1	STARTER VALVE
979102-5-1	STARTER VALVE
979410-1-1	VALVE
98G176	SWITCH
980-1005-001	MAGAZINE
98505-1218-2	OIL PRESSURE SWITCH
98505-1437-1	OIL PRESSURE SWITCH
989-0505-00	SWITCH



# *Consolidated Aircraft Supply Co., Inc.*

55 Raynor Ave Ronkonkoma, NY 11779

Phone: 631-981-7700 Toll Free: 800-422-6300 Fax: 631-981-7706

E-mail: CONSOL1291@aol.com

Web address: www.consolac.com

## **AVIONES DE TRANSPORT CAPABILITY LISTING (ATR42)**

<b><u>PART NUMBER</u></b>	<b><u>DESCRIPTION</u></b>
ACP2531	AUDIO CONTROL PANEL
A1148B	POWER DC CONTACTOR
AV24B1319D3	VALVE
BHC1000	VALVE BLOCK FLAP
BHC1021	VALVE BLOCK SPOILER
B03AA1012	VALVE DE ICING DUAL DIST
B03AA1020	VALVE
B03AA1031	VALVE
B07EF2000	DRAIN WATER WING
B-138S	RELAY
B14GF1501	VALVE DE ICING PRESS REG
B14GF1502	VALVE DE ICING PRESS REG
B14GF1503	VALVE
B04NA1500	FAN
B40NA1500	FAN SMOKE DETECTION
B47CA1090	VALVE
B97N19-201	VALVE FILLING & DRAINING
CAU2533	REMOTE CONTROL AUDIO UNIT
CT60	LP BLEED AIR CHECK VALVE
C11VQ0013	PUMP FUEL ELECTRIC
C11VQ0020	PUMP FUEL ELECTRIC
C17LR0010	JET PUMP FEEDER TANK
C17MQ0010	JET PUMP ENGINE FEED
C24295350	SOLENOID VALVE NLG
C24483010	SELECTOR SWIVEL VALVE
C24568000-4	VALVE
C24644070	RESTRICTOR VALVE
C24656070	RESTRICTOR VALVE
C49AA0210	ELECTRIC PUMP CANISTER
C49AA0211	ELECTRIC PUMP CANISTER
DMN27-2	MKR. BEACON
DVE90-04	VALVE FEED STOP

D14DB	CONTRACTOR DC
D22715000	ACTUATOR
EVAC2423FD	FAN
EVAC2423H	FAN
EVAC23EXA	COOLING FAN
EVAC523-SERIES	RECIRCULATION FAN
EVCTA325	FAN AIR DISTRIBUTOR
EVTA1925B	FAN
EVTA1926	FAN AIR EXTRACTION
EVTA1926DC	FAN-AIR EXTRACTION
EV5247-2-00	ELECTRO VALVE
E308-1	UNDER VOLTAGE RELAY
E311PB	RELAY
GB0680AA0	CHECK VALVE
GB0800AA0	CHECK VALVE
L83A13-601-1	DRAIN WATER
L83A13-605-1	DRAIN WATER
L83A13-606-1	DRAIN WATER
L83A23-608	DRAIN WATER
L87-20-202	FLOAT VALVE
L87-26-601	VENT FLOAT VALVE
L87F26-601	VENT FLOAT VALVE
L93C31-651	VALVE
L93D31-651	VALVE
NB01201	IGNITION UNIT
N10605	IGNITION UNIT
PA2532AB01	PUBLIC ADDRESS AMPLIFIER
PA2532A1301	PASSENGER ADDRESS AMP
PC251	INVERTER
PC251-123E	INVERTER
PR4237-1	STICK SHAKER
Q1794122051AA	CLOCK
RP171-00	OVERHEAT SENSOR
R25-1M2	LIGHT
R25-1M2BR	LIGHT
R25-1M8R	LIGHT
R25-1-1A	POWER SUPPLY
SM15AXD3	CONTACTOR
SM15CWD3	RELAY
SM400D28	RELAY
SM400D29	RELAY
SM400D30	RELAY
SVL6028-25-09	PUMP
VL32C11	CARGO DOOR ACTUATOR
VST170	GROUND VENTILATION VALVE
VST170A	VALVE

VST170-1	GROUND VENTILATION VALVE
V2T125-1	UNDERFLOOR VALVE
V2T61	UNDERFLOOR VENT VALVE
V5000-220	SOLENOID VALVE
011232-100	RECIRCULATION FAN
011260-100	EXTRACTION FAN
101CC01A02	CONTACTOR
101004-03	VALVE
1019501	HYDRAULIC PUMP
102003-1	G.C.U
102003-11	G.C.U
103003-2	HALL EFFECT SENSOR
10-381550-4	EXCITER
1039B25-1	FUEL VALVE
1040B25-1	CROSSFEED VALVE
10-516000-3A	EXCITER IGNITION
106ZC0562004B	CABIN TEMP FLOW SENSOR FAN
1103P0603	PRESSURE SWITCH
11059-72	TIMER TOILET
1153-000	FUEL PRESSURE SWITCH
1158-200	PRESSURE SWITCH
1173T0319	OVERHEAT SENSOR
1173T0342	THERMAL SWITCH
1173T217-3	SWITCH
1206P0121	PRESSURE SWITCH
121CC01A02	CONTACTOR
1304-000	PRESSURE SWITCH
140-071	TRANSDUCER
14302-211	TIMER ASSEMBLY
1656-6	EMERGENCY BATTERY
2LA002607-16	LIGHT
20032	ALTERNATOR
20032-2	AC ALTERNATOR
20032-2B	ALTERNATOR
20732	CURRENT TRANSFORMER
2095E020800	VALVE
2095F020800	VALVE
2096G020800	VALVE
2096H020800	VALVE
2206170-1	GROUND COOLING FAN
2214805-5	VALVE
242-082-3	VALVE
242-082-4	VALVE
2432-11	GENERATOR CONTROL UNIT
2432-30	GCU
26942	BLOWER

2757B01	VALVE
291-SERIES	NAVIGATION LIGHT
291-10	NAVIGATION LIGHT
291-21	NAVIGATION LIGHT
291-31	NAVIGATION LIGHT
292-00	ANTI COLL LIGHT
292-12	STROBE LIGHT
292-13	STROBE LIGHT
292-24	STROBE LIGHT
2936	LP FUEL VALVE ACTUATOR
2940	FUEL CROSSED ACTUATOR
301-1004	POWER SUPPLY
301-1180	EMERGENCY LIGHT
301-1185A	POWER SUPPLY
301-2000	POWER SUPPLY
3033378	IGNITION EXCITER
3035526	FUEL PUMP
3035889	EXCITER
3100035	TEMPERATURE SENSOR
3108502	CHECK VALVE
3202258-2	BLEED AIR CHECK VALVE
3202260-1	CHECK VALVE
320482-2	SHUT OFF VALVE
3214102-4	REGULATOR
3214558-2	VALVE
3214560-2	REGULATING VALVE
3214958-ALL	VALVE
3214960-1	VALVE
3214960-2	REGULATING VALVE
3214960-3	VALVE
3289674-1	TURBINE BYPASS VALVE
3289704	SHUT OFF VALVE ASSY
3289704-1	SHUT OFF VALVE
3289706-1	ECU ISOLATION VALVE
3290104-1	HOT BYPASS VALVE
3290196-1	ECU ISOLATION VALVE
3290288-1	TEMPERATURE CONTROL VALVE
400SG137Q	GENERATOR
40195-01	PUMP
40196-01	PUMP
407A0103	JET PUMP
4100D01	VALVE
41063E01	VALVE
41080F01	VALVE
41100D01	VALVE
41115A01	VALVE

41125A01	VALVE
41173B01	VALVE
41173C01000	VALVE
4122-00600-1	FEATHER PUMP & MOTOR
4122-006009	PUMP
42053	HYDRAULIC AUX PUMP
4211067	WIPER BLADE
4213966	LOGO LIGHT
4213973	LIGHT
4216009	MOTO-CONVERTER L/H
4216016	WIPER MOTOR ASSY
42160168	WIPER MOTOR
4216019	MOTO-CONVERTER R/H
4216023	WIPER ARM R/H
4216039	WIPER ARM L/H
4262461	DOOR ACTUATOR
4267812	WING INSP LIGHT R/H
4267828	WING INSP LIGHT L/H
42-741	ANTI-SKID CONTROL UNIT
42-801-1	ANTI SKID CONTROL UNIT
42023-01	PUMP
42053	PUMP
4213973A	TAXI LIGHT
4216009	RH WIPER MOTOR
4216016	LH WIPER MOTOR
4262461	CARGO DOOR ACTUATOR
4267812	WING ENGINE LIGHT
4267823	WING ENGINE LIGHT
4285098	WING INSP LIGHT L/H
4285104	WING INSP LIGHT R/H
4292915	LANDING LIGHT
4295747	TAXI LIGHT
4298738	WING INSP LIGHT R/H
4298741	WING INSP LIGHT L/H
47717	IGNITOR
48-077	LOW PRESSURE RELIEF
49930	EXCITER
5008269-SERIES	POWER DRIVE ROTARY PUMP
5009984	PUMP
5018-753-00-00	MIXING AUDIO AMPLIFIER
520913	GENERATOR
548482-4-1	CONTROL TEM
559-012A	STATIC INVERTER
559-012B	STATIC INVERTER
624820-1	TEMPERATURE CONTROLLER
624992-2	WINDSHIELD CONTROLLER

627962-1	TEMPERATURE SENSOR
627962-2	TEMPERATURE SENSOR
641134-3	SWITCH OVERTEMPERATURE
641134-4	SWITCH OVERTEMPERATURE
642012-1	PRESSURE SWITCH
683GC01Y01	PROTECTION UNIT BATTERY
6910G01	VALVE
7102AH020004	VALVE
72184003	WATER BOILER
7306G01	VALVE
7404SB01	VALVE
782655-1	PUMP
784-717-2	SWITCH OVERTEMPERATURE
785-113-1	CONTROL BOX TEMPERATURE
785-259-1	THERMOSTAT
785-403	THERMAL SWITCH
800ZN010528A	RELAY ELECTRONIC
8236-3	ACTUATOR TRIM
8260-120	STARTER ACTUATOR
8260-121	STARTER ACTUATOR
8260-123	GENERATOR
8295-1	ACTUATOR ELECTRONIC
8300-1	ACTUATOR STICK PUSHER
8312-120-00-10	SENSOR TEMPERATURE
871BN3-3	ICE DETECTOR
912D0401	REGULATOR
9300-A140-01	INVERTER
93005A01	VALVE
979142-1-1	VALVE
979142-6-1	VALVE SHUTOFF TURBOFAN
979990-1	VALVE CONTROL TEMPERATURE
98087-1173T217-3	SWITCH
3038137	EXCITER
3040032	EXCITER
3117095-1	FUEL PUMP
8210-176	PUMP
8236-3	ACTUATOR
4204301	PUMP

# *Consolidated Aircraft Supply Co., Inc.*

55 Raynor Ave Ronkonkoma, NY 11779

Phone: 631-981-7700 Toll Free: 800-422-6300 Fax: 631-981-7706

E-mail: CONSOL1291@aol.com

Web address: www.consolac.com

## **DEHAVILLAND-6 TWIN OTTER CAPABILITY LIST**

<b><u>PART NUMBER</u></b>	<b><u>DESCRIPTION</u></b>
AN6207-4	VALVE
AV1A1128	SOLENOID VALVE
AV1E1139	SOLENOID VALVE
AV16B1761B	SHUT OFF VALVE
AV16B1762B	SHUT OFF VALVE
AV16B1864B	SHUT OFF VALVE
AYLF2215-1	TEMP SENSOR
AYLF3001-1	TEMP SENSING UNIT
A413A	STROBE LIGHT PWR SUPPLY
A6458	MOTOR
A700AAP	RELAY
A701D	RELAY
A9373M1	MOTOR ONLY
BYLB9304-10	HOT AIR VALVE
BYLB9304-11	HOT AIR VALVE
BYLF7469	TEMP. SENSOR
CYLZ3230	CONTROL BOX
C6HF1020-5	ACTUATOR
C6NF1017-1	VALVE
C6SC1005-3	PUMP
C6SC1125	PRESSURE SWITCH
C65C1005-ALL	PUMP
DHCSC70019-15	PRESSURE SWITCH
DHC60148-ALL	PUMP
DH-1030-24-65-C5	TRANSVERTOR
E311C	RELAY
E329E	RELAY
F102	FAN
G8400A24	LIGHT ASSY
G8400A24C	LIGHT ASSY
G8400A36-24	BEACON LIGHT
L10-20	ACTUATOR

MS24171D1	RELAY
MS24172D1	RELAY
MS25024-ALL	RELAY
MS25035-ALL	RELAY
M3424CB	MOTOR
M5861AD-6B	BLOWER
M6921W-1B	FLOW FAN
PC15A	INVERTER
PC15B	INVERTER
PC15BC	INVERTER
PC250	INVERTER
RG15150P	PUMP
RR12830A	BOOST PUMP
SYLZ50517	TEMP CONTROLLER
TD-805V-2	OVER VOLTAGE REG.
VR1010-24-1A	VOLTAGE REGULATOR
VR1010-24-2A	VOLTAGE REGULATOR
XW21121-227-90	CONVERTER
XW21160-2	MOTOR
0253223-101-03	PUMP
025323-101	FUEL PUMP
025323-101-02	PUMP
025323-500	PUMP
1D2-14	PUMP
1D2-17	BOOST PUMP
100-681-2	PUMP & MOTOR
100-689-4	BREAKER
10-381550-1	EXCITER
10-381550-4C	
1042-17A	VOLT. REG.
12RPX12A1	CIRCUIT BREAKER
12XRP12A1	CONVERTER
12830A	PUMP
1321-536250	LEVEL CONTROL VALVE
14-91355-ALL	CONVERTER
14-97862-02	W/W MOTOR
1532-10C	VALVE
1532-3A	DE ICER DISTRIBUTER
1532-3C	VALVE
1532-8C	VALVE
160-011	BOOST PUMP
160-065	PUMP
1708906A	PUMP
17343-62-300	FIRE DETECTOR
19E26-1A	VALVE
2B7-1	PUMP



23048-ALL	STARTER GENERATOR
23048-004	STARTER GENERATOR
250SG115Q	GENERATOR
258800-3	PUMP
258800-5	PUMP
26440051	VALVE
3E1150-10	TIMER
3S206DM109A2	PANEL
3-1158-18	HYD. HAND PUMP
30-0239-1	LIGHT ASSY
30-0239-2	LIGHT ASSY
30-0516-1	LIGHT ASSY
30-0863-1	LIGHT ASSY
30-0863-3	LIGHT ASSY
30-0863-4	LIGHT ASSY
30-2815	FAN
30-863-3	LIGHT ASSY
30-863-4	LIGHT ASSY
3100829-03	VALVE
32005-007	TACH
320295-1	VALVE
38E59-ALL	VALVE
38E96-2E	DE ICER PRESSURE REG.
4100-68100-8	PUMP
4100-689004	PUMP
42E13-3A	TIMER
42E13-3B	TIMER
42245-2	LIGHT ASSY
44E06-1A	SEPARATOR
5590F1-1	STATIC INVERTER
60-1755-5	POWER SUPPLY
6607A7-31	SWITCH
6607P9-6	SWITCH
6607P9-6A	SWITCH
70-0075-1	LIGHT ASSY
71383	PUMP
71383-2	PUMP
71383-3	PUMP
71383-3A	PUMP
72266-3	PUMP
72368-1	PUMP
72390-2	PUMP
8190024	SWITCH
8190026	SWITCH ASSY
85816	PUMP
9072-3344	RELAY