

991029201	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
095001	DC VOLTAGE REGULATOR	PHOENIX AEROSPACE
095027	D.C. GENERATOR CTRL. UNIT	PHOENIX AEROSPACE
100-389005-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
101-369012-11	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
101-389007-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
101-780-80-07	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
101-780-80-18	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
101-910051-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
101-970051-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
1042-17-A	DC VOLTAGE REGULATOR	BENDIX
1152108-4	GENERATOR CTRL. UNIT	HONEYWELL
1152108-5	GENERATOR CTRL. UNIT	HONEYWELL
1152108-6	GENERATOR CTRL. UNIT	HONEYWELL
1152218-3	A.C. GENERATOR	HONEYWELL
1152218-4	A.C. GENERATOR	HONEYWELL
1152218-5	A.C. GENERATOR	HONEYWELL
1152400-2	DC GENERATOR	HONEYWELL
1152400-3	DC GENERATOR	HONEYWELL
115-389004-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
144SG143Q-1	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG111Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG114Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG115Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG116Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG117Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG118Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG119Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG120Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG121Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG122Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG122Q-XL	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG123Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG124Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG125Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG125Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
150SG144Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
1539-11A	GENERATOR CTRL. UNIT	BENDIX
1539-11B	GENERATOR CTRL. UNIT	BENDIX
1539-12-A	GENERATOR CTRL. UNIT	BENDIX
1539-12B	GENERATOR CTRL. UNIT	BENDIX
1539-12B.	GENERATOR CTRL. UNIT	BENDIX
1539-15A	GENERATOR CTRL. UNIT	BENDIX
1539-15B	GENERATOR CTRL. UNIT	BENDIX
1539-5A	GENERATOR CTRL. UNIT	BENDIX
1539-8A	GENERATOR CTRL. UNIT	BENDIX ELE.
1539-9A	GENERATOR CTRL. UNIT	BENDIX
1539-9B	GENERATOR CTRL. UNIT	BENDIX
1588-2C	GENERATOR CTRL. UNIT	BENDIX
1588-2D	GENERATOR CTRL. UNIT	BENDIX

1588-2E	GENERATOR CTRL. UNIT	BENDIX
1588-2F	GENERATOR CTRL. UNIT	BENDIX
1588-3B	GENERATOR CTRL. UNIT	BENDIX
1589-1C	GENERATOR CTRL. UNIT	BENDIX
1589-1D	GENERATOR CTRL. UNIT	BENDIX
1589-1E	GENERATOR CTRL. UNIT	BENDIX
1589-1F	GENERATOR CTRL. UNIT	BENDIX
1589-1-F	GENERATOR CTRL. UNIT	BENDIX
1589-7-B	GENERATOR CTRL. UNIT	BENDIX
160SG136Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
160SG137Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
160SG137Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
160SG139Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
160SG139Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
160SG140Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
160SG141Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
160SG142Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
20032-2	A.C. GENERATOR	HONEYWELL
200SG111Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SG112Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SG116Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SG117Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SG119Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SG121Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SG122Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SG130Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL111Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL111Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL111Q-3	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL112Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL114Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL115Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL115Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL117Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL118Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL118Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL119Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL119Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL120Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL121Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL124Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL129Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL129Q-1	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL129Q-4	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL129Q-5	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL129Q-8	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL129Q-8	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL130Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL132Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL142Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC

200SGL144Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL145Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
200SGL147Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
20B100-20A	AC VOLTAGE REG	HONEYWELL / BENDIX
20B100-2A	AC VOLTAGE REG	HONEYWELL / BENDIX
20B82-11A	GENERATOR CTRL. UNIT	BENDIX
20B82-6A	AC VOLTAGE REGULATOR	HONEYWELL / BENDIX
20B82-6B	AC VOLTAGE REGULATOR	HONEYWELL / BENDIX
20B9-1A	GENERATOR CTRL. UNIT	BENDIX
20B9-1CMX	GENERATOR CTRL. UNIT	BENDIX
20B9-2C	GENERATOR CTRL. UNIT	BENDIX
20B9-2CMX	GENERATOR CTRL. UNIT	BENDIX
20B9-2E	GENERATOR CTRL. UNIT	BENDIX
20B94-6A	AC VOLTAGE REG	HONEYWELL / BENDIX
20B95-4A	GENERATOR CTRL. UNIT	BENDIX
20B95-6A	AC VOLTAGE REG	HONEYWELL / BENDIX
21B17-10A	GENERATOR CTRL. UNIT	BENDIX
21B17-10A.	A-C VOLTAGE REGULATOR	HONEYWELL / BENDIX
21B17-10B	GENERATOR CTRL. UNIT	BENDIX
21B17-10-B	GENERATOR CTRL. UNIT	BENDIX
21B17-10B.	GENERATOR CTRL. UNIT	BENDIX
21B17-22A	GENERATOR CTRL. UNIT	BENDIX
21B17-22B	GENERATOR CTRL. UNIT	BENDIX
21B17-26A	GENERATOR CTRL. UNIT	BENDIX
21B17-28A	GENERATOR CTRL. UNIT	BENDIX
21B17-55BM	GENERATOR CTRL. UNIT	BENDIX
21B17-55C	GENERATOR CTRL. UNIT	BENDIX
21B17-5B	GENERATOR CTRL. UNIT	BENDIX
21B17-5C	GENERATOR CTRL. UNIT	BENDIX
21B17-6A	GENERATOR CTRL. UNIT	BENDIX
21B17-6B	GENERATOR CTRL. UNIT	BENDIX
21B17-6B.	GENERATOR CTRL. UNIT	BENDIX
21B17-82-B	GENERATOR CTRL. UNIT	BENDIX
21B17-96A	GENERATOR CTRL. UNIT	BENDIX
21B18-1B	GENERATOR CTRL. UNIT	BENDIX
21B18-1C	GENERATOR CTRL. UNIT	BENDIX
21B18-5-A	GENERATOR CTRL. UNIT	BENDIX
21B29-6-B	GENERATOR CTRL. UNIT	BENDIX
21B29-7-B	GENERATOR CTRL. UNIT	BENDIX
21B29-7-C	GENERATOR CTRL. UNIT	BENDIX
21B73-1-D	GENERATOR CTRL. UNIT	BENDIX
21B73-1-DM	GENERATOR CTRL. UNIT	BENDIX
21B73-1-E	GENERATOR CTRL. UNIT	BENDIX
21B73-1-F	GENERATOR CTRL. UNIT	BENDIX
21B73-2-A	GENERATOR CTRL. UNIT	BENDIX
21B73-2-B	GENERATOR CTRL. UNIT	BENDIX
23032-006	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23032-007	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23032-010	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23032-011	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI













23088-008	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23088-009	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23088-010	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23091-001	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23091-002	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23091-003	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23091-004	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23092 001	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23092-001	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23092-002	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23095-002	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23095-002	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23280-066	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23280-067	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
23291-006	DC STARTER GENERATOR	GOODRICH / TRW / LAPEC / LSI
250SG111Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG112Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG114Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG115Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG116Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG117Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG118Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG120Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG122Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG123Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG123Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG124Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG125Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
250SG127Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
25B12-3-B	GENERATOR CTRL. UNIT	BENDIX
25B31-1AM	DC GENERATOR CONTROL UNIT	HONEYWELL / BENDIX
25B31-1-AM	DC GENERATOR CONTROL UNIT	HONEYWELL / BENDIX
25B31-1-B	DC GENERATOR CONTROL UNIT	HONEYWELL / BENDIX
25B58-9-A	A.C. GENERATOR	LOCKHEED
25B58-9-B	A.C. GENERATOR	LOCKHEED
28B135-101AM	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-121A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-121A.	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-121A..	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-126	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-126A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-129A	ELECTRIC GENERATOR	BENDIX
28B135-133A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-135A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-145A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-145-A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-145AM	ELECTRIC GENERATOR	BENDIX
28B135-145-AM	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-151	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-151A	A.C. GENERATOR	HONEYWELL / BENDIX

28B135-163A	ELECTRIC GENERATOR	BENDIX
28B135-166	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-168	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-168B	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-207-A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-29A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-29A.	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-29AM	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-29-AM	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-4A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-56A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-76	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-76A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-93A	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-93AM	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-93AVD	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-9C	A.C. GENERATOR	HONEYWELL / BENDIX
28B135-9D	A.C. GENERATOR	HONEYWELL / BENDIX
28B139-13A	ELECTRIC GENERATOR	BENDIX
28B139-15A	ELECTRIC GENERATOR	BENDIX
28B139-17A	ELECTRIC GENERATOR	BENDIX
28B139-33A	A.C. GENERATOR	HONEYWELL / BENDIX
28B139-33AVD	A.C. GENERATOR	HONEYWELL / BENDIX
28B139-3A	ELECTRIC GENERATOR	BENDIX
28B139-53A	A.C. GENERATOR	HONEYWELL / BENDIX
28B139-7B	ELECTRIC GENERATOR	BENDIX
28B141-17B	A.C. GENERATOR	HONEYWELL / BENDIX
28B141-17C	A.C. GENERATOR	HONEYWELL / BENDIX
28B141-51A	A.C. GENERATOR	HONEYWELL / BENDIX
28B141-9A	A.C. GENERATOR	HONEYWELL / BENDIX
28B23-15A	A.C. GENERATOR	HONEYWELL / BENDIX
28B23-1A	A.C. GENERATOR	HONEYWELL / BENDIX
28B23-3A	A.C. GENERATOR	HONEYWELL / BENDIX
28B23-3B	A.C. GENERATOR	HONEYWELL / BENDIX
28B262-35B	A.C. GENERATOR	HONEYWELL / BENDIX
28B262-35C	A.C. GENERATOR	HONEYWELL / BENDIX
28B262-5B	A.C. GENERATOR	HONEYWELL / BENDIX
28B263-13A	A.C. GENERATOR	HONEYWELL / BENDIX
28B263-13B	A.C. GENERATOR	HONEYWELL / BENDIX
28B285-43-A	A.C. GENERATOR	HONEYWELL / BENDIX
28B285-43-B	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-2A	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-2AR	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-2B	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-2C	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-2CR	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-2D	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-4A	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-4AR	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-4B	A.C. GENERATOR	HONEYWELL / BENDIX

28B362-4BR	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-4D	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-4DR	A.C. GENERATOR	HONEYWELL / BENDIX
28B362-4E	A.C. GENERATOR	HONEYWELL / BENDIX
28B391-2-C	A.C. GENERATOR	HONEYWELL / BENDIX
28B421-2A	A.C. GENERATOR	HONEYWELL / BENDIX
28B54-1A	A.C. GENERATOR	HONEYWELL / BENDIX
28B54-1B	A.C. GENERATOR	HONEYWELL / BENDIX
28B54-9A	A.C. GENERATOR	HONEYWELL / BENDIX
28B54-9B	A.C. GENERATOR	HONEYWELL / BENDIX
28B58-17A	A.C. GENERATOR	HONEYWELL / BENDIX
28B58-17-A	ELECTRIC GENERATOR	BENDIX
28B58-57A	A.C. GENERATOR	HONEYWELL / BENDIX
28B58-57-A	ELECTRIC GENERATOR	BENDIX
28B58-9A	A.C. GENERATOR	HONEYWELL / BENDIX
28B58-9-A.	A.C. GENERATOR	HONEYWELL / BENDIX
28B58-9B	A.C. GENERATOR	HONEYWELL / BENDIX
28B58-9-B.	A.C. GENERATOR	HONEYWELL / BENDIX
28B94-103A	A.C. GENERATOR	HONEYWELL / BENDIX
28B94-111-A	A.C. GENERATOR	HONEYWELL / BENDIX
28B94-129A	A.C. GENERATOR	HONEYWELL / BENDIX
28B94-15A	A.C. GENERATOR	HONEYWELL / BENDIX
28B94-5-A	A.C. GENERATOR	HONEYWELL / BENDIX
28B94-5-AM	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-15A	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-15B	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-15C	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-15D	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-15D(V)	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-35A	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-35B	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-57A	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-59A	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-65A	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-65A KM1	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-9A	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-9B	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-9C	A.C. GENERATOR	HONEYWELL / BENDIX
28B95-SERIES	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-11-A	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-11-B	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-13-A	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-13-C	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-22-B	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-22-BM	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-22-D	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-27-A	A.C. GENERATOR	HONEYWELL / BENDIX
28E20-27-AM	A.C. GENERATOR	HONEYWELL / BENDIX
2CM210B1E	A.C. GENERATOR	GENERAL ELECTRIC
2CM210B1G	A.C. GENERATOR	GENERAL ELECTRIC

2CM210C1E	A.C. GENERATOR	GENERAL ELECTRIC
2CM210C1G	A.C. GENERATOR	GENERAL ELECTRIC
2CM214B1E	ELECTRIC GENERATOR	GENERAL ELECTRIC
2CM214B8	ELECTRIC GENERATOR	GENERAL ELECTRIC
2CM214B9	ELECTRIC GENERATOR	GENERAL ELECTRIC
2CM217A10	A.C. GENERATOR	GENERAL ELECTRIC
2CM217A5	A.C. GENERATOR	GENERAL ELECTRIC
2CM217A5A	A.C. GENERATOR	GENERAL ELECTRIC
2CM217A7	A.C. GENERATOR	GENERAL ELECTRIC
2CM217A7A	A.C. GENERATOR	GENERAL ELECTRIC
2CM217SERIES	A.C. GENERATOR	GENERAL ELECTRIC
2CM270D2A	STARTER MOTOR	GENERAL ELECTRIC
2CM270D3	STARTER MOTOR	GENERAL ELECTRIC
2CM270D5	DC STARTER MOTOR	GENERAL ELECTRIC
2CM270D5C	DC STARTER MOTOR	GENERAL ELECTRIC
2CM270D7	D.C. STARTER MOTOR	GENERAL ELECTRIC
2CM353C1	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1D	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1D.	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1E	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1F	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1H	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1H.	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1J	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1J.	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1K	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1L	A.C. GENERATOR	GENERAL ELECTRIC
2CM353C1P	A.C. GENERATOR	GENERAL ELECTRIC
2CM355A1	A.C. GENERATOR	GENERAL ELECTRIC
2CM355B2	A.C. GENERATOR	GENERAL ELECTRIC
2CM355C1	ELECTRIC GENERATOR	GENERAL ELECTRIC
2CM355C2	ELECTRIC GENERATOR	GENERAL ELECTRIC
2CM355D2A	A.C. GENERATOR	GENERAL ELECTRIC
2CM355D3	A.C. GENERATOR	GENERAL ELECTRIC
2CM355D5	A.C. GENERATOR	GENERAL ELECTRIC
2CM355D5A	A.C. GENERATOR	GENERAL ELECTRIC
2CM355D6	A.C. GENERATOR	GENERAL ELECTRIC
2CM535C1J	A.C. GENERATOR	GENERAL ELECTRIC
2CM63C7	D.C. GENERATOR	GENERAL ELECTRIC
2CM63C7A	D.C. GENERATOR	GENERAL ELECTRIC
2CM63C7B	D.C. GENERATOR	GENERAL ELECTRIC
2CM63E1	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM75D2BT	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM75D2M	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM75D6	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM75D6D	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM75D7	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM75D7B	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM75D7E	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM75D7F	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.

2CM76C1	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM76C4A	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM76C7	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM76C7A	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM76C7B	DC GENERATOR	GENERAL ELECTRIC AEROSPACE DIV.
2CM77B10	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM77B8A	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM77B8C	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM77D3	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM77D3B	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM77D3V	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM77D3VB	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM82J1	DC STARTER GENERATOR	GENERAL ELECTRIC
2CM82J1B	D.C. STARTER MOTOR	GENERAL ELECTRIC
2CM82J2	D.C. STARTER MOTOR	GENERAL ELECTRIC
2CM82J4	D.C. STARTER MOTOR	GENERAL ELECTRIC
30076-007	D C GENERATOR	GOODRICH / TRW / LAPEC / LSI
30081-001	DC GENERATOR	LUCAS AEROSPACE/LSI
30081-010	D.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
30086-010	DC GENERATOR	GOODRICH / TRW / LAPEC / LSI
30086-011	DC GENERATOR	GOODRICH / TRW / LAPEC / LSI
300SG117Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SG118Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SG119Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SG120Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SG121Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SG121Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SG125Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SG126Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SG127Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL111Q-1	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL111Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL114Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL115Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL116Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL116Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL118Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL126Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL127Q-1	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL127Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL127Q-3	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL127Q-4	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL129Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL129Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL129Q-3	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL138Q-2	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL138Q-4	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL138Q-5	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL139Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL145Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC

300SGL146Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL150Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
300SGL152Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
30B107-11-A	D.C. GENERATOR	HONEYWELL / BENDIX
30B107-19-A	DC GENERATOR	HONEYWELL / BENDIX
30B107-7-F	D.C. GENERATOR	HONEYWELL / BENDIX
30B119-5-A	D.C. GENERATOR	BENDIX
30B119-9-A	D.C. GENERATOR	BENDIX
30B37-15A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-17A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-23B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-37A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-3A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-41A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-49A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-49B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-49BM	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-49BT	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-51A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-54A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-55A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-63A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B37-7B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B43-17A	DC GENERATOR	HONEYWELL / BENDIX
30B43-1-A	D-C GENERATOR	HONEYWELL / BENDIX
30B43-24A	DC GENERATOR	HONEYWELL / BENDIX
30B43-7A	DC GENERATOR	HONEYWELL / BENDIX
30B43-7B	DC GENERATOR	HONEYWELL / BENDIX
30B43-SERIES	DC GENERATOR	HONEYWELL / BENDIX
30B45-21-A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B45-22-A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30B58-13A	DC GENERATOR	HONEYWELL / BENDIX
30B58-1A	DC GENERATOR	HONEYWELL / BENDIX
30B58-3B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E02-11C	DC GENERATOR	HONEYWELL / BENDIX
30E02-11E	DC GENERATOR	HONEYWELL / BENDIX
30E02-11G	DC GENERATOR	HONEYWELL / BENDIX
30E02-19G	DC GENERATOR	HONEYWELL / BENDIX
30E02-21	ELECTRIC GENERATOR	BENDIX
30E02-21G	ELECTRIC GENERATOR	BENDIX
30E02-27A	ELECTRIC GENERATOR	BENDIX
30E02-5C	DC GENERATOR	HONEYWELL / BENDIX
30E02-5E	DC GENERATOR	HONEYWELL / BENDIX
30E02-5F	DC GENERATOR	HONEYWELL / BENDIX
30E02-5G	DC GENERATOR	HONEYWELL / BENDIX
30E02-9C	DC GENERATOR	HONEYWELL / BENDIX
30E02-9E	DC GENERATOR	HONEYWELL / BENDIX
30E02-9F	DC GENERATOR	HONEYWELL / BENDIX
30E02-9G	DC GENERATOR	HONEYWELL / BENDIX
30E02-SERIES	DC GENERATOR	HONEYWELL / BENDIX

30E13-6-D	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E13-6-F	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E13-6-G	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-111A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-111B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-11A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-11B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-11C	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-19-A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-1-A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-33-B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-39A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-41A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-41B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-41B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-49-A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-49B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-5-A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-5-B	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-5-C	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-61A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-69A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-97A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-97-A	DC STARTER GENERATOR	HONEYWELL / BENDIX
30E20-9-A	DC STARTER GENERATOR	HONEYWELL / BENDIX
31008-011	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31008-012	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31008-013	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31161-001	A.C. GENERATOR	GOODRICH
31164-000	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-002	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-002B	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-003	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-003A	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-003AB	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-003B	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-004	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-004B	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31164-005	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31176-001	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31176-002	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31220-002	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31220-003	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31220-004	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31220-004.	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31220-004..	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31220-006	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31220-009	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31229-000	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31342-001	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI

31342-003	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
31425-011	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31708-000	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31708-000A	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31708-001	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31708-001A	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31708-002	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31708-002A	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31708-003	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
31708-003A	ELECTRIC GENERATOR	GOODRICH / TRW / LAPEC / LSI
3S2020BR129A1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2020BR129B1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2020BR134B1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2020BR134C1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2060DC168A1A	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2060DC168B1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2060DC168D1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2060DR113A1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2060DR113C1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2060DR113C2	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2781F121C1A	CONTROL UNIT	GENERAL ELECTRIC
3S2781F121C1B	CONTROL UNIT	GENERAL ELECTRIC
3S2781F121C1B1	CONTROL UNIT	GENERAL ELECTRIC
3S2781F121C1C	CONTROL UNIT	GENERAL ELECTRIC
3S2795F107B1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2795F107B11	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2795F107B1A	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
3S2795F107B1A1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
400SG111Q-1	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG111Q-3	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG111Q-4	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG112Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG114Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG115Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG119Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG123Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG134Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG135Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG136Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG137Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG138Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG139Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG142Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG143Q-1	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG143Q-4	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG146Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG157Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG158Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG159Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG163Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC



400SG165Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG166Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
400SG168Q	DC STARTER GENERATOR	SKURKA AEROSPACE / UNISON / APC
50-380076-001A	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
50-380076-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
50-380076-5	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
51065-013	GENERATOR CTRL. UNIT	AAE/LSI
51065-014	GENERATOR CTRL. UNIT	AAE/LSI
51102-000	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51102-001	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51102-002	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51102-003	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51102-007	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51107-003	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51115-000	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51202-002	GENERATOR CTRL. UNIT	LUCAS/LSI
51202-003	GENERATOR CTRL. UNIT	LUCAS/LSI
51202-011	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51202-011-2	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51202-011-3	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51203-000	GENERATOR CTRL. UNIT	LUCAS/LSI
51203-011	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51203-011-0	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51203-011-1	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-001	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-001R	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-002	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-002A	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-002B	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-002R	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-006	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-006B	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-006BR	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-006C	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-006D	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-006E	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51509-006Z	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51511-001	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51511-002	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51511-003	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51511-004	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51525-001B	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51525-001C	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51525-001E	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51525-001F	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51525-002B	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-001	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-001A	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-001E	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-001EI	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI

51530-006	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-006A	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-006B	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-007	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-007A	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-007B	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-007D	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-008	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51530-SERIES	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51538-001A	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51538-001B	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51538-001C	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51538-001D	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51538-002A	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51538-002B	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-002A	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-002B	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-002M	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-002N	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-002P	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-005A	GENERATOR CTRL. UNIT	LUCAS
51539-005B	GENERATOR CTRL. UNIT	LUCAS
51539-005M	GENERATOR CTRL. UNIT	LUCAS
51539-005N	GENERATOR CTRL. UNIT	LUCAS
51539-005P	GENERATOR CTRL. UNIT	LUCAS
51539-005R	GENERATOR CTRL. UNIT	LUCAS
51539-006	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-006B	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-006C	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-006D	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-006E	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-006F	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-006H	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-006J	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-006M	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-007A	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-007B	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-008B	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-008C	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-008C MOD. A	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-008D	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-008D MOD. A	GENERATOR CTRL. UNIT	LUCAS AEROSPACE/LSI
51539-009B	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-009C	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-009D	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-009E	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-009G	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-009H	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-009J	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-009M	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI

51539-010A	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-013B	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-013C	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51539-014A	DC GENERATOR CONTROL UNIT	GOODRICH / TRW / LAPEC / LSI
51539-014A MOD A	DC GENERATOR CONTROL UNIT	GOODRICH / TRW / LAPEC / LSI
51539-014A MOD B	DC GENERATOR CONTROL UNIT	GOODRICH / TRW / LAPEC / LSI
51539-014A MOD C	DC GENERATOR CONTROL UNIT	GOODRICH / TRW / LAPEC / LSI
51549-001A	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51565-000	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51565-000R	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51565-001	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51565-001R	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51565-016	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51565-016R	GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51576-003	D.C. GENERATOR CTRL. UNIT	GOODRICH / TRW / LAPEC / LSI
51634-001	AC GENERATOR CONTROL UNIT	GOODRICH / TRW / LAPEC / LSI
51634-002	AC GENERATOR CONTROL UNIT	GOODRICH / TRW / LAPEC / LSI
56748-2	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
580-379	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
60B00010-24	A.C. GENERATOR	HONEYWELL
60B0010-17	A.C. GENERATOR	HONEYWELL
6115-250-5431	DC GENERATOR	NATIONAL STOCK NUMBER
6115-294-1596	DC GENERATOR	NATIONAL STOCK NUMBER
6115-538-8382	DC GENERATOR	NATIONAL STOCK NUMBER
6115-538-8739EN	A.C. GENERATOR	WESTINGHOUSE
6115-583-9055	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
6115-635-3637EN	A.C. GENERATOR	WESTINGHOUSE
6115-635-8613	DC GENERATOR	NATIONAL STOCK NUMBER
6115-678-6319	A.C. GENERATOR	GOODRICH / TRW / LAPEC / LSI
6115-899-7419EN	A.C. GENERATOR	WESTINGHOUSE
640055-501	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
6608201-9	DC GENERATOR	HONEYWELL / BENDIX
687-577	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
697201 REV-J	A.C. GENERATOR	LOCKHEED
697201-1	A.C. GENERATOR	LOCKHEED
720845	ELECTRIC GENERATOR	HAMILTON SUNDSTRAND
720845A	ELECTRIC GENERATOR	HAMILTON SUNDSTRAND
720845B	ELECTRIC GENERATOR	HAMILTON SUNDSTRAND
720845C	ELECTRIC GENERATOR	HAMILTON SUNDSTRAND
720845D	ELECTRIC GENERATOR	HAMILTON SUNDSTRAND
720845E	ELECTRIC GENERATOR	HAMILTON SUNDSTRAND
738156B	A.C. GENERATOR	HAMILTON SUNDSTRAND
738158A	A.C. GENERATOR	HAMILTON SUNDSTRAND
758926	A.C. GENERATOR	HAMILTON SUNDSTRAND
8060-3	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
8060-300	DC STARTER GENERATOR	THALES / AUXILEC
8060-300-1	DC STARTER GENERATOR	THALES / AUXILEC
8060-320	DC STARTER GENERATOR	THALES / AUXILEC
8060-320-1	DC STARTER GENERATOR	THALES / AUXILEC
8060-360	DC STARTER GENERATOR	THALES / AUXILEC

8260-120	DC STARTER GENERATOR	THALES / AUXILEC
8260-120	DC STARTER GENERATOR	AUXILEC
8260-121	DC STARTER GENERATOR	THALES / AUXILEC
8260-121	DC STARTER GENERATOR	AUXILEC
8260-123	DC STARTER GENERATOR	THALES / AUXILEC
8260-123	DC STARTER GENERATOR	AUXILEC
905D975-5	GENERATOR CTRL. UNIT	WESTINGHOUSE
905D975-6	GENERATOR CTRL. UNIT	WESTINGHOUSE
905D977-3	GENERATOR CTRL. UNIT	WESTINGHOUSE
905D977-4	GENERATOR CTRL. UNIT	WESTINGHOUSE
905D977-7	GENERATOR CTRL. UNIT	WESTINGHOUSE
914F569-4	GENERATOR CTRL. UNIT	WESTINGHOUSE
914F569-5	GENERATOR CTRL. UNIT	WESTINGHOUSE
914F569-6	GENERATOR CTRL. UNIT	WESTINGHOUSE
915F212-4	GENERATOR CTRL. UNIT	WESTINGHOUSE
915F212-6	GENERATOR CTRL. UNIT	WESTINGHOUSE
915F212-6	GENERATOR CTRL. UNIT	HAMILTON SUNDSTRAND
915F212-7	GENERATOR CTRL. UNIT	WESTINGHOUSE
915F212-8	GENERATOR CTRL. UNIT	WESTINGHOUSE
947F310-1	GENERATOR CTRL. UNIT	WESTINGHOUSE
947F945-1	GENERATOR CTRL. UNIT	WESTINGHOUSE
947F945-2	GENERATOR CTRL. UNIT	WESTINGHOUSE
947F945-2	GENERATOR CTRL. UNIT	SUNDSTRAND
947F945-3	GENERATOR CTRL. UNIT	WESTINGHOUSE
948F450-4	GENERATOR CTRL. UNIT	WESTINGHOUSE
948F458-1	GENERATOR CTRL. UNIT	WESTINGHOUSE
948F458-1	GENERATOR CTRL. UNIT	HAMILTON
948F458-2	GENERATOR CTRL. UNIT	WESTINGHOUSE
948F458-2	GENERATOR CTRL. UNIT	SUNDSTRAND DATA
948F458-4	GENERATOR CTRL. UNIT	WESTINGHOUSE
948F458-5	GENERATOR CTRL. UNIT	WESTINGHOUSE
9542719-3	ELECTRIC GENERATOR	LORAL AIRCRAFT SYSTEMS
976J012-3	A.C. GENERATOR	WESTINGHOUSE
976J012-4	A.C. GENERATOR	WESTINGHOUSE
976J063-2	A.C. GENERATOR	WESTINGHOUSE
976J118-10	A.C. GENERATOR	WESTINGHOUSE
976J118-11	A.C. GENERATOR	WESTINGHOUSE
976J118-6	A.C. GENERATOR	WESTINGHOUSE
976J118-8	A.C. GENERATOR	WESTINGHOUSE
976J119-11	A.C. GENERATOR	WESTINGHOUSE
976J119-12	A.C. GENERATOR	WESTINGHOUSE
976J119-6	A.C. GENERATOR	WESTINGHOUSE
976J119-8	ELECTRIC GENERATOR	WESTINGHOUSE
976J128-1	A.C. GENERATOR	WESTINGHOUSE
976J128-2	A.C. GENERATOR	WESTINGHOUSE
976J198-1	A.C. GENERATOR	WESTINGHOUSE
976J252-3	A.C. GENERATOR	WESTINGHOUSE
976J252-5	A.C. GENERATOR	WESTINGHOUSE
976J252-6	A.C. GENERATOR	WESTINGHOUSE
976J252-7	A.C. GENERATOR	WESTINGHOUSE

976J252-8	A.C. GENERATOR	WESTINGHOUSE
976J254-4	A.C. GENERATOR	WESTINGHOUSE
976J255-5	A.C. GENERATOR	WESTINGHOUSE
976J366-2	A.C. GENERATOR	WESTINGHOUSE
976J449-1	A.C. GENERATOR	WESTINGHOUSE
976J480-1	A.C. GENERATOR	WESTINGHOUSE
976J480-2	A.C. GENERATOR	WESTINGHOUSE
976J480-4	A.C. GENERATOR	WESTINGHOUSE
976J480-5	A.C. GENERATOR	WESTINGHOUSE
976J497-1	A.C. GENERATOR	WESTINGHOUSE
976J498-1	A.C. GENERATOR	WESTINGHOUSE
976J498-1	A.C. GENERATOR	WESTINGHOUSE
976J498-1R	A.C. GENERATOR	WESTINGHOUSE
976J498-2	A.C. GENERATOR	WESTINGHOUSE
976J582-1	A.C. GENERATOR	WESTINGHOUSE
976J597-1	A.C. GENERATOR	WESTINGHOUSE
976J598-1	A.C. GENERATOR	WESTINGHOUSE
976J862-10	GENERATOR CTRL. UNIT	WESTINGHOUSE
976J862-16	GENERATOR CTRL. UNIT	WESTINGHOUSE
976J862-17A	GENERATOR CTRL. UNIT	WESTINGHOUSE
976J882-16	GENERATOR CTRL. UNIT	HAMILTON SUNDSTRAND
976J889-3	A.C. GENERATOR	WESTINGHOUSE
976J889-5	A.C. GENERATOR	WESTINGHOUSE
976J889-6	A.C. GENERATOR	WESTINGHOUSE
976J898-2	A.C. GENERATOR	WESTINGHOUSE
976J937-1	A.C. GENERATOR	WESTINGHOUSE
977J003-11	GENERATOR CTRL. UNIT	WESTINGHOUSE
977J003-11A	GENERATOR CTRL. UNIT	WESTINGHOUSE
977J003-9	GENERATOR CTRL. UNIT	WESTINGHOUSE
977J008-2	A.C. GENERATOR	WESTINGHOUSE
977J024-3	A.C. GENERATOR	WESTINGHOUSE
977J024-4	A.C. GENERATOR	WESTINGHOUSE
977J150-1	A.C. GENERATOR	WESTINGHOUSE
977J150-2	A.C. GENERATOR	WESTINGHOUSE
977J150-3	A.C. GENERATOR	WESTINGHOUSE
977J150-4	A.C. GENERATOR	WESTINGHOUSE
977J150-5	A.C. GENERATOR	WESTINGHOUSE
977J324-1	A.C. GENERATOR	WESTINGHOUSE
977J330-2	A.C. GENERATOR	WESTINGHOUSE
977J330-3	A.C. GENERATOR	WESTINGHOUSE
9910292-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
9910293-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
9912038-2	DC STARTER GENERATOR	CESSNA AIRCRAFT CO
9912038-3	DC STARTER GENERATOR	CESSNA AIRCRAFT CO
9912038-7	DC STARTER GENERATOR	CESSNA AIRCRAFT CO
9912125-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
9912125-3	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
A40A1750	GENERATOR CTRL. UNIT	WESTINGHOUSE
A40A1750-2	GENERATOR CTRL. UNIT	WESTINGHOUSE
A50J206	A.C. GENERATOR	WESTINGHOUSE

A50J207-2	A.C. GENERATOR	WESTINGHOUSE
A50J207-4	A.C. GENERATOR	WESTINGHOUSE
A50J252	A.C. GENERATOR	WESTINGHOUSE
AE2132MK3	A.C. GENERATOR	LUCAS AEROSPACE
AE2132MK4	A.C. GENERATOR	LUCAS AEROSPACE
AE2132MK6	A.C. GENERATOR	LUCAS AEROSPACE
AE2152MK3	A.C. GENERATOR	LUCAS AEROSPACE
AE2152MK4	A.C. GENERATOR	LUCAS AEROSPACE
AE7065MK1	GENERATOR CTRL. UNIT	LUCAS AEROSPACE
AE7065MK2	GENERATOR CTRL. UNIT	LUCAS AEROSPACE
AE7083MK2	GENERATOR CTRL. UNIT	LUCAS AEROSPACE, LTD
AE7083MK2.	GENERATOR CTRL. UNIT	LUCAS UK
BC0910-1	DC STARTER GENERATOR	AIRCRAFT MFG. P/N
C5116-03	STARTER MOTOR	LUCAS AEROSPACE
C5116-04	STARTER MOTOR	LUCAS AEROSPACE
C5116-05	STARTER MOTOR	LUCAS AEROSPACE
C5116-06	STARTER MOTOR	LUCAS AEROSPACE
C5116-07	STARTER MOTOR	LUCAS AEROSPACE
C5116-08	STARTER MOTOR	LUCAS AEROSPACE
C5116-09	STARTER MOTOR	LUCAS AEROSPACE
C5116-10	STARTER MOTOR	LUCAS AEROSPACE
C5116-11	STARTER MOTOR	LUCAS AEROSPACE
CB00901C	GENERATOR CTRL. UNIT	LUCAS AEROSPACE
CB02601	GENERATOR CTRL. UNIT	LUCAS AEROSPACE LTD
CR2795B105A1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR2795B105A1.	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR2795B105A1A	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR2795M103F1A1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR2795M103G1A	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR7930NA123G1	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR7930NA123G1A	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR7930NA123G1AX	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR7930NA123G3A	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR7930NA123G3B	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR7930NA123G4	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR7930NA123G4A	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CR7930NA123G5	GENERATOR CTRL. UNIT	GENERAL ELECTRIC
CSD791-3	GENERATOR CTRL. UNIT	LELAND
CSV1152-11AB	GENERATOR CTRL. UNIT	AMF ELECTROSYSTEMS
CSV1152-12AB	GENERATOR CTRL. UNIT	AMF ELECTROSYSTEMS
CSV1152-1AB	GENERATOR CTRL. UNIT	AMF ELECTROSYSTEMS
CSV1152-2AB	GENERATOR CTRL. UNIT	AMF ELECTROSYSTEMS
CSV1185-1	GENERATOR CTRL. UNIT	LELAND
CSV1829-1	D.C. GENERATOR CTRL. UNIT	LELAND
CSV1829-3	D.C. GENERATOR CTRL. UNIT	LELAND
CSV1829-7	D.C. GENERATOR CTRL. UNIT	LELAND
CSV2215-1	GENERATOR CTRL. UNIT	LELAND
CSV2215-3	GENERATOR CTRL. UNIT	LELAND
CSV2215-4	GENERATOR CTRL. UNIT	LELAND
G29-7A	DC GENERATOR	LUCAS AEROSPACE/LSI



