



KEARSLEY AIRWAYS LIMITED



ROMEERA HOUSE . STANSTED AIRPORT . STANSTED . ESSEX CM24 1QL . UNITED KINGDOM

Telephone: +44(0)1279 871000 Fax: +44(0)1279 871187 Email: info@kalair.co.uk Web: www.kalair.co.uk

Component Maintenance Capabilities List KAL/QC/5 Issue:23 Dated:01/10/14

Our In-House Component Maintenance Capability List can change periodically. Please contact us today for an individual quotation.

PART NUMBER	ALTERNATE PART NUMBER	DESCRIPTION	MANUFACTURER	WORKSCOPE	AIRCRAFT TYPE	RELEASE APPROVAL
115.161		Water Quantity Indicator	ROGERSON	OH/REP/TEST	B757	PLEASE CONTACT US
115.217		Water Quantity Indicator	ROGERSON	OH/REP/TEST	B747;B757	PLEASE CONTACT US
589		Pilot & Co-Pilots Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
649		Aircrew Swivel Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
665		Pilot & Co-Pilots Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1000	695855-5	Oven Assembly	SPERRY FRANK INC.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1003		De-Icing Cyclic Timer	DAVALL	OH/REP/TEST	HS748	PLEASE CONTACT US
1032	AN6279-12CD	Hydraulic Pressure Relief Valve	DROITCOUR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1042		Voltage Regulator	BENDIX	OH/REP/TEST	P51 MUSTANG	PLEASE CONTACT US
1120		Rudder Boost Cylinder Assembly	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1290		Motor Assembly	AUXILEC	OH/REP/TEST	F100	PLEASE CONTACT US
1297		DC Electric Motor	AUXILEC	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
1652	10-60551-3	Pressure Relief Valve	PNEUDRAULICS	OH/REP/TEST	B727;B737;B757	PLEASE CONTACT US
1841		Hydraulic Relief Valve	PNEUDRAULICS	OH/REP/TEST	B757	PLEASE CONTACT US
1885		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
4100	697273-1	Instrument Switching Unit	SEABOARD ELECTRONIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
4127	EH579	Emergency Accumulator	DOWTY	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
4538		Priority Relief Cartridge Valve	PNEUDRAULICS	OH/REP/TEST	B707;B737	PLEASE CONTACT US
5059		Hydraulic Shuttle Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
5200		Oven	NORDSKOG	OH/REP/TEST	DC8	PLEASE CONTACT US
5242		Nose Wheel Assembly	ABSC	OH/REP/TEST	BEECH;CESS;LEARJET 40/45	PLEASE CONTACT US
5316		Double Oven	NORDSKOG	OH/REP/TEST	B707;B737	PLEASE CONTACT US
6136	EH586	Flap And Aileron Jack	DOWTY	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
6137		Nose Undercarriage Steering Jack	DOWTY	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
6138	EH589	Flap Control Jack	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
6172		Flow Regulator Valve	PNEUDRAULICS	OH/REP/TEST	B727;B737	PLEASE CONTACT US
6204		Solenoid Operated Two Way Hyd Valve	TACTAIR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
6212		Hydraulic Quantity Fuse	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6252	10-62045-1	Hydraulic Fuse	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6271		Hydraulic Fuse	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6301	695974-1	Shut Off Valve	J.C.CARTER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
6502		Altitude Switch	FLIGHTLINE AIRCRAFT	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
6535		Boost Pump Bypass Valve	J.C.CARTER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
6563		Fuel Shut Off Valve	J.C.CARTER	OH/REP/TEST	B727;B737	PLEASE CONTACT US

6568		Fuel Shut Off Valve	J.C.CARTER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
7046	695225	Actuator Assembly	PNEUDRAULICS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
7974		Non Return Valve	ELECTRO-HYDRAULICS	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
8118	697195-1	Aileron Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8256		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	DC10	PLEASE CONTACT US
8347	695579-45	Gear Box Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8353	695579-71	MLG Ballscrew Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8408		Yaw Trim Actuator	SAGEM	OH/REP/TEST	DO328	PLEASE CONTACT US
8409		Pitch Trim Actuator	SAGEM	OH/REP/TEST	DO328	PLEASE CONTACT US
8430		MLG Ballscrew Assembly	CEF INDUSTRIES (CALCO)	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
8445		Wing Flap Actuator Assembly (Inboard)	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8446		Wing Flap Actuator Assembly (Outboard)	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8521		Gearbox Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8526		APU Door Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8544		Gear Box Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8545		Wing Flap Ballscrew Assembly (Inboard)	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8546		Wing Flap Ballscrew Assembly (Outboard)	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8656		Oil Cooler Door Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8681		Elevator Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9269		Relay	LEACH	OH/REP/TEST	F27;MD80	PLEASE CONTACT US
10280		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
10640		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
10850		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
10870		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
11060		Dual Power Brake Valve	NUCLEAR VALVE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
11170		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
11460		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
11606		Shuttle Valve	KENYON	OH/REP/TEST	TBD	PLEASE CONTACT US
11660		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
11670		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
13210	695547-1	Four-Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
13930	695495-3	Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14080		Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
16550		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
19090		Main Landing Gear	MESSIER-DOWTY	OH/REP/TEST	CL600;CL604	PLEASE CONTACT US
20045		Nose Landing Gear Drag Brace Assembly	MESSIER-DOWTY	OH/REP/TEST	G53	PLEASE CONTACT US
20348	AN6277-4	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
20349	AN6277-6	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
20350	AN6277-8	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
20355	AN6209-4	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
22887		Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
22888		Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
22889		Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23410		Dual Brake Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23600		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US

23612		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23686		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23924		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
024116		Vaneaxial Fan	EG&G ROTRON	OH/REP/TEST	B707;B737;B757	PLEASE CONTACT US
25060		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25400		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25412		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25800		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
27100		Suction Boost Pump	ABLE CORP	OH/REP/TEST	C130;L100	PLEASE CONTACT US
27100		Suction Boost Pump	ABLE CORP	OH/REP/TEST	C130;L100	PLEASE CONTACT US
27531	695111	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
30230		Accumulator-Hydraulic Assembly	EFS AEROSPACE	OH/REP/TEST	B747;B757;B767;B777	PLEASE CONTACT US
30678		Torque Actuator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
30850		Hydraulic Accumulator Assembly	TRIUMPH ACT SYSTEMS	OH/REP/TEST	B737	PLEASE CONTACT US
32706		DC Aircraft Motor	AIRESEARCH	REP/TEST	C130;L100	PLEASE CONTACT US
39858		Linear Actuator	GARRETT	OH/REP/TEST	F27	PLEASE CONTACT US
40088	695683-1	Differential Pressure Switch	HYDRA ELECTRIC	TEST ONLY	C130;L100	PLEASE CONTACT US
40122	695683-3	Differential Pressure Switch	HYDRA ELECTRIC	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
42582		Program Position Indicator	AIRESEARCH	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
43325		Anti-Collision Lamp	GRIMES	OH/REP/TEST	VC10	PLEASE CONTACT US
44910		Emergency Exit Light Assembly	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
46303		AC Current Motor	ALLIED SIGNAL	OH/REP/TEST	B707	PLEASE CONTACT US
47560	695526-3	Control Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
47610	695547-1	Emergency Flap Brake Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
47680	695495-3	Directional Control Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
49740		Ramp Control Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
49740		Ramp Control Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
50150		Hydraulic Selector Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
50160		Plate Warmer	NORDSKOG	OH/REP/TEST	DC10	PLEASE CONTACT US
50222	MS28720-8	Hydraulic Filter	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
50652		Pressure Transmitter	NEGRETTI	OH/REP/TEST	BAE146	PLEASE CONTACT US
50659		Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
52737		Landing Gear Sequence Valve	CRANE HYDRO-AIRE	OH/REP/TEST	B707	PLEASE CONTACT US
52760	695684-1	Auxiliary Manual Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
53230	695812-2	Shut Off Valve	STERER	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
53814		Shuttle Valve	CRANE HYDRO-AIRE	OH/REP/TEST	B707	PLEASE CONTACT US
55035		Hydraulic Pump	PARKER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
55076	10-60470-3	Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727	PLEASE CONTACT US
55097	10-60470-4	Hydraulic Pump	PARKER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
55098		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
55107	10-60470-6	Hydraulic Pump	PARKER	OH/REP/TEST	B707;B727	PLEASE CONTACT US
57186	10-60556-6	Pump Motor Package	PARKER	TEST ONLY	B727;B737;B747	PLEASE CONTACT US
60051		Fuel Shut-Off Valve	J.C.CARTER	OH/REP/TEST	B737	PLEASE CONTACT US
60127		Fuel Shut Off Valve	J.C.CARTER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
60128		Fuel Shutoff Valve	J.C.CARTER	OH/REP/TEST	B737	PLEASE CONTACT US

60177		Override Linkage	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
60187		Cold Air Valve	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
60188		Cold Air Valve	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
60199		Override Linkage	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
60710		Override Linkage	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
60720		Override Linkage	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
61073		Double Compartment Oven	RUMBOLD	OH/REP/TEST	B747;B757;B767;B777	PLEASE CONTACT US
61162		Fuel Shut-Off Valve	J.C.CARTER	OH/REP/TEST	B737	PLEASE CONTACT US
61183		Fuel Shut-Off Valve	J.C.CARTER	OH/REP/TEST	B727	PLEASE CONTACT US
61185		Fuel Shut-Off Valve	J.C.CARTER	OH/REP/TEST	B737	PLEASE CONTACT US
62216		Water Boiler Assembly	RUMBOLD	OH/REP/TEST	BAE146	PLEASE CONTACT US
62702		Position Indicating Switch	HAYDON SWITCH	OH/REP/TEST	B737	PLEASE CONTACT US
62716		Position Indicating Switch	HAYDON SWITCH	OH/REP/TEST	B737	PLEASE CONTACT US
62721		Position Indicating Switch	HAYDON SWITCH	OH/REP/TEST	B737	PLEASE CONTACT US
62726		Position Indicating Switch	HAYDON SWITCH	OH/REP/TEST	B737	PLEASE CONTACT US
62740		Position Indicating Switch	HAYDON SWITCH	OH/REP/TEST	B747	PLEASE CONTACT US
62742		Position Indicating Switch	HAYDON SWITCH	OH/REP/TEST	B747	PLEASE CONTACT US
62743		Position Indicating Switch	HAYDON SWITCH	OH/REP/TEST	B747	PLEASE CONTACT US
62744		Position Indicating Switch	HAYDON SWITCH	OH/REP/TEST	B747	PLEASE CONTACT US
64752		Beverage Maker	L.A.RUMBOLD	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
64759		Coffee Maker	RUMBOLD	OH/REP/TEST	BAE146	PLEASE CONTACT US
64763		Coffee Maker	RUMBOLD	OH/REP/TEST	BAE146	PLEASE CONTACT US
65001	10-60470-7	Hydraulic Pump	PARKER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65053		Hydraulic Pump	PARKER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65075		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
67063		Single Oven	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
67241		Single Compartment Oven	RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
67251		Single Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	B737;A300;A320	PLEASE CONTACT US
70262	697219-1	Restrictor Valve	ADEL-CRANE HYD-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
71234		Hand Pump Assembly	CRANE HYDRO-AIRE	OH/REP/TEST	B727;B737;B747;B757;B767	PLEASE CONTACT US
72909		Hyd Reservoir Press Regulator	CRANE HYDRO-AIRE	OH/REP/TEST	B737	PLEASE CONTACT US
78500		Master Valve Assembly	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
83832		Cooling Turbine Heat Exchanger	AIRESEARCH	TEST ONLY	C130;L100	PLEASE CONTACT US
85027		Cooling Turbine Heat Exchanger	AIRESEARCH	TEST ONLY	C130;L100	PLEASE CONTACT US
86550		Torque Link Steering Assembly	BENDIX	OH/REP/TEST	GS1	PLEASE CONTACT US
95023		Oil Pressure Switch	HYDRA ELECTRIC	TEST ONLY	C130;L100	PLEASE CONTACT US
95024	632184-3	Oil Pressure Switch	HYDRA ELECTRIC	TEST ONLY	C130;ELECTRA	PLEASE CONTACT US
95024	632184-3	Oil Pressure Switch	HYDRA ELECTRIC	TEST ONLY	C130;L100	PLEASE CONTACT US
100507		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
100914		Motor Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
102679		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103347		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103432		Shut Off Valve	STRATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
104083		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
104087		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US

104156		Shut Off Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
104922		Butterfly Shutoff Valve	AIRESEARCH	OH/REP/TEST	B707;B720	PLEASE CONTACT US
106616		2 1/2 Inch Shutoff Airflow Regulator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
107255		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
108605	695318	Motor Actuated Butterfly Valve Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
110011	1111	Tandem Aileron Cylinder	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
111102	1111-2	Tandem Aileron Cylinder	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
111103	1111-3	Tandem Aileron Cylinder	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
111105	1111-5	Tandem Aileron Cylinder	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
113538		Motor Actuator Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
117045		Motor Actuated Shutoff Valve	WHITTAKER	OH/REP/TEST	TBD	PLEASE CONTACT US
121010	695748-15	Air Control Valve	ROCKER IND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
121535		Butterfly Shutoff Valve	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
124645		Butterfly Shutoff Valve	WHITTAKER	OH/REP/TEST	B707	PLEASE CONTACT US
129485		Butterfly Shutoff Valve	WHITTAKER	OH/REP/TEST	B707	PLEASE CONTACT US
130345		Valve Shut Off	WHITTAKER CONTROLS	OH/REP/TEST	F27	PLEASE CONTACT US
130585		Shutoff Valve	WHITTAKER CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
130595		Slide Shutoff Valve	WHITTAKER CONTROLS	OH/REP/TEST	B707;B737	PLEASE CONTACT US
132555		Shutoff Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
137275		Shutoff Valve	WHITTAKER	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
138105		Shutoff Valve	WHITTAKER	OH/REP/TEST	B707	PLEASE CONTACT US
140925		Shutoff Valve	WHITTAKER	OH/REP/TEST	B707;B727	PLEASE CONTACT US
147465		Shut Off Valve	WHITTAKER	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
148105		Selector Valve	WHITTAKER	OH/REP/TEST	B737	PLEASE CONTACT US
150055		Vapour Proof Actuator	WHITTAKER	OH/REP/TEST	B707	PLEASE CONTACT US
150095		Vapour Proof Actuator	WHITTAKER	OH/REP/TEST	B707	PLEASE CONTACT US
150201		Actuator Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
151395		Vapour Proof Actuator	WHITTAKER	OH/REP/TEST	B707	PLEASE CONTACT US
152292		Motor Assembly	WHITTAKER	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
152297		Actuator Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
152550		Actuator	WHITTAKER	OH/REP/TEST	F27	PLEASE CONTACT US
157800		Temperature Indicator	WESTON	OH/REP/TEST	C130;L100;L382;ELEC	PLEASE CONTACT US
157801		Temperature Indicator	WESTON	OH/REP/TEST	C130;L100;L382;ELEC	PLEASE CONTACT US
166726	695780-1	AC Loadmeter Indicator	WESTON	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
188440		Screwjack	TRIUMPH CONTROLS	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
203430	695294-13	Aircraft Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
225885		Butterfly Shut Off Valve	WHITTAKER	OH/REP/TEST	B727	PLEASE CONTACT US
229165		Butterfly Shut Off Valve	WHITTAKER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
233145		Shut Off Valve	WHITTAKER	OH/REP/TEST	B737;B757;B767	PLEASE CONTACT US
311540		Hand Pump	GLADDEN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
314035		Three Way Valve	ADEL	OH/REP/TEST	B707	PLEASE CONTACT US
314160		Hydraulic Reservoir Pressure Regulator	CRANE HYDRO-AIRE	OH/REP/TEST	B707;B727;B737;DC10	PLEASE CONTACT US
316525		Hydraulic Hand Pump	CRANE HYDRO-AIRE	OH/REP/TEST	B707;B727;B737;B757;DC9;MD80	PLEASE CONTACT US
316565		Hydraulic Relief Valve	CRANE	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
324425		Anti-Ice Valve (Butterfly Shut-Off)	WHITTAKER	OH/REP/TEST	A320	PLEASE CONTACT US

340545	S270T002-3	Motor Actuated Rotary Selector Valve	WHITTAKER	TEST ONLY	B757;B767	PLEASE CONTACT US
340565	S271N501-2	Motor Actuated Rotary Shutoff Valve	WHITTAKER	OH/REP/TEST	B737;B757	PLEASE CONTACT US
341448		MLG Torque Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
378004	MPEV3-032-4	Electric Driven Hydraulic Motorpump	SPERRY VICKERS	OH/REP/TEST	TBD	PLEASE CONTACT US
400192		A/C Mechanical Clock	NEWAL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
400201		A/C Mechanical Clock	WALTHAM PRECISION	OH/REP/TEST	C130;L100	PLEASE CONTACT US
400202	A-13A-2	A/C Mechanical Clock	WALTHAM PRECISION	OH/REP/TEST	C130;L100	PLEASE CONTACT US
411600	697218-1	Oil Tank Relief Valve	ACCESSORY PRODUCTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
421495		Butterfly Shut Off Valve	WHITTAKER	OH/REP/TEST	B727;B737;DC9;MD80	PLEASE CONTACT US
7-3141		MLG Door Actuator	SARGENT	OH/REP/TEST	B737	PLEASE CONTACT US
511000		Shut Off Valve	HYDRAULIC RESEARCH	OH/REP/TEST	B727;B737	PLEASE CONTACT US
515407		AC Motor	AIRESEARCH	OH/REP/TEST	B707	PLEASE CONTACT US
516543		Battery Charger	GULTON IND.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
516574		Emergency Power Pack	GULTON IND.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
517610		Direct Current Motor	ALLIED SIGNAL	OH/REP/TEST	BAE146	PLEASE CONTACT US
522805		Brake Pressure Indicator	AMETEK	OH/REP/TEST	F100	PLEASE CONTACT US
523156		Brake Pressure Indicator	AMETEK	OH/REP/TEST	F100	PLEASE CONTACT US
525804		Rotary Actuator	AIRESEARCH	OH/REP/TEST	B707	PLEASE CONTACT US
552430		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
569408		Hydraulic Filter	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695037		Cylinder Ramp Uplock	DRESCHER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695040		NLG Steering Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695043		NLG Uplock Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695111	27531	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695197	50150-20	Hydraulic Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695292	EA573A-1	Flap Position Transmitter	LIQUIDOMETER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695324	C19A513	Centrifugal Fan	GLOBE INDUSTRIES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695345	411-31-18	Vacuum Actuated Switch	MELETRON	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
695434	1111-5	Tandem Aileron Cylinder	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
731700		Dual Level Control Valve	ACCESSORY PRODUCTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
738440		Charge Pump	SUNDSTRAND	OH/REP/TEST	F100	PLEASE CONTACT US
741495		Scavenge Pump	SUNDSTRAND	OH/REP/TEST	F100	PLEASE CONTACT US
887477	MPEV3-056-7A	AC Driven Motorpump Assembly	EATON	OH/REP/TEST	TBD	PLEASE CONTACT US
890411		Solenoid Valve Assembly	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890412		Solenoid Valve Assembly	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
891041		Fire Detector Control Unit	WALTER KIDDE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1009350		Rotary Actuator Assembly	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1105123		Actuator Oil Cooler Flap	SMITH & SMITH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1501420		Shut Off And Regulator Valve	RANDALL	OH/REP/TEST	F27	PLEASE CONTACT US
1523009		Piston Assembly	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1539414		High Pressure Filter	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
6120-1-2		Shut Off Valve	BOBRICK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
6130-1-2		Shut Off Valve	BOBRICK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2570892		Nose Landing Gear Assembly	BENDIX	OH/REP/TEST	GS1	PLEASE CONTACT US
2570894		Main Landing Gear Assembly	BENDIX	OH/REP/TEST	GS1	PLEASE CONTACT US

2640628		Swing Check Valve	PARKER	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2670112		Gear Door Modular Assembly	PARKER	OH/REP/TEST	B747;B757;TRIS	PLEASE CONTACT US
2690194		Accumulator	PARKER	OH/REP/TEST	F28	PLEASE CONTACT US
4000466		Rotor Brake Assembly	ABSC	OH/REP/TEST	BELL214	PLEASE CONTACT US
4000523		Rotor Brake Assembly	ABSC	OH/REP/TEST	BELL214	PLEASE CONTACT US
5000400		Main Wheel Assembly	ABSC	OH/REP/TEST	FALCON 10	PLEASE CONTACT US
5000757		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000919		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5002460	101-8002-5	Main Wheel Assembly	ABSC	OH/REP/TEST	BEECH B200	PLEASE CONTACT US
5002744		Nose Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5003064		Main Wheel Assembly	ABSC	OH/REP/TEST	CESS441	PLEASE CONTACT US
5003065		Brake Assembly	ABSC	OH/REP/TEST	CESS406, CESS441	PLEASE CONTACT US
5003086		Brake Assembly	ABSC	OH/REP/TEST	F27	PLEASE CONTACT US
5003096		Brake Assembly	ABSC	OH/REP/TEST	LEARJET	PLEASE CONTACT US
5003174		Fuel Booster Pump.	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
5003410		Brake Assembly	ABSC	OH/REP/TEST	CORV	PLEASE CONTACT US
5003426		Brake Assembly	ABSC	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
5003588		Main Wheel Assembly	ABSC	OH/REP/TEST	F27	PLEASE CONTACT US
5003783		Main Wheel Assembly	ABSC	OH/REP/TEST	CESS	PLEASE CONTACT US
5004069		Main Wheel Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
5004070		Brake Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
5004236		Brake Assembly	ABSC	OH/REP/TEST	C212	PLEASE CONTACT US
5004410		Main Wheel Assembly	ABSC	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
5004899		Main Wheel Assembly	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5004902		Brake Unit Assy	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5005494		Brake Assembly	ABSC	OH/REP/TEST	CESS	PLEASE CONTACT US
5005495		Main Wheel Assembly	ABSC	OH/REP/TEST	CESS	PLEASE CONTACT US
5006227		Nose Wheel Assembly	ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5006450		Nose Wheel Assembly	ABSC	OH/REP/TEST	CANA(CL600)	PLEASE CONTACT US
5006484		Brake Assembly	ABSC	OH/REP/TEST	C212	PLEASE CONTACT US
5006528		Nose Wheel Assembly	ABSC	OH/REP/TEST	DO228	PLEASE CONTACT US
5006566		Main Wheel Assembly	ABSC	OH/REP/TEST	GS100;GS150	PLEASE CONTACT US
5006618		Main Wheel Assembly	ABSC	OH/REP/TEST	DO228	PLEASE CONTACT US
5007045		Main Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5007218		Main Wheel Assembly	ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5007553		Nose Wheel Assembly	ABSC	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
5007555		Brake Assembly	ABSC	OH/REP/TEST	SIK S-76B	PLEASE CONTACT US
5007898		Brake Assembly	ABSC	OH/REP/TEST	MD83;MD88	PLEASE CONTACT US
5007995		Main Wheel Assembly	ABSC	OH/REP/TEST	F50	PLEASE CONTACT US
5007998		Nose Wheel Assembly	ABSC	OH/REP/TEST	F50	PLEASE CONTACT US
5008133		Nose Wheel Assembly	ABSC	OH/REP/TEST	F70	PLEASE CONTACT US
5008264		Shuttle Valve Assy	ABSC	OH/REP/TEST	F28;F50;F60;F70;F100	PLEASE CONTACT US
5008309		Main Wheel Assembly	ABSC	OH/REP/TEST	DO228-202	PLEASE CONTACT US
5008367		Shuttle Valve	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008447		Main Wheel Assembly	ABSC	OH/REP/TEST	GS4	PLEASE CONTACT US

5008540		Main Wheel Assembly	ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5008541		Brake Assembly	MEGGITT/ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5009027		Brake Assembly	ABSC	OH/REP/TEST	CL600	PLEASE CONTACT US
5009029		Main Wheel Assembly	ABSC	OH/REP/TEST	CANA	PLEASE CONTACT US
5009238		Main Wheel Assembly	ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5010488		Main Wheel Assembly	ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5010571		Main Wheel Assembly	ABSC	OH/REP/TEST	CRJ-200;CL600	PLEASE CONTACT US
5010598	604-85005-1	Nose Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL604;HAWKER 800	PLEASE CONTACT US
5011740	6600330-20	Main Wheel Assembly	ABSC	OH/REP/TEST	LEAR 60	PLEASE CONTACT US
5011809		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
5012333		Brake Assembly	ABSC	OH/REP/TEST	CL604 CHALLENGER	PLEASE CONTACT US
5012373	604-85123-1	Main Wheel Assembly	ABSC	OH/REP/TEST	CL604;CL605;HAWKER 800XP	PLEASE CONTACT US
5012609		Brake Assembly	MEGGITT/ABSC	OH/REP/TEST	ATR42	PLEASE CONTACT US
5013640		Nose Wheel Assembly	ABSC	OH/REP/TEST	CANA(CRJ-700)	PLEASE CONTACT US
5013641		Main Wheel Assembly	ABSC	OH/REP/TEST	CANA(CRJ-700)	PLEASE CONTACT US
5014197		Main Wheel Assembly	MEGGITT/ABS	OH/REP/TEST	FALC900	PLEASE CONTACT US
6781568	35-055	Solenoid Operated Shutoff Valve	CRANE HYDRO-AIRE	OH/REP/TEST	C130;L100;L382;ELEC	PLEASE CONTACT US
6829274	697244-1	Torquemeter Indicator	TEXAS INSTRUMENTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9300141		Spherical Plug Valve	FLIGHT REFUELLING	OH/REP/TEST	F100	PLEASE CONTACT US
9300216		Motorised Valve	FLIGHT REFUELLING	OH/REP/TEST	F100	PLEASE CONTACT US
9402006		Motor Unit	FLIGHT REFUELLING	OH/REP/TEST	A300	PLEASE CONTACT US
9507445		Vent Float Valve	FLIGHT REFUELLING	OH/REP/TEST	F100	PLEASE CONTACT US
9531924		Main Wheel Assembly	ABSC	OH/REP/TEST	S-61	PLEASE CONTACT US
9531925		Tail Wheel Assembly	ABSC	OH/REP/TEST	S-61	PLEASE CONTACT US
9531966		Nose Wheel Assembly	LORAL	OH/REP/TEST	GS1	PLEASE CONTACT US
9541493		Nose Wheel Assembly	ABSC	OH/REP/TEST	F27	PLEASE CONTACT US
9541584		Brake Assembly	ABSC	OH/REP/TEST	F27	PLEASE CONTACT US
9541587		Main Wheel Assembly	ABSC	OH/REP/TEST	F27	PLEASE CONTACT US
9541617		Nose Wheel Assembly	ABSC	OH/REP/TEST	B707	PLEASE CONTACT US
9542306		Main Wheel Assembly	LORAL	OH/REP/TEST	GS1	PLEASE CONTACT US
9542327		Nose Wheel Assembly	ABSC	OH/REP/TEST	B707	PLEASE CONTACT US
9543195		Wheel Drive Unit	ABSC	OH/REP/TEST	GS11;GS111	PLEASE CONTACT US
9543367	1159SCL205-1	Nose Wheel Assembly	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
9543426		Nose Wheel Assembly	ABSC	OH/REP/TEST	FALCON 20/50	PLEASE CONTACT US
9543476		Nose Wheel Assembly	LORAL	OH/REP/TEST	F28	PLEASE CONTACT US
9543705		Nose Wheel Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
9543991		Main Wheel Assembly	ABSC	OH/REP/TEST	LEAR 35	PLEASE CONTACT US
9544207		Nose Wheel Assembly	MEGGITT/ABSC	OH/REP/TEST	BEECH;CESS;LEAR	PLEASE CONTACT US
9544455		Main Wheel Assembly	ABSC	OH/REP/TEST	AERO COMM 685	PLEASE CONTACT US
9550064		Main Wheel Assembly	ABSC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9550266	1159SC-L204-1	Brake Assembly	ABSC	OH/REP/TEST	GS11	PLEASE CONTACT US
9550267		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC9;MD83;MD87;MD88;MD90	PLEASE CONTACT US
9550328		Nose Wheel Assembly	LORAL	OH/REP/TEST	DC8	PLEASE CONTACT US
9550377		Brake Assembly	ABSC	OH/REP/TEST	DHC-6	PLEASE CONTACT US
9550616		Main Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US

9550616		Main Wheel Assembly	ABSC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9550661	1159SC-L204-3	Brake Assembly	ABSC	OH/REP/TEST	GS11	PLEASE CONTACT US
9560569		Brake Assembly	ABSC	OH/REP/TEST	B707	PLEASE CONTACT US
9560685		Multiple Disk Brake	ABSC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9560685		Brake Unit	ABSC	OH/REP/TEST	L100; L382	PLEASE CONTACT US
9561061	1159SCL203-9	Main Wheel Assembly	ABSC	OH/REP/TEST	GS2	PLEASE CONTACT US
9561062	1159SC-L204-5	Brake Assembly	ABSC	OH/REP/TEST	GS11	PLEASE CONTACT US
9811705		Automatic Purge Valve	FLIGHT REFUELLING	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
1650E4		MLG Horizontal Shaft Assembly	WESTERN GEAR CORP	OH/REP/TEST	C130;L100	PLEASE CONTACT US
26130010	695805-1	Shut Off Valve	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
26130011		Shut Off Valve	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
27231317	697639-11	Flight Station Temperature Controller	SUNDSTRAND	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
27231318	697639-21	Cargo Compart Temperature Controller	SUNDSTRAND	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
27241301		Hot Air Check Valve	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
90000581		Nose Wheel Assembly	ABSC	OH/REP/TEST	EMB170;EMB190	PLEASE CONTACT US
90001935		Nose Wheel Assembly	ABSC	OH/REP/TEST	G450	PLEASE CONTACT US
90001936		Main Wheel Assembly	ABSC	OH/REP/TEST	G450	PLEASE CONTACT US
90002021	2610485-1	Nose Wheel Assembly	ABSC	OH/REP/TEST	DO328	PLEASE CONTACT US
90002024	2610701-2	Main Wheel Assembly	ABSC	OH/REP/TEST	DO328	PLEASE CONTACT US
90002317		Main Wheel Assembly	MEGGITT	OH/REP/TEST	EMB-190	PLEASE CONTACT US
90002746		Nose Wheel Assembly	MEGGITT	OH/REP/TEST	FALCON 7X	PLEASE CONTACT US
90005024		Main Wheel Assembly	MEGGITT	OH/REP/TEST	EMB-500	PLEASE CONTACT US
100120001		Steering Selector Valve	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
100318001		Steering Selector Control Box	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
100318200		Steering Selector	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
100574001		Steering Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748;AND	PLEASE CONTACT US
100574002		Steering Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748;AND	PLEASE CONTACT US
100574004		Steering Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748;AND	PLEASE CONTACT US
100574005		Steering Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748;AND	PLEASE CONTACT US
100574006		Steering Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748;AND	PLEASE CONTACT US
100927001		Selector Valve	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
102185004		Pressure Indicator Switch	DOWTY AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
102185005		Pressure Indicator Switch	DOWTY AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
102298002		Swivel Coupling Unit	DOWTY AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
102298003		Swivel Coupling Unit	DOWTY AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
102348007	H5063	Double Relief Valve	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
102526003		Double Pressure Relief Valve	DOWTY	OH/REP/TEST	F28;F100	PLEASE CONTACT US
102697001		Valve 3 Way Selector	DOWTY AEROSPACE	OH/REP/TEST	SD330	PLEASE CONTACT US
103005009		Main Undercarriage Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
103005011		Main Undercarriage Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
103005012		Main Undercarriage Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
103011010		Nose Undercarriage Jack	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
103011011		Nose Undercarriage Jack	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
103011012		Nose Undercarriage Jack	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
103506001		Ram Air Turbine Jack	DOWTY	OH/REP/TEST	HARR;HAWK	PLEASE CONTACT US

103583001		Nose Undercarriage Jack	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
103583002		Nose Undercarriage Jack	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
103612001		Main Undercarriage Jack	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
103612002		Main Undercarriage Jack	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
103641001		Steering Valve	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
103641002		Steering Valve	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
103641003		Steering Valve	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
103641004		Steering Valve	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
104214001		Selector Valve	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
104216001		Selector Valve	DOWTY	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
104217001		Selector Valve	DOWTY	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
104220001		Accumulator	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
104224001		Accumulator	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
104224002		Accumulator	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
104228001		Accumulator	DOWTY AEROSPACE	OH/REP/TEST	SD330	PLEASE CONTACT US
104245002		Reservoir	DOWTY AEROSPACE	OH/REP/TEST	SD330;JETST	PLEASE CONTACT US
104245003		Reservoir	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
104249001		Inflation Cock	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
104249002		Inflation Cock	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
104250001		Pressure Indicator Switch	DOWTY AEROSPACE	OH/REP/TEST	A330;A360;SKY	PLEASE CONTACT US
104258002		Relief Valve	DOWTY AEROSPACE	OH/REP/TEST	SD330;JETST	PLEASE CONTACT US
104259001		Relief Valve	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
104270001		Pressure Reducing Valve	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
104277001		Release Valve	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
104317001		Cut-Off Valve	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
104343001		Accumulator	DOWTY AEROSPACE	OH/REP/TEST	F50;SD330;SD360	PLEASE CONTACT US
104353001		Pressure Reducing Valve	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
104471003		Nose Landing Gear Actuator	MESSIER-DOWTY	OH/REP/TEST	CL601;CL602	PLEASE CONTACT US
104512001		Pressure Reducing Valve	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
104661001		Uplock Jack	DOWTY	OH/REP/TEST	HS748	PLEASE CONTACT US
104796002		MLG Actuator	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
104796003		MLG Actuator	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
104796004		MLG Actuator	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
104797001		Actuator	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
104797002		Actuator	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
104800003		Steering Control Valve	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
104800004		Steering Control Valve	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
114157001		Steering Control Valve	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
114167001		Centring Actuator	DOWTY	OH/REP/TEST	F28;F100	PLEASE CONTACT US
114200001		Shimmy Restrictor	DOWTY	OH/REP/TEST	F50	PLEASE CONTACT US
114201001		Steering Control Valve	DOWTY	OH/REP/TEST	F50	PLEASE CONTACT US
114201002		Steering Control Valve	DOWTY	OH/REP/TEST	F50	PLEASE CONTACT US
114202001		Steering Control Valve	DOWTY	OH/REP/TEST	F28;F100	PLEASE CONTACT US
114202002		Steering Control Valve	DOWTY	OH/REP/TEST	F28;F100	PLEASE CONTACT US
114202003		Steering Control Valve	DOWTY	OH/REP/TEST	F28;F100	PLEASE CONTACT US

114220001		Main Undercarriage Jack	DOWTY	OH/REP/TEST	F28;F100	PLEASE CONTACT US
114220002		Main Undercarriage Jack	DOWTY	OH/REP/TEST	F28;F100	PLEASE CONTACT US
114350001		Nose Undercarriage Jack	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
1855E5		Wing Flap Emergency Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
200020298		Single Swivel Pipe	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200020314		Swivel Coupling (LH)	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200020315		Swivel Coupling (RH)	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061004		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061006		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061008		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061010		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061012		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061014		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061016		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061018		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200061020		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200062007		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200062008		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200062010		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200062011		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200062012		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200062013		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200062014		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200062015		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063001		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063002		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063003		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063004		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063005		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063007		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063101		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063102		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063103		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063104		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063105		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200063107		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200140001		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200140002		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200140003		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200140004		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200140005		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200141004		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200141005		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200141006		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200141007		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US

200141008		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200143001		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200143002		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200143003		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200170002		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170004		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170006		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170008		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170010		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170012		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170014		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170016		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170018		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200170020		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200174001		Double Swivel Pipe	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200175001		Downlock Block Unit	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200175002		Downlock Block Unit	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200175300		Downlock Block	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200175302		Downlock Block	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200197003		Retraction Link	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200197004		Retraction Link	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200197006		Retraction Link	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200223001		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200223203		Upper Swivel Coupling & Centre S. Pipe	MESSIER DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
200223204		Upper Swivel Coupling & Centre S. Pipe	MESSIER DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
200223206		Upper Swivel Coupling & Centre S. Pipe	MESSIER DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
200223208		Upper Swivel Coupling & Centre S. Pipe	MESSIER DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
200224001		Main Undercarriage Drag Stay	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200228001		Uplock	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200228002		Uplock	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200251001		Upper Member	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200260001		Lock Strut	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200261001		Drag Stay	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200275001		Drag Stay	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200277002		Retraction Link	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200277003		Retraction Link	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200304001		Downlock Block Unit	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200324001		Main Undercarriage Downlock	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200325001		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200325002		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200325003		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200342001		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200342002		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200342003		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200427003		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US

200427004		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427005		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427006		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427007		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427008		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427009		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427010		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427013		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427014		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427015		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427016		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427017		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427018		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427019		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200427020		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200429002		Nose Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200429003		Nose Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200429004		Nose Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200429005		Nose Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200444001		Damper	DOWTY AEROSPACE	OH/REP/TEST	F28;F100	PLEASE CONTACT US
200444002		Damper	DOWTY AEROSPACE	OH/REP/TEST	F28;F100	PLEASE CONTACT US
200444003		Damper	DOWTY AEROSPACE	OH/REP/TEST	F28;F100	PLEASE CONTACT US
200444004		Damper	DOWTY AEROSPACE	OH/REP/TEST	F28;F100	PLEASE CONTACT US
200451012		Uplock	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200451013		Uplock	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200463001		Main Undercarriage Upper Member	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200472001		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200473002		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200473003		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200473004		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200473006		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200473007		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200473008		Shock Absorber	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200477001		Cross Beam & Radius Rod	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200485001		Drag Stay	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200485003		Drag Stay	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200485004		Drag Stay	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200487001		NLG Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200490001		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200497004		Jack And Springpot	DOWTY AEROSPACE	OH/REP/TEST	F28;F100	PLEASE CONTACT US
200497005		Jack And Springpot	DOWTY AEROSPACE	OH/REP/TEST	F28;F100	PLEASE CONTACT US
200498004		Jack And Springpot	DOWTY AEROSPACE	OH/REP/TEST	F28;F100	PLEASE CONTACT US
200498005		Jack And Springpot	DOWTY AEROSPACE	OH/REP/TEST	F28;F100	PLEASE CONTACT US
200566001		Shock Absorber	MESSIER DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
200566002		Shock Absorber	MESSIER DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US

200580001		Main Undercarriage Downlock	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200581001		Uplock	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200587001		Nose U/C Downlock Bracket Assy	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200633001		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200633002		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200633005		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200633006		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200635001		Nose Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200635002		Nose Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200642005		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200642006		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200642007		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200642008		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200642009		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200642010		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200643001		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F28	PLEASE CONTACT US
200643002		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F28	PLEASE CONTACT US
200664001		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200678001		Nose Undercarriage	MESSIER DOWTY	OH/REP/TEST	F27;F28	PLEASE CONTACT US
200682001		Uplock	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
200682002		Uplock	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
200725001		Nose Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200736001		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	F28	PLEASE CONTACT US
200739001		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200739002		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200739003		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200739004		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200739005		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200739006		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200752001		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200752002		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200752003		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200752004		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200752005		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782003		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782004		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782005		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782006		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782007		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782008		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782009		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782010		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782011		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200782012		Main Undercarriage	DOWTY	OH/REP/TEST	F28	PLEASE CONTACT US
200798001		Nose Undercarriage	MESSIER DOWTY	OH/REP/TEST	F27;F28	PLEASE CONTACT US

200851001		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200852001		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
200916001		Wheel Lever (LH)	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200917001		Wheel Lever (RH)	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200918001		Drag Brace	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200918002		Drag Brace	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200920001		Shock Absorber	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200920002		Shock Absorber	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200920003		Shock Absorber	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200920004		Shock Absorber	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200921001		Nose Landing Gear	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
200921003		Nose Landing Gear	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
200923002		Downlock Bracket	DOWTY AEROSPACE	OH/REP/TEST	SD360	PLEASE CONTACT US
200927001		Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200927002		Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
200950001		Rear Pintle Pin (LH)	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200951001		Rear Pintle Pin (RH)	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
200952003		Forward Pintle Pin	DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
201073001		Side Stay Assembly	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201073002		Side Stay Assembly	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201073003		Side Stay Assembly	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201115001		Wheel Lever	MESSIER DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
201116001		Wheel Lever	MESSIER DOWTY	OH/REP/TEST	SD360	PLEASE CONTACT US
201218001		Jack And Springpot	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201218002		Jack And Springpot	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201218003		Jack And Springpot	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201218004		Jack And Springpot	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201218005		Jack And Springpot	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201218006		Jack And Springpot	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201218007		Jack And Springpot	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
201218008		Jack And Springpot	DOWTY	OH/REP/TEST	F100	PLEASE CONTACT US
286351005		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A300;A320	PLEASE CONTACT US
286351006		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A300;A320	PLEASE CONTACT US
286351007		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A300;A320	PLEASE CONTACT US
289021122		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A340	PLEASE CONTACT US
601012414		Drive Shaft Assy	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
601012416		Drive Shaft Assy	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
601021436		Slip Ring Assembly	DOWTY	OH/REP/TEST	HS748	PLEASE CONTACT US
601021623		Brush Gear Housing	DOWTY	OH/REP/TEST	HS748	PLEASE CONTACT US
601021624		Brush Gear Housing	DOWTY	OH/REP/TEST	HS748	PLEASE CONTACT US
602070001		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
602070009		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
602250001		Gearbox Drive Shaft	DOWTY	OH/REP/TEST	YS11	PLEASE CONTACT US
610020004		Corrector Motor	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
610020008		Corrector Motor	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US

632002001		Corrector Unit	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
638005205		Motor Assembly	DOWTY	OH/REP/TEST	SAAB340	PLEASE CONTACT US
1044661001		Uplock Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
1855E6		Wing Flap Emergency Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2132010011		Indicator	SCHLUMBERGER	OH/REP/TEST	BAE146;BAE ATP;TUCA	PLEASE CONTACT US
2132010019		Indicator	SCHLUMBERGER	OH/REP/TEST	BAE146;BAE ATP;TUCA	PLEASE CONTACT US
2132010022		Indicator	SCHLUMBERGER	OH/REP/TEST	BAE146;BAE ATP;TUCA	PLEASE CONTACT US
1855E95	695422-10	Wing Flap Emergency Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1855E96	695422-11	Wing Flap Emergency Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
002000AA000NC9A		Air Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
002002AA000NC9A		Air Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
0091520200-1		Vent Valve Assembly	ESSEX IND.	OH/REP/TEST	B737;B757	PLEASE CONTACT US
0091520200-2		Reservoir Vent Valve	ESSEX IND.	OH/REP/TEST	B737;B757	PLEASE CONTACT US
011800AA000GC9A		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
011802AA000JC6A		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
021027-010-01		Fuel Pump	PESCO	OH/REP/TEST	F100	PLEASE CONTACT US
040-20300	40-203	Main Wheel Assembly	PARKER	OH/REP/TEST	KING AIR 200	PLEASE CONTACT US
040-23901		Wheel Assembly	PARKER	OH/REP/TEST	CITATION 550	PLEASE CONTACT US
0411KTS/1		Turn And Slip Indicator	SMITHS INDUSTRIES	OH/REP/TEST	F100	PLEASE CONTACT US
0432KMB/CP/1		Mach Air Speed Switch	SMITHS	OH/REP/TEST	BAE125;F100	PLEASE CONTACT US
0432KTD/1		Tachometer Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
08-60169-001		Hydraulic Accumulator (100 Cu In)	TACTAIR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-60170-001		Hydraulic Accumulator (100 Cu In)	TACTAIR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8421-001-1		Hydraulic Accumulator (100 Cu In)	TACTAIR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8421-010	MS28700-1	Hydraulic Accumulator	YORK INDUSTRIES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8422-001		Hydraulic Accumulator	YORK INDUSTRIES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8422-001-1		Hydraulic Accumulator	YORK INDUSTRIES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8422-0011		Hydraulic Accumulator (100 Cu In)	TACTAIR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8422-010		Hydraulic Accumulator	YORK INDUSTRIES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8424-0011	MS28700-4	Hydraulic Accumulator (100 Cu In)	TACTAIR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8424-010	MS28700-4	Hydraulic Accumulator	TACTAIR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
08-8425-010	MS28700-5	Hydraulic Accumulator (200 Cu In)	TACTAIR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
09038YA01		Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09038YA01		Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09039YA01		Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09039YA01		Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09045YA01		Single Swivel Pipe	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09045YA01		Single Swivel Pipe	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09046YA01		Double Swivel Pipe	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09053YA01		Swivel Lower	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09054YA01		Upper Member	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09055YA01		Pipe Swivel Centre (RH)	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09056YA01		Pipe Swivel Centre (LH)	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09057YA01		Drag Stay	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09058YA01		Lock Strut	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US

09059YA01		Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09060YA01		Swivel Coupling	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09061YA01		Coupling Swivel Upper (LH)	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09062YA01		Coupling Swivel Upper (RH)	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
09063YA01		Uplock	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
1/Q2398		Hydraulic Reservoir	BAE	OH/REP/TEST	HS748	PLEASE CONTACT US
10-0015-1		Wheel Well Dome Light	GRIMES	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
10-0027-1		Passenger Reading Light	GRIMES	OH/REP/TEST	A300	PLEASE CONTACT US
1001/2PG		Differential Pressure Switch	SMITHS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
1001/2PG/CP6		Differential Pressure Switch	SMITHS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
1001/9PG		Differential Pressure Switch	SMITHS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
1001/9PG/6		Differential Pressure Switch	SMITHS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
10031-0000-01	10-60722-8	Oil Qty Indicator	BF GOODRICH	OH/REP/TEST	B737;DC10	PLEASE CONTACT US
1004PG		Torque Pressure Transmitter	SMITHS	OH/REP/TEST	F27;GS1;HRLD	PLEASE CONTACT US
1004PG/SB		Torque Pressure Transmitter	SMITHS	OH/REP/TEST	F27;GS1;HRLD	PLEASE CONTACT US
10051-0000-01	10-60722-13	Oil Qty Indicator	BF GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
1007FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
100800-1		Actuator Assembly	AVIONIC PRODUCTS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
100-849-21		Motor Driven Hydraulic Pump	ADEL-CRANE HYD-AIRE	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
1008700-1		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1008700-2	MS28700-2	Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1008700-3		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1008700-4	MS28700-4	Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1008700-5		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1008700-6		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1008700-7		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1008FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1009350-1		Rotary Actuator Assembly	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1009350-2		Rotary Actuator Assembly	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101/10		Heated Waste Water Outlet	FLITEFORM	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
101004-03		Solenoid Valve	PURITAN	OH/REP/TEST	A300	PLEASE CONTACT US
101005-03		Solenoid Valve	PURITAN	OH/REP/TEST	A300	PLEASE CONTACT US
10-1026	695872-1	Hydraulic Valve Assy	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
10-1026-1		Hydraulic Valve Assy	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101041-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101041-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101051-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101051-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101051-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101051-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1010530-6		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1010530-7		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101-17		Heated Waste Water Outlet	FLITEFORM	OH/REP/TEST	BAC111(CofC only);BAE146	PLEASE CONTACT US
101-18		Heated Waste Water Outlet	FLITEFORM	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
101-19		Heated Waste Water Outlet	AIM(FLITEFORM)	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US

101-22		Heated Waste Water Outlet	AIM(FLITEFORM)	OH/REP/TEST	BAE146	PLEASE CONTACT US
1012200-1		Ramp Control Valve Assy	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1012200-2		Ramp Control Valve Assy	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1012200-3		Ramp Control Valve Assy	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1012200-4	695762-3	Ramp Control Valve Assy	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101-24		Heated Waste Water Outlet	AIM AVIATION	OH/REP/TEST	TBD	PLEASE CONTACT US
10-1382-1	AN6248-3	Hydraulic Hand Pump	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1014/3PG		Differential Pressure Switch	SMITHS AEROSPACE	OH/REP/TEST	BAE125	PLEASE CONTACT US
1014/3PG/CP		Differential Pressure Switch	SMITHS AEROSPACE	OH/REP/TEST	BAE125	PLEASE CONTACT US
1015FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	F27	PLEASE CONTACT US
101-6		Heated Waste Water Outlet	AIM(FLITEFORM)	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
101657-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
101657-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1016FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	F27	PLEASE CONTACT US
101720-01354		Altimeter	AEROSONIC	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
101730-01356		Altimeter	AEROSONIC	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
1017FG/MB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	F27	PLEASE CONTACT US
101-8		Heated Waste Water Outlet	FLITEFORM	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
101-8001-47	3-1341-1	Main Wheel Assembly	GOODRICH	OH/REP/TEST	BEECHCRAFT	PLEASE CONTACT US
101-8002-5	5002460	Main Wheel Assembly	ABSC	OH/REP/TEST	BEECH B200	PLEASE CONTACT US
101-8002-51	5002460-1	Main Wheel Assembly	ABSC	OH/REP/TEST	BEECH B200	PLEASE CONTACT US
101-8002-57	5002460-2	Main Wheel Assembly	ABSC	OH/REP/TEST	BEECH B200	PLEASE CONTACT US
101809-00		Altitude Switch	B/E AEROSPACE	TEST ONLY	A300	PLEASE CONTACT US
1018FG/MB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	F27	PLEASE CONTACT US
102-00000	MS28034-1	Temperature Sensor	NORWICH AERO	TEST ONLY	C130;B747	PLEASE CONTACT US
1023PG/SB		Oil Pressure Transmitter	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
1024PG/SB		Oil Pressure Transmitter	SMITHS	OH/REP/TEST	HS748;F27;GS1;HRLD	PLEASE CONTACT US
102650BA		DC Motor	ITT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
102650FA		DC Motor	ITT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
102650K100		DC Motor	ITT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
10280-A1		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
102842DB		Actuator Assembly	ITT	OH/REP/TEST	B707;B727;B737;B747	PLEASE CONTACT US
102842ED		Actuator Assembly	GENERAL CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
102842FM		Actuator Assembly	ITT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
102842FN		Actuator Assembly	ITT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
102842HD		Actuator Assembly	ITT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
102842LX		Actuator Assembly	ITT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
102AB06		Sp Aero Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
103351-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103351-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103351-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103351-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103432-1		Shut Off Valve	STRATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103971-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103971-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US

103971-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103971-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
103BB04/1		3/8 Diam Sp Drain Valve	SAUNDERS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
1-040-0001		Vibration Indicator	BELL AND HOWELL	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
1-040-0002		Vibration Indicator	BELL AND HOWELL	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
1-040-0005		Vibration Indicator	BELL AND HOWELL	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
104156-1-6		Shut Off Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
104156-1-7		Shut Off Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
10470-1		Hyd Pump & Motor (10500-1)	SUNDSTRAND	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
10470-2		Hyd.Pump & Motor (10500-1)	SUNDSTRAND	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
10470-5		Motor Pump	SUNDSTRAND	OH/REP/TEST	B707;B727	PLEASE CONTACT US
1047PG/SB		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
104AR11/1		Aero Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
104CM14-AD		Motorised Sp Aero Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
104DPG/2		Air Pressure Gauge	SMITHS	OH/REP/TEST	BAC111;F27	PLEASE CONTACT US
10500-1		Motor Pump	SUNDSTRAND	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
10500-6		Motor Pump	SUNDSTRAND	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
10500-7		Motor Pump	SUNDSTRAND	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
105045-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105045-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105045-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105045-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105055-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105055-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105055-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105055-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105071-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105071-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105071-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
105071-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1051R228		Emergency G/Box With Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1051R268		Emergency G/Box With Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1051R274	695579-69	Emergency G/Box With Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1051R300	695579-69	Emergency G/Box With Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1052PG/SB		Pressure Warning Switch	SMITHS INDUSTRIES	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
1053PG/KP		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
1056350-2		Pressure Control Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1056350-20		Pressure Control Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1056350-21		Pressure Control Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1056350-3		Pressure Control Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1056350-7		Pressure Control Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1056PG/KP		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	B707	PLEASE CONTACT US
1058FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
105BM10		Motorised Sp Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
105SPT/BU/1		Position Transmitter	SMITHS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US

10-61063-8	2601571-1	Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
10-61287-10	2-1147	MLG Brake Assembly	B F GOODRICH	OH/REP/TEST	B727	PLEASE CONTACT US
106475-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106475-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106475-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106475-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106535-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106535-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106535-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106535-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106616-0-3		2 1/2 Inch Shutoff Airflow Regulator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106616-1-1	695753-3	2 1/2 Inch Shutoff Airflow Regulator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
106785A104		Motor Assembly	ITT	OH/REP/TEST	B727	PLEASE CONTACT US
106785A105		Motor Assembly	ITT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
106785A111		Motor Assembly	ITT	OH/REP/TEST	DHC-7	PLEASE CONTACT US
106785B100		Motor Assembly	ITT	OH/REP/TEST	B707;B727;B737;B747;B767	PLEASE CONTACT US
106785B101		Motor Assembly	ITT	OH/REP/TEST	B707;B727;B737;B747;B767	PLEASE CONTACT US
106785B105		Motor Assembly	ITT	OH/REP/TEST	B707;B727;B737;B747;B767	PLEASE CONTACT US
106785B110		Motor Assembly	ITT	OH/REP/TEST	DHC-7	PLEASE CONTACT US
106785B114		Motor Assembly	ITT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
106785B125		Motor Assembly	ITT	OH/REP/TEST	B707;B727;B737;B747;B767	PLEASE CONTACT US
106785B133		Motor Assembly	ITT	OH/REP/TEST	B707;B727;B737;B747;B767	PLEASE CONTACT US
106785C101		Motor Assembly	ITT	OH/REP/TEST	DHC-7	PLEASE CONTACT US
106788A103		Actuator Assembly	ITT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
106788A128		Actuator Assembly	ITT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
106788A131		Actuator Assembly	ITT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
106788A140		Actuator Assembly	ITT	OH/REP/TEST	B747	PLEASE CONTACT US
106788A144		Actuator Assembly	ITT	OH/REP/TEST	B737;B747	PLEASE CONTACT US
106788A205		Actuator Assembly	ITT	OH/REP/TEST	B747	PLEASE CONTACT US
106788B164		Actuator Assembly	ITT	OH/REP/TEST	DHC-7	PLEASE CONTACT US
106788B165		Actuator Assembly	ITT	OH/REP/TEST	DHC-7	PLEASE CONTACT US
106RV		Engine Speed Generator	SMITHS	OH/REP/TEST	F27;GS1	PLEASE CONTACT US
106RV/KP		Engine Speed Generator	SMITHS	OH/REP/TEST	F27;GS1	PLEASE CONTACT US
106RV/SB		Engine Speed Generator	SMITHS	OH/REP/TEST	F27;GS1	PLEASE CONTACT US
10700-1		Flow Control Valve	VICKERS	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
10700-5		Flow Control Valve	VICKERS	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
107025-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
107025-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
107025-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
107025-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
107-133		Brake Adjuster	GOODRICH	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
107312-1		Pneumatic Relay	GARRETT	OH/REP/TEST	CONV;F28;YS11	PLEASE CONTACT US
107416-1-1		Air Pressure Control	GARRETT	OH/REP/TEST	B727;B737;F100	PLEASE CONTACT US
10751-17		Aileron Tab Lockout Cylinder Assy.	MENASCO-COLTEC	OH/REP/TEST	F100	PLEASE CONTACT US
10752A		Oil Cooler	SOUTH WIND	OH/REP/TEST	C130;L100	PLEASE CONTACT US

10752C		Oil Cooler	SOUTH WIND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
108136-1		Air Pressure Regulator	ALLIED SIGNAL	OH/REP/TEST	C130;F28;GS11;YS11	PLEASE CONTACT US
10870-2		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
108BM56/1-CA		Multiway Sp Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
108DM51/1-AC		Aero Valve	FLIGHT REFUELING	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
108DM51-B		Aero Valve	FLIGHT REFUELING	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
108M2		Hydraulic Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
1091PG/BU/1		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
1091PG/CP/1		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	BAC111;F27	PLEASE CONTACT US
109710-2-1		Butterfly Shutoff Valve	ALLIED SIGNAL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
10C(2)	53433-002	Inertia Switch	KIDDE GRAVINER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
11-0151-00-0		Beverage Container	ROLF RODEHAU	OH/REP/TEST	TBD	PLEASE CONTACT US
11-0283-2	10-60091-38	Emergency Exit Light Subassembly	GRIMES	OH/REP/TEST	B707;B727	PLEASE CONTACT US
11-0283-3		Emergency Exit Light Subassembly	GRIMES	OH/REP/TEST	B737;B747	PLEASE CONTACT US
11-0283-7		Emergency Exit Light Subassembly	GRIMES	OH/REP/TEST	B727	PLEASE CONTACT US
1103KSD/BU/1		Altitude Switch	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
1103KSD/BU/2		Altitude Switch	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
1105123-1		Actuator Oil Cooler Flap	SMITH & SMITH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
11060-7		Dual Power Brake Valve	NUCLEAR VALVE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1107KSD/BU/1		Altitude Switch	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
110EM51-AB		Aero Valve	SAUNDERS AERO VALVES	OH/REP/TEST	BAC111(CofC only);GS1	PLEASE CONTACT US
110JR02		Valve	FLIGHT REFUELING	OH/REP/TEST	HS748	PLEASE CONTACT US
111095-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1111-5	695434	Tandem Aileron Cylinder	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1111-517704		Swing Check Valve	PARKER	OH/REP/TEST	DC8	PLEASE CONTACT US
1111-517708	695656-1	Valve Fuel Check	LOCKHEED	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
1111-578574	695833-1	Valve Fuel Check	LOCKHEED	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
1111KSD/BU/1		Altitude Switch	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
1112-587331		Valve	LOCKHEED	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
1112PG/CP		Oil Pressure Transmitter	SMITHS AEROSPACE	OH/REP/TEST	TBD	PLEASE CONTACT US
1118-GB-0120304		Tacho Generator	KOLLSMAN	OH/REP/TEST	HELI	PLEASE CONTACT US
1118-GC-0120304		Tacho Generator	KOLLSMAN	OH/REP/TEST	HELI	PLEASE CONTACT US
1118-GD-0120304		Tacho Generator	KOLLSMAN	OH/REP/TEST	TBD	PLEASE CONTACT US
111AM/PC/M		Altimeter	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
1120-1		Rudder Boost Cylinder Assembly	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1120-3		Rudder Boost Cylinder Assembly	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1130PG/CP	1130PG-CP	Oil Pressure Transmitter	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
1132PG/CP		Torque Pressure Transmitter	SMITHS	OH/REP/TEST	F27;GS1;HRLD	PLEASE CONTACT US
1133-1		Pressure Switch	HYDRA ELECTRIC	TEST ONLY	GS1	PLEASE CONTACT US
1135PG/CP		Oil Pressure Transmitter	SMITHS AEROSPACE	OH/REP/TEST	BAC111(CofC only);F27	PLEASE CONTACT US
1137PG/BU/1		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
1138PG/CP/1		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	F27;F100	PLEASE CONTACT US
113PTS/BU/1		Synchro Pressure Transmitter	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
113PTS/CP/1		Synchro Pressure Transmitter	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
11400-1		Hydraulic Pump	SUNDSTRAND	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US

1145-0015	10-61383-1	Water Quantity Transmitter	KAISER	OH/REP/TEST	B737	PLEASE CONTACT US
1145-0035	10-61383-3	Water Quantity Transmitter	KAISER	OH/REP/TEST	B737	PLEASE CONTACT US
114AM/PC		Altimeter	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
115.217-1		Water Quantity Indicator	ROGERSON	OH/REP/TEST	B747;B757	PLEASE CONTACT US
11553-000		Oil Cooler Radiator	HUGHES TREITLER	OH/REP/TEST	SEA KING;SIK 5-61	PLEASE CONTACT US
11562-103		Gear Motor	ELECTRA MOTION	OH/REP/TEST	F100	PLEASE CONTACT US
115-8001-4		Main Landing Gear Wheel	BEECHCRAFT	OH/REP/TEST	BEECH	PLEASE CONTACT US
1160-8		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
11670-1		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1172PG/BU		Oil Pressure Transmitter	SMITHS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
1184R125	695755-1	Retrieving Winch	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1185PG/CP/1		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	BAE125	PLEASE CONTACT US
1185PG/CP/1		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	BAE125	PLEASE CONTACT US
11AG		Fuel Quantity Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
11C30-1M		Ignition Unit	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
1200FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1201FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1202FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1203FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1204FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1205FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1206FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
121000-1	695748-13	Air Control Valve	ROCKER IND.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
12-10001-01	695800-3	Oil Quantity Tank Unit	LIQUIDOMETER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
121000-2		Air Control Valve	ROCKER IND.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
12123YA01		Downlock Block Unit	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
12142-1-A		Inverter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
12143-1-A		Inverter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
12143-2-A		Inverter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
1214FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
121535-1		Butterfly Shutoff Valve	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1216FG/M		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
121AM/PC		Altimeter	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
1225P6-1		Pressure Switch	ITT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
1225P6-2		Pressure Switch	ITT	OH/REP/TEST	B737	PLEASE CONTACT US
122723-111-01		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-111-02		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-112-01		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-112-02		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-113-01		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-113-02		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-120-01		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-121-01		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-200-01		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
122723-200-01		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US

122723-200-02		Fuel Booster Pump	SUNDSTRAND	OH/REP/TEST	F27	PLEASE CONTACT US
123266-2-1		Check Valve	HONEYWELL	TEST ONLY	B737	PLEASE CONTACT US
123488-010-01	695592-3	Fuel Drain Pump	PESCO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
123510-010-01		Fuel Booster Pump	PESCO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
123510-011-01	695769-3	Fuel Booster Pump	PESCO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
123510-014-01		Fuel Booster Pump	PESCO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
124-132		Volt Amp Meter	ROGERSON-KRATOS	OH/REP/TEST	SD330	PLEASE CONTACT US
124-133	10-60757-144	DC Ammeter	ROGERSON-KRATOS	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
124-155		Voltage/Frequency Meter	ROGERSON-KRATOS	OH/REP/TEST	SD330	PLEASE CONTACT US
124-551-9		ITT Indicator	ROGERSON-KRATOS	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
124-832	10-60757-22	AC Voltmeter	ROGERSON-KRATOS	OH/REP/TEST	B707;B727;B737;DC10	PLEASE CONTACT US
124-833	10-60757-23	DC Voltmeter	ROGERSON-KRATOS	OH/REP/TEST	B707;B727;DC10	PLEASE CONTACT US
124-834	10-60757-24	DC Ammeter	ROGERSON-KRATOS	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
124-838	10-60757-28	Temperature Indicator	ROGERSON-KRATOS	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
12525-21		MLG Door Actuator Assy.	MENASCO	OH/REP/TEST	F100	PLEASE CONTACT US
12525-25		MLG Door Actuator Assy.	MENASCO	OH/REP/TEST	F100	PLEASE CONTACT US
12529-2		Pressure Switch	HYDRA ELECTRIC	TEST ONLY	TBD	PLEASE CONTACT US
12530-2		Pressure Switch	HYDRA ELECTRIC	TEST ONLY	TBD	PLEASE CONTACT US
12550-5		NLG Door Uplock Actuator Assy.	MENASCO	OH/REP/TEST	F100	PLEASE CONTACT US
12575-1		MLG Door Uplock Actuator	MENASCO	OH/REP/TEST	F100	PLEASE CONTACT US
12575-3		MLG Door Uplock Actuator	MENASCO	OH/REP/TEST	F100	PLEASE CONTACT US
12575-7		MLG Door Uplock Actuator	MENASCO	OH/REP/TEST	F100	PLEASE CONTACT US
126/1PG		Differential Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	F100	PLEASE CONTACT US
126/2PG		Differential Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	F100	PLEASE CONTACT US
126/3PG		Differential Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	F100	PLEASE CONTACT US
126/4PG		Differential Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	F100	PLEASE CONTACT US
12920-3		Change Angle Gearbox Assy.	MENASCO	OH/REP/TEST	F100	PLEASE CONTACT US
129666-1		Pre Cooler Control Valve Sensor	HONEYWELL	OH/REP/TEST	B737;B777	PLEASE CONTACT US
129666-2		Pre Cooler Control Valve Sensor	HONEYWELL	OH/REP/TEST	B737;B777	PLEASE CONTACT US
129666-3		Pre Cooler Control Valve Sensor	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
129694-1		Bleed Air Overtemp Sensor	HONEYWELL	OH/REP/TEST	B737;B777	PLEASE CONTACT US
129694-2		Bleed Air Overtemp Sensor	HONEYWELL	OH/REP/TEST	B737;B777	PLEASE CONTACT US
129694-3		Bleed Air Overtemp Sensor	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
129FL		Desynn Position Transmitter	SMITHS	OH/REP/TEST	GS1	PLEASE CONTACT US
129FL/BR		Desynn Position Transmitter	SMITHS	OH/REP/TEST	GS1	PLEASE CONTACT US
12D117-4		Ball Drain Valve	ALLEN AIRCRAFT PROD	OH/REP/TEST	TBD	PLEASE CONTACT US
13210-1		Four-Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1323-566187M1		Precheck Pilot Valve	PARKER	OH/REP/TEST	B707;B757	PLEASE CONTACT US
132555-1	695812-1	Shutoff Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
132555-1	695812-1	Shutoff Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1327-566098		Fuel Cap	PARKER	OH/REP/TEST	DC8	PLEASE CONTACT US
1333-613233		Butterfly Air Valve	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1333-613233M1	695750-1	Butterfly Air Valve	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1334-3	695485-3	Hydraulic Servo Valve	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1334-5		Hydraulic Servo Valve	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US

1334-7	695485-7	Hydraulic Servo Valve	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
13500-003		Pressure Reducing Valve	EMBRAER	OH/REP/TEST	EMB110	PLEASE CONTACT US
1356-552093		Accumulator Assembly	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1356-552094		Accumulator Assembly	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1356-583314	MS28700-1	Hydraulic Accumulator	PARKER	OH/REP/TEST	C130;L100;DHC6;F50	PLEASE CONTACT US
1356-583314-101		Hydraulic Accumulator	PARKER	OH/REP/TEST	C130;DHC6;F50	PLEASE CONTACT US
1356-583315		Hydraulic Accumulator	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1356-583315-101		Hydraulic Accumulator	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1356-583317		Hydraulic Accumulator	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1356-613314		Hydraulic Accumulator	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1356-613511		Hydraulic Accumulator	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1356-613511-101		Hydraulic Accumulator	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1358FG		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
135FL		Position Transmitter	SMITHS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
1371-598820		Solenoid Selector Valve	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1371-598850		Solenoid Operated Pilot Valve	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1372-3		Hydraulic Boost Control Assy	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1372-4		Hydraulic Boost Control Assy	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1372-5		Hydraulic Boost Control Assy	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1372-579788		Hydraulic Manual Control Valve	PARKER HANNIFIN	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
138AM/PC		Altimeter	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
13V600-6	697260-1	Hydraulic Shuttle Valve	ALTAIR-GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14080-1	695526-3	Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
140925-1		Shutoff Valve	WHITTAKER	OH/REP/TEST	B707;B727	PLEASE CONTACT US
14302-201		Timer Assembly	MONOGRAM	OH/REP/TEST	A300	PLEASE CONTACT US
14302-205		Timer Assembly	MONOGRAM	OH/REP/TEST	A300	PLEASE CONTACT US
14302-207		Timer Assembly	MONOGRAM	OH/REP/TEST	A300	PLEASE CONTACT US
1430PG/AA/2		Pressure Switch	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
1430PG/AA/4		Pressure Switch	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
1433-623304		Rotary Actuator Assembly	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
143495-1		Selector Valve	WHITTAKER	OH/REP/TEST	GS1	PLEASE CONTACT US
143495-2		Selector Valve	WHITTAKER	OH/REP/TEST	GS1	PLEASE CONTACT US
143495-3		Selector Valve	WHITTAKER	OH/REP/TEST	GS1	PLEASE CONTACT US
143495-4		Selector Valve	WHITTAKER	OH/REP/TEST	GS1	PLEASE CONTACT US
1437-10		Hydraulic Boost Pump	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1437-2		Hydraulic Boost Pump	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1437-5		Hydraulic Boost Pump	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1437-8		Hydraulic Boost Pump	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
144213-010-01		Water/Alcohol Pump	SUNDSTRAND-PESCO	OH/REP/TEST	F27	PLEASE CONTACT US
144213-020-01		Water/Alcohol Pump	SUNDSTRAND-PESCO	OH/REP/TEST	F27	PLEASE CONTACT US
1458PG/SB/1		Differential Pressure Switch	SMITHS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
145AM/PC		Altimeter	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
146505-1		Selector Valve	WHITTAKER	OH/REP/TEST	BAC111(CofC only);B707	PLEASE CONTACT US
146505-15		Selector Valve	WHITTAKER	OH/REP/TEST	BAC111(CofC only);B707	PLEASE CONTACT US
147265-1		Control Valve	WHITTAKER	OH/REP/TEST	B707	PLEASE CONTACT US

1473PG/KP/1		Oil Pressure Switch	SMITHS INDUSTRIES	OH/REP/TEST	BAE125	PLEASE CONTACT US
147B31A		Oil Temperature Indicator	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
147B31A2		Oil Temperature Indicator	LOCKHEED	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
147B31A3		Oil Temperature Indicator	LOCKHEED	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
147B31A4		Oil Temperature Indicator	LOCKHEED	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
147B31B		Oil Temperature Indicator	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14-90002-08		Motor Assembly	CURTISS WRIGHT	OH/REP/TEST	F27;F50	PLEASE CONTACT US
14950-17	TYPE CRU-47/A	Oxygen Regulator	CARLETON-ARO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-34		Oxygen Regulator	CARLETON-ARO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-34/5072		Oxygen Regulator	CARLETON-ARO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-34M	CRU-68A/A	Oxygen Regulator	CARLETON-ARO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-34M/5072		Oxygen Regulator	CARLETON-ARO	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-40	CRU-73/A	Oxygen Regulator	CARLETON TECH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-40/5072		Oxygen Regulator	CARLETON TECH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-41		Oxygen Regulator	CARLETON TECH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-43	CRU-92/A	Oxygen Regulator	CARLETON TECH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
14950-45	CRU-73/A	Oxygen Regulator	CARLETON TECH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
149545-1		Door Control Valve	WHITTAKER	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
149545-4		Door Control Valve	WHITTAKER	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
14-97418	D-17418	Windshield Wiper Converter	CURTISS WRIGHT	OH/REP/TEST	F27;F50	PLEASE CONTACT US
14-97418-04		Windshield Wiper Converter	CURTISS WRIGHT	OH/REP/TEST	F27;F50	PLEASE CONTACT US
14-99154	D-16955	Windshield Wiper Converter	CURTISS WRIGHT	OH/REP/TEST	F27;F50	PLEASE CONTACT US
14-99154-41		Windshield Wiper Converter	CURTISS WRIGHT	OH/REP/TEST	F27;F50	PLEASE CONTACT US
15-0247-9		Service Compartment Light	GRIMES	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
15-0466-1		Floodlight Flexible Arm	GRIMES	OH/REP/TEST	BAE146	PLEASE CONTACT US
15-0470-1		Floodlight Pilots Map Case	GRIMES	OH/REP/TEST	BAE146	PLEASE CONTACT US
150550-3		Brake & Hydraulic Adjuster	BENDIX	OH/REP/TEST	B707	PLEASE CONTACT US
150741-5		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B707	PLEASE CONTACT US
150741-7		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B707	PLEASE CONTACT US
15101-1F-A5		Three Axis Trim Indicator	BENDIX	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
15103-3B-A1		Three Axis Trim Indicator	BENDIX	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
1518-14-E		Rotary Inverter	HONEYWELL	OH/REP/TEST	F27	PLEASE CONTACT US
1518-16-A		Rotary Inverter	HONEYWELL	OH/REP/TEST	F27	PLEASE CONTACT US
1518-8-C		Rotary Inverter	HONEYWELL	OH/REP/TEST	HS748	PLEASE CONTACT US
1518-8-D		Rotary Inverter	HONEYWELL	OH/REP/TEST	HS748	PLEASE CONTACT US
1518-8-E		Rotary Inverter	HONEYWELL	OH/REP/TEST	HS748	PLEASE CONTACT US
151D/01/XXX		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
1523103-121		Shock Strut	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1523107-103		MLG Jury Brace Actuator	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1523153-115		MLG Truck Beam Positioner	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1523153-117		Actuator	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1523153-119		MLG Truck Beam Positioner	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1523248-103		MLG Upstop Snubber	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1523249-109		MLG Uplock Snubber	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1523327-107		NLG Retraction Actuator	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US

1523327-117		NLG Retraction Actuator	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1523328-115		NLG Steering Actuator	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
152LMA18	10-62190-1	Temperature Indicator	LEWIS/HORIZON AERO	OH/REP/TEST	B737	PLEASE CONTACT US
152LMA22	10-62190-2	Temperature Indicator	LEWIS/HORIZON AERO	OH/REP/TEST	B737	PLEASE CONTACT US
152LMA23	10-62190-3	Temperature Indicator	LEWIS/HORIZON AERO	OH/REP/TEST	B737	PLEASE CONTACT US
1532-12A		De-Icer Distributing Valve	LUCAS	OH/REP/TEST	HS748;DHC-8;C130;F27;GS1	PLEASE CONTACT US
1532-2A		De-Icer Distributing Valve	LUCAS	OH/REP/TEST	HS748;DHC-8;C130;F27;GS1	PLEASE CONTACT US
1532-3A		De-Icer Distributing Valve	LUCAS	OH/REP/TEST	HS748;DHC-8;C130;F27;GS1	PLEASE CONTACT US
1532-3B		De-Icer Distributing Valve	LUCAS	OH/REP/TEST	HS748;DHC-8;C130;F27;GS1	PLEASE CONTACT US
1532-3C		De-Icer Distributing Valve	LUCAS	OH/REP/TEST	HS748;DHC-8;C130;F27;GS1	PLEASE CONTACT US
1532-6A		De-Icer Distributing Valve	LUCAS	OH/REP/TEST	HS748;DHC-8;C130;F27;GS1	PLEASE CONTACT US
1532-6C		De-Icer Distributing Valve	LUCAS	OH/REP/TEST	HS748;DHC-8;C130;F27;GS1	PLEASE CONTACT US
1532-8A		De-Icer Distributing Valve	LUCAS	OH/REP/TEST	HS748;DHC-8;C130;F27;GS1	PLEASE CONTACT US
1535830-103		Shock Strut Nose Landing Gear	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1535927-101		MLG Retraction Actuator	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1535927-109		MLG Retraction Actuator	LOCKHEED	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1539-11-B		Generator Control Panel	BENDIX	OH/REP/TEST	CONV;F27	PLEASE CONTACT US
1539-12-B		Generator Control Panel	BENDIX	OH/REP/TEST	CONV;F27	PLEASE CONTACT US
153DH1		AC Motor Assembly	WESTERN GEAR	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
153DH1R197		Power Drive Unit	WESTERN GEAR	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
154251-1		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	DC8	PLEASE CONTACT US
154252-1		Brake Assembly	BENDIX	OH/REP/TEST	DC8	PLEASE CONTACT US
154252-2		Brake Assembly	BENDIX	OH/REP/TEST	DC8	PLEASE CONTACT US
154615-3-1		Oil Temperature Control Valve	AIRESEARCH/HONEYWELL	OH/REP/TEST	BAE146	PLEASE CONTACT US
1554FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
155D/01/XXX		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
156D/01		High Speed Resetting Detector	KIDDE GRAVINER	OH/REP/TEST	BAE146	PLEASE CONTACT US
156PG		Pressure Warning Switch	SMITHS AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
157710-4		Actuator Assembly	WHITTAKER	OH/REP/TEST	B757	PLEASE CONTACT US
157720-1		Rotary Actuator	WHITTAKER	OH/REP/TEST	B767	PLEASE CONTACT US
157720-2		Rotary Actuator	WHITTAKER	OH/REP/TEST	B767	PLEASE CONTACT US
157PG		Pressure Warning Switch	SMITHS AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
157PG/BR		Pressure Warning Switch	SMITHS AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
15830A		Oxygen Regulator	ARO CORP.	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
15830E		Oxygen Regulator	ARO CORP.	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
15830L		Oxygen Regulator	ARO CORP.	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
15830M		Oxygen Regulator	ARO CORP.	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
15830N		Oxygen Regulator	ARO CORP.	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
1588-2-E		Voltage Regulator	BENDIX	OH/REP/TEST	GS1	PLEASE CONTACT US
1589-7-A		Voltage Regulator	BENDIX	OH/REP/TEST	GS1;HELI	PLEASE CONTACT US
158D/01/XXX		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
15900-105		Pressure Indicator	KOLLSMAN	OH/REP/TEST	TBD	PLEASE CONTACT US
160122-1		Air To Oil Cooler	AIRESEARCH	OH/REP/TEST	BAE146	PLEASE CONTACT US
1601KMB/CP/1		Air Speed Machswitch	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
1602KMB/CP/1		Air Speed Machswitch	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US

162A1100-9		Nose Landing Gear Component Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
162A2100-2		Nose Landing Gear Drag Strut Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
162A2100-3		Nose Landing Gear Drag Strut Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
162A2100-4		Nose Landing Gear Drag Strut Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
162A2100-5		Nose Landing Gear Drag Strut Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
162A2100-6		Nose Landing Gear Drag Strut Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
162A2100-7		Nose Landing Gear Drag Strut Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
162B2		Elec.Resistance Thermometer Indicator	LEWIS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
162B2D		Elec.Resistance Thermometer Indicator	LEWIS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
162B2G		Elec.Resistance Thermometer Indicator	LEWIS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
162B3		Elec.Resistance Thermometer Indicator	LEWIS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
162B3A		Elec.Resistance Thermometer Indicator	LEWIS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
162B4		Elec.Resistance Thermometer Indicator	LEWIS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
162D		Fire Wire Control Unit	KIDDE GRAVINER	OH/REP/TEST	HS748	PLEASE CONTACT US
162RV/KP		Engine Speed Generator	SMITHS	OH/REP/TEST	F27;GS1	PLEASE CONTACT US
162RV/SB		Engine Speed Generator	SMITHS	OH/REP/TEST	F27;GS1	PLEASE CONTACT US
163B2		Temperature Indicator	LEWIS	OH/REP/TEST	HELI	PLEASE CONTACT US
164-1		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
16430-1		Hyd Suction Boost Pump	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
164D		Control Unit	KIDDE GRAVINER	OH/REP/TEST	TBD	PLEASE CONTACT US
1650E321		Vertical Shaft Assembly	WESTERN GEAR CORP	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1650E412	695579-39	MLG Ballscrew Assembly	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1650E615	695579-71	MLG Ballscrew Assembly	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1650E615	695579-71	MLG Ballscrew Assembly	WESTERN GEAR	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1650R21		MLG Gearbox Assembly	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1650R319	695579-7	MLG Gearbox Assembly	WESTERN GEAR	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
16760-1		Manual Control Valve	SUNDSTRAND	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
16760-2		Manual Control Valve	SUNDSTRAND	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
1679FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1693FG		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1697EA		Hydraulic Control Valve	SARGENT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
1697EA-1		Hydraulic Control Valve	SARGENT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
17051-101		Uplock Assembly	MESSIER DOWTY	OH/REP/TEST	CL600;CL601;CL604	PLEASE CONTACT US
172625-5	S332A101-5	Nose Cowl Thermal Anti-Ice Valve	WHITTAKER	OH/REP/TEST	B737	PLEASE CONTACT US
172625-6	S332A101-6	Nose Cowl Thermal Anti-Ice Valve	WHITTAKER	OH/REP/TEST	B737	PLEASE CONTACT US
172625-7	S332A101-7	Nose Cowl Thermal Anti-Ice Valve	WHITTAKER	OH/REP/TEST	B737	PLEASE CONTACT US
17279-101		Uplock Assembly	MESSIER DOWTY	OH/REP/TEST	CL600;CL601;CL604	PLEASE CONTACT US
17343-006-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-011-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-016-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-061-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-062-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-078-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-081-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-083-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US

17343-087-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-104-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-106-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-108-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-161-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-771-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
17343-781-XXX		Unit Fire Detector	FENWAL	TEST ONLY	C130;L100	PLEASE CONTACT US
1777FG		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
178040-2		Heat Exchanger	AIRESEARCH	TEST ONLY	B727	PLEASE CONTACT US
17989-4		Linear Actuator Assembly	CONRAC	OH/REP/TEST	DC8	PLEASE CONTACT US
1807H1		Sampling Valve Assembly	FAIREY	OH/REP/TEST	F100	PLEASE CONTACT US
18-1105	MS28010-5	Hydraulic Pressure Indicator	COURTER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
18-1278	695674-1	Oil Pressure Indicator	COURTER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
18-1299		Flap Position Indicator	BENDIX	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
18-1299-2		Flap Position Indicator	BENDIX	OH/REP/TEST	B727;DC10	PLEASE CONTACT US
18-1299-3		Flap Position Indicator	BENDIX	OH/REP/TEST	B727;DC10	PLEASE CONTACT US
18-1299-3-2		Flap Position Indicator	BENDIX	OH/REP/TEST	B727;DC10	PLEASE CONTACT US
18-1299-4		Flap Position Indicator	BENDIX	OH/REP/TEST	B727;B737;DC10	PLEASE CONTACT US
18-1704		Pressure Transmitter	COURTER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
18-1729		Pressure Transmitter	COURTER	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
181PG/SB		Pressure Transmitter	SMITHS AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
18-2021		Pressure Indicator	COURTER	TEST ONLY	C130;L100	PLEASE CONTACT US
1827FG		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
182820-1-1		Heat Exchanger	HONEYWELL	TEST ONLY	B737	PLEASE CONTACT US
182820-2		Heat Exchanger	HONEYWELL	TEST ONLY	B737	PLEASE CONTACT US
182820-3		Heat Exchanger	HONEYWELL	TEST ONLY	B737	PLEASE CONTACT US
1848FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
18500-3		NLG Retraction Actuator	MENASCO	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
18500-5		NLG Retraction Actuator	MENASCO	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
18500-7		NLG Retraction Actuator	MENASCO	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
1855D10	695422-7	L/H Sensing Switch	WESTERN GEAR	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
1855D11	695422-9	R/H Sensing Switch	WESTERN GEAR	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
18C(2)	53433-001	Inertia Switch	KIDDE GRAVINER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
18Z10348		Landing Lamp	GRIMES	OH/REP/TEST	HS748	PLEASE CONTACT US
191PG		Pressure Switch	SMITHS AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
19-20-5	695187-1	Oil Flap Position Indicator	PENN KEYSTONE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
1927FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1952FG		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
1965FG		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
19AG		Fuel Quantity Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE125	PLEASE CONTACT US
1CZ135630A-3		Cub Jag Actuator	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
1CZ135830-A		Jaguar Actuator	FR-HITEMP	OH/REP/TEST	F27	PLEASE CONTACT US
1CZ136080-A		Jaguar Actuator	FR-HITEMP	OH/REP/TEST	F27	PLEASE CONTACT US
1CZ136480		Squirrel Actuator	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
1CZ80360/A/16		Cub Jag Actuator	GEC	OH/REP/TEST	BAE ATP	PLEASE CONTACT US

1CZ80360/B/13		Cub Jag Actuator	GEC	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
1G107	695906-1	Low Pressure Warning Switch	CUSTOM CONTROL SENS.	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
1G113		Air Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B737	PLEASE CONTACT US
1G222	697482-1	Air Pressure Switch	CUSTOM COMPONENTS	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
1G259-1	698430-1	Air Pressure Switch	CUSTOM COMPONENTS	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
1G259-2	698430-2	Air Pressure Switch	CUSTOM COMPONENTS	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
1G263		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	DC10;MD83	PLEASE CONTACT US
1G309		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B737	PLEASE CONTACT US
1U1110	10-6558-2	Leading Edge Hyd Flap Actuator	SMITHS	OH/REP/TEST	B727;B737	PLEASE CONTACT US
1V14397		Flasher Unit	A V ROE	OH/REP/TEST	TBD	PLEASE CONTACT US
1X4 003 665-00		Runway Turn Off Light	HELLA	OH/REP/TEST	BAE146	PLEASE CONTACT US
1X4 003 665-10		Runway Turn Off Light	HELLA	OH/REP/TEST	BAE146	PLEASE CONTACT US
200-037-005		Fuel Quantity Indicator	GULL AIRBORNE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
201-004-001		Torquemeter Indicator	GULL AIRBORNE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2012-1		Battery Charger Unit	RADIANT POWER CORP	OH/REP/TEST	B727;B737;B747;B757;B767	PLEASE CONTACT US
2013-1A		Battery Assembly	RADIANT	OH/REP/TEST	CRJ200	PLEASE CONTACT US
20140-0351		Air Speed Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
203430-1	695294-13	Aircraft Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
203430-4		Aircraft Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
203430-4-1		Aircraft Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
203720-1		Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
203720-2		Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
203720-3		Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
203720-3-2		Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
204050-10		Cooling Turbine	HONEYWELL	OH/REP/TEST	B727;B737	PLEASE CONTACT US
204050-11		Cooling Turbine	HONEYWELL	OH/REP/TEST	B727;B737	PLEASE CONTACT US
205BR04/1		Multiway Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
205CR04/1		Multiway Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
205DR04		Multiway Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
205MI		Valve Assembly	SAUNDERS-FLIGHT REF.	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
2094-0011		Water Quantity Indicator	KAISER	OH/REP/TEST	B737	PLEASE CONTACT US
20A03		Pressure Relief Valve	FLIGHT REFUELLING	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
20B100-20-A		Voltage Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
20B95-4-A		Voltage Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
20RC/PC		Rate Of Climb Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
210-2360	695753-1	Swivel Coupling	DUNBAR KAPPLE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
210-2365	695754-1	Swivel Coupling	DUNBAR KAPPLE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
2111FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
2-1147	10-61287-10	MLG Brake Assembly	B F GOODRICH	OH/REP/TEST	B727	PLEASE CONTACT US
2-1147-3	10-61287-18	MLG Brake Assembly	B F GOODRICH	OH/REP/TEST	B727	PLEASE CONTACT US
2-1195-5		Brake Unit	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
2-1195-7		Brake Unit	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
2120FG		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
2125H		Microfilter	FAIREY HYDRAULICS	OH/REP/TEST	BAE125	PLEASE CONTACT US
2129FG		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US

2132FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
2-1337-2		Multiple Disc Brake	B F GOODRICH	OH/REP/TEST	DHC-5	PLEASE CONTACT US
2134FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
2-1367		Brake Unit	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
2-1367-1		Brake Unit	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
2-1367-2		Brake Unit	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
2-1474-5	10-61819-31	Main Landing Gear Brake Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
2-1474-7	10-61819-35	Main Landing Gear Brake Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
21520-1		Mixed Flow Fan Assy	HAMILTON SUNDSTRAND	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2-1521	10-62174-2	MLG Brake Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
2-1521-1	10-62174-5	MLG Brake Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
2-1526		MLG Brake Assembly	BF GOODRICH	OH/REP/TEST	A319;A320	PLEASE CONTACT US
2-1526-2		MLG Brake Assembly	BF GOODRICH	OH/REP/TEST	A319;A320	PLEASE CONTACT US
2-1526-3		MLG Brake Assembly	BF GOODRICH	OH/REP/TEST	A319;A320	PLEASE CONTACT US
2-1526-4		MLG Brake Assembly	BF GOODRICH	OH/REP/TEST	A319;A320	PLEASE CONTACT US
2-1529-5		Main Brake Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 500	PLEASE CONTACT US
2-1529-6		Main Brake Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 500	PLEASE CONTACT US
2-1529-7		Main Brake Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 500	PLEASE CONTACT US
2-1535		MLG Brake Assembly	GOODRICH	OH/REP/TEST	WEST EH-101	PLEASE CONTACT US
2-1566	S294W511-310	MLG Brake Assembly	GOODRICH	OH/REP/TEST	B777	PLEASE CONTACT US
2-1587-1		Brake Assembly	B F GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
2-1588	9912469-5	Brake Assembly	B F GOODRICH	OH/REP/TEST	CESS BRAVO	PLEASE CONTACT US
2-1588-1	9912469-7	Brake Assembly	B F GOODRICH	OH/REP/TEST	CESS BRAVO	PLEASE CONTACT US
2-1601	9912487-5	Main Brake Assembly	GOODRICH	OH/REP/TEST	CESS 560XL	PLEASE CONTACT US
2-1601-1	9912487-7	Main Brake Assembly	GOODRICH	OH/REP/TEST	CESS 560XL	PLEASE CONTACT US
2-1608-2		Main Brake Assembly	GOODRICH	OH/REP/TEST	BD700	PLEASE CONTACT US
2177000-3		Aileron Hydraulic Actuator	NATIONAL WATERLIFT	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
2178000-5		Rudder Hydraulic Actuator	NATIONAL WATERLIFT	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
2179000-5		Aileron Hydraulic Actuator	NATIONAL WATERLIFT	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
218-013-001	S271T455-10	Hyd Quantity Remote Indicator	GULL AIRBORNE	OH/REP/TEST	B757	PLEASE CONTACT US
218-013-002	S271T455-11	Hyd Quantity Remote Indicator	GULL AIRBORNE	OH/REP/TEST	B757	PLEASE CONTACT US
218-013-003	S271T455-13	Hyd Quantity Remote Indicator	GULL AIRBORNE	OH/REP/TEST	B757	PLEASE CONTACT US
219A967	697489-1	Nose Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
219A967-1		Nose Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
21B67-1-A		Generator Control Unit	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
21M27-13		Pressure Switches	EATON	TEST ONLY	BAE146	PLEASE CONTACT US
2214FG/MB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	HS748	PLEASE CONTACT US
221Q2415		Hydraulic Reservoir	BAE JETSTREAM	OH/REP/TEST	HS748	PLEASE CONTACT US
2220FG		Desynn Contents Transmitter	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
2235FG/MB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
2236FG/SB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
2244FG/MB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
22472-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
22472-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
22472-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US

22472-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
224-917-012		Propeller RPM Indicator	GULL INC.	OH/REP/TEST	SD360	PLEASE CONTACT US
2252FG/MB		Desynn Contents Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
227595-2		Anti-Icing Valve	WHITTAKER	OH/REP/TEST	LYNX	PLEASE CONTACT US
227605-4		Manifold Assembly	WHITTAKER	OH/REP/TEST	LYNX	PLEASE CONTACT US
22A623		Tacho-Generator	GLOBE INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
2302KGA/CP/1		Engine Speed Generator	SMITHS	OH/REP/TEST	GS1	PLEASE CONTACT US
23048-001A		Starter Generator	LEAR SIEGLER	OH/REP/TEST	BEECH;D228;DHC6;TUCA	PLEASE CONTACT US
23069-015		Starter Generator	TRW-LUCAS	OH/REP/TEST	MERLIN	PLEASE CONTACT US
23076-001		DC Starter Generator	TRW-LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
23076-004-1		DC Starter Generator	TRW-LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
23088-001		DC Starter Generator	GOODRICH	OH/REP/TEST	TBD	PLEASE CONTACT US
23088-002		DC Starter Generator	GOODRICH	OH/REP/TEST	DHC-8	PLEASE CONTACT US
23088-003		DC Starter Generator	GOODRICH	OH/REP/TEST	DHC-8	PLEASE CONTACT US
23088-005		DC Starter Generator	GOODRICH	OH/REP/TEST	TBD	PLEASE CONTACT US
23088-005-1		DC Starter Generator	GOODRICH	OH/REP/TEST	TBD	PLEASE CONTACT US
23088-006		DC Starter Generator	GOODRICH	OH/REP/TEST	TBD	PLEASE CONTACT US
23088-015		DC Starter Generator	GOODRICH	OH/REP/TEST	TBD	PLEASE CONTACT US
23088-050		DC Starter Generator	GOODRICH	OH/REP/TEST	TBD	PLEASE CONTACT US
23088-064		DC Starter Generator	GOODRICH	OH/REP/TEST	TBD	PLEASE CONTACT US
2311M132	02311-0132-0001	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B747	PLEASE CONTACT US
2311M208-1	2311M-208-1	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B727;B737;FALCON 50	PLEASE CONTACT US
2311M208-2	2311M-208-2	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B727;B737;FALCON 50	PLEASE CONTACT US
2311M208-3	2311M-208-3	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B727;B737;FALCON 50	PLEASE CONTACT US
2311M49-1	02311-0049-0001	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M49-2	02311-0049-0002	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M49-3	02311-0049-0003	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M50-1	02311-0050-0001	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M50-2	02311-0050-0002	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M51-1	02311-0051-0001	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M51-2	02311-0051-0002	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M51-3	02311-0051-0003	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M51-4	02311-0051-0004	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
2311M69-1	2311M-69-1	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2311M69-2	2311M-69-2	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2311M69-3	2311M-69-3	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2311M69-4	2311M-69-4	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2311M69-5	2311M-69-5	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2311M69-6	2311M-69-6	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2312M104-11	2312M-104-11	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	ATP	PLEASE CONTACT US
2312M30-11	2312M-30-11	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
2312M30-17	02312-0030-0017	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2312M41-1	2312M-41-1	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	DHC-7	PLEASE CONTACT US
2312M67-1	2312M-67-1	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M194-1	2313M-194-1 (XW23629-1)	Windshield Wiper Motor-Converter	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US

2313M194-2	2313M-194-2 (XW23629-2)	Windshield Wiper Motor-Converter	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M194-3	2313M-194-3 (XW23629-3)	Windshield Wiper Motor-Converter	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M194-4	2313M-194-4 (XW23629-4)	Windshield Wiper Motor-Converter	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M21-1	2313M-21-1	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M21-2	2313M-21-2	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M21-3	2313M-21-3	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M21-4	2313M-21-4	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M21-5	2313M-21-5	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M21-6	2313M-21-6	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M21-7	2313M-21-7	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M21-8	2313M-21-8	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2313M37-1	2313M-37-1	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B747	PLEASE CONTACT US
2340940-1		Water Extractor	ALLIED SIGNAL	OH/REP/TEST	F100	PLEASE CONTACT US
23410-3	697395-1	Dual Brake Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23426-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23440-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23440-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23440-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23440-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23440-5		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23452-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23452-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23452-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
23452-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2350-0030-4	S417N203-3	DC Motor Actuator	CIRCLE SEAL CONTROLS	OH/REP/TEST	B757	PLEASE CONTACT US
2350-0030-5	S417N203-5	DC Motor Actuator	CIRCLE SEAL CONTROLS	OH/REP/TEST	B747	PLEASE CONTACT US
23700-5		MLG Damper Assembly	GOODRICH	OH/REP/TEST	TBD	PLEASE CONTACT US
23FWU/1/350		Cooling Air Failure Warning Unit	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
23FWU/1/370		Cooling Air Failure Warning Unit	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
23FWU/3/300		Cooling Air Failure Warning Unit	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
23FWU/3/380		Cooling Air Failure Warning Unit	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
24142-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24142-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24142-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24142-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24180-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24180-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24180-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24180-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24250-400-2	695272	Check Valve Assembly	MARMAN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
24420-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24420-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24420-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24420-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24424-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US

24424-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24424-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24424-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2-463-03		Time Delay Switch	CRANE-ELDEC	OH/REP/TEST	B737	PLEASE CONTACT US
2-463-2		Time Delay Switch	CRANE-ELDEC	OH/REP/TEST	B737	PLEASE CONTACT US
24954-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24954-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24954-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24954-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
24E507009G01		Lavatory Water Heater	B F GOODRICH	OH/REP/TEST	A300;A320	PLEASE CONTACT US
24E507040G01		Lavatory Water Heater	B F GOODRICH	OH/REP/TEST	B747;B757	PLEASE CONTACT US
24E507040G02		Lavatory Water Heater	B F GOODRICH	OH/REP/TEST	B747;B757	PLEASE CONTACT US
24E507040G03		Lavatory Water Heater	B F GOODRICH	OH/REP/TEST	B747;B757	PLEASE CONTACT US
24E507040G04		Lavatory Water Heater	B F GOODRICH	OH/REP/TEST	B747;B757	PLEASE CONTACT US
24E507040G05		Lavatory Water Heater	B F GOODRICH	OH/REP/TEST	B747;B757	PLEASE CONTACT US
250A200		Main Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2510-0007-01		Single Cavity Oven	AIRCRAFT PRODUCTS .	OH/REP/TEST	B737;B757	PLEASE CONTACT US
25101-A10C-2-C1		Single Autosyn Indicator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25101-A37B-1-B1		Single Autosyn Indicator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2515-2		DC Motor Rotary Actuator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
251A1510-3		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
25326-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25326-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25326-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25326-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25342-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25342-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25342-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25342-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25386-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25386-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25386-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25386-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25386-5		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25430135-02		Temperature Control Box	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25430135-03		Temperature Control Box	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25430135-06		Temperature Control Box	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25430135-07		Temperature Control Box	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25430135-08	695304-7	Temperature Control Box	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25430135-09	695304-8	Temperature Control Box	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25530562-01	695539-3	Oil Temperature Thermostat	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25530562-02	695539-4	Oil Temperature Thermostat	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25615-C29C-26-A3		Fuel Pressure Indicator	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
25730032-02		Shut Off Valve	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25730032-03		Shut Off Valve	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US

25730032-04		Shut Off Valve	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25730043-02		Shut Off Valve	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25730043-03	695748-15	Shut Off Valve	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25756-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25756-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25782-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25782-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25782-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25782-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
25B12-1-A		Generator Control Panel	ALLIED SIGNAL	OH/REP/TEST	GS111	PLEASE CONTACT US
25B12-3-B		Generator Control Unit	BENDIX	OH/REP/TEST	DC10	PLEASE CONTACT US
25B31-1-AM		DC Generator Control Unit	ALLIED SIGNAL	OH/REP/TEST	F27	PLEASE CONTACT US
25FWU/1/509		Failure Warning Unit	SMITHS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
25FWU/1/625		Failure Warning Unit	SMITHS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
2601042-3		Main Brake Assembly	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
2601042-4		Main Brake Assembly	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
2601042-5		Main Brake Assembly	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
2601181-1		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B727	PLEASE CONTACT US
2601182-5		Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	B727	PLEASE CONTACT US
2601182-6		Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	B727	PLEASE CONTACT US
2601225-1		Main Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
2601240-1		Main Brake Assembly	BENDIX	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
2601411-1		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	DC8	PLEASE CONTACT US
2601411-2		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	DC8	PLEASE CONTACT US
2601412-1		Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	DC8	PLEASE CONTACT US
2601412-2		Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	DC8	PLEASE CONTACT US
2601571-1	10-61063-8	Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2603561-10		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-11		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-12		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-13		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-14		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-15		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-16		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-3		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-4		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-5		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-50		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-51		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-52		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-7		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2603561-9		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2604561-1		Main Wheel Assembly	BENDIX	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2606671-1		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2606671-2		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US

2606671-3		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2606672-1		Main Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2606672-2		Main Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2606672-3		Main Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2606672-4		Main Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2606735-1		Nose Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B767	PLEASE CONTACT US
2606735-2		Nose Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B767	PLEASE CONTACT US
2606801-1		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	A300	PLEASE CONTACT US
2606801-2		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	A300	PLEASE CONTACT US
2606801-3		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	A300	PLEASE CONTACT US
2606801-4		Main Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	A300	PLEASE CONTACT US
2606802-3		Main Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	A300	PLEASE CONTACT US
2606802-4		Main Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	A300	PLEASE CONTACT US
2606802-5		Main Brake Assembly	ALLIED SIGNAL	OH/REP/TEST	A300	PLEASE CONTACT US
2607081-1		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2607081-2		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2607081-3		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
2607092-1		Brake Assembly	HONEYWELL	OH/REP/TEST	B767	PLEASE CONTACT US
2607092-2		Brake Assembly	HONEYWELL	OH/REP/TEST	B767	PLEASE CONTACT US
2607092-3		Brake Assembly	HONEYWELL	OH/REP/TEST	B767	PLEASE CONTACT US
2607092-4		Brake Assembly	HONEYWELL	OH/REP/TEST	B767	PLEASE CONTACT US
2607825-1		Nose Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2607825-2		Nose Wheel Assembly	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
2608811-3		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B767-300	PLEASE CONTACT US
2608811-5		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B767-300	PLEASE CONTACT US
2608812-10		Main Brake Assembly	HONEYWELL	OH/REP/TEST	B767	PLEASE CONTACT US
2608812-11		Main Brake Assembly	HONEYWELL	OH/REP/TEST	B767	PLEASE CONTACT US
2608812-6		Main Brake Assembly	HONEYWELL	OH/REP/TEST	B767	PLEASE CONTACT US
2608812-7		Main Brake Assembly	HONEYWELL	OH/REP/TEST	B767	PLEASE CONTACT US
2609801-1		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B737-400	PLEASE CONTACT US
2610181-2		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	A330;A340	PLEASE CONTACT US
2610181-3		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	A330;A340	PLEASE CONTACT US
2610181-4		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	A330;A340	PLEASE CONTACT US
2610181-5		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	A330;A340	PLEASE CONTACT US
2610181-6		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	A330;A340	PLEASE CONTACT US
2610485-1	90002021	Nose Wheel Assembly	ABSC	OH/REP/TEST	DO328	PLEASE CONTACT US
2610701-2	90002024	Main Wheel Assembly	ABSC	OH/REP/TEST	DO328	PLEASE CONTACT US
2612311-1		Main Wheel Assembly	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
2612312-1		Main Brake Assembly	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
26130010-01	695805-2	Shut Off Valve	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
26130010-01A		Shut Off Valve	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
26130011-01		Shut Off Valve	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2624T100-1		Load Limiter	TALLEY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2670112M1		Gear Door Modular Assembly	PARKER	OH/REP/TEST	B747;B757;TRIS	PLEASE CONTACT US
2-690012-5		NLG Actuator Assembly	DECOTO-DOWTY YAKIMA	OH/REP/TEST	CESS	PLEASE CONTACT US

2-690021-11		MLG Door Actuator Assembly	DOWTY YAKIMA	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
2690194M1		Accumulator	PARKER	OH/REP/TEST	F28	PLEASE CONTACT US
2-697		Brake Unit	GOODRICH	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
2-699		Brake Unit	GOODRICH	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
27-1-8101-000-401		Engine Mount Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
27-1-8101-000-405		Engine Mount Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
27-1-8127-003-901		Fuel Heater Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
27-1-8420-018-003		Swing Check Valve	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
27-1-8420-018-005		Swing Check Valve	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
27231317-01	697639-37	Flight Station Temperature Controller	SUNDSTRAND	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
27231318-01	697639-39	Cargo Compart Temperature Controller	SUNDSTRAND	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
27350-107	3-1599	Main Wheel Assembly	GOODRICH	OH/REP/TEST	BD700	PLEASE CONTACT US
273A2201-1		MLG Downlock Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
273A3610-1		Main Gear Shimmy Damper Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
273A3610-2		Main Gear Shimmy Damper Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
273A3610-3		Main Gear Shimmy Damper Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
273A3610-4		Main Gear Shimmy Damper Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
273A3610-5		Main Gear Shimmy Damper Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
27431466-01	697639-35	Low Limit Temperature Controller	SUNDSTRAND	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
274N1003-4		Valve Assembly	BOEING	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
274N1028-4		Valve Assembly	BOEING	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
274N1028-5		Valve Assembly	BOEING	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
274N1028-6		Valve Assembly	BOEING	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
274N1051-1		Valve Assembly	BOEING	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
274N1051-2		Valve Assembly	BOEING	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
274N1051-3		Valve Assembly	BOEING	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
27-510001-1		Engine 'W' Strut	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
27-510001-31		Engine Mount	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
27-510001-51		Engine Mount	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
275A1101-3		NLG Steering Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
275A1101-4		NLG Steering Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
275A1101-5		NLG Steering Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
275A1101-6		NLG Steering Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
275A1101-7		NLG Steering Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
275A1101-8		NLG Steering Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
27620-1		Emergency Wing Flap Brake	ABLE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
27620-2		Emergency Wing Flap Brake	ABLE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
27-680011-11		Fuel Heater	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
2810039-101	F61A0048	Swing Check Valve	PARKER	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
2830036-101		Flow Control Valve	PARKER	OH/REP/TEST	B757	PLEASE CONTACT US
286351005-1		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A300;A320	PLEASE CONTACT US
286351006-1		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A300;A320	PLEASE CONTACT US
286351007-1		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A300;A320	PLEASE CONTACT US
2-872-4		Brake Unit	GOODRICH	OH/REP/TEST	B727	PLEASE CONTACT US
289021122-1		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A340	PLEASE CONTACT US

289021122-2		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A340	PLEASE CONTACT US
289021122-3		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A340	PLEASE CONTACT US
28B135-126-A		AC Generator	ALLIED SIGNAL	OH/REP/TEST	GS1;HELI	PLEASE CONTACT US
28B135-133-A		AC Generator	ALLIED SIGNAL	OH/REP/TEST	GS1;HELI	PLEASE CONTACT US
28B135-29-A		AC Generator	ALLIED SIGNAL	OH/REP/TEST	GS1;HELI	PLEASE CONTACT US
28B141-17-C		AC Generator	ALLIED SIGNAL	OH/REP/TEST	F27	PLEASE CONTACT US
28B141-51-A		AC Generator	ALLIED SIGNAL	OH/REP/TEST	F27	PLEASE CONTACT US
28B141-9-A		AC Generator	ALLIED SIGNAL	OH/REP/TEST	F27	PLEASE CONTACT US
28B58-9-A		AC Generator	ALLIED SIGNAL	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
28B58-9-A		AC Generator	BENDIX	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
28B58-9-B		AC Generator	ALLIED SIGNAL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
28B58-9-B		AC Generator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
28B95-35-A		AC Generator	BENDIX	OH/REP/TEST	P3 ORION	PLEASE CONTACT US
28VS50C-3		Power Supply Silicon Rectification	TUNG SOL	OH/REP/TEST	B707	PLEASE CONTACT US
29255-10A-A17		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
29255-10A-A17/5072		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
29270-10A-A1		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
29270-10A-A1/5072		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
29270-10A-B1		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
29270-10A-B1/5072		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
29270-10A-B2		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
29600-3		Valve Assembly	VICKERS-STERER	OH/REP/TEST	F100	PLEASE CONTACT US
29680-1		Pressure Reducing Valve	VICKERS-STERER	OH/REP/TEST	F100	PLEASE CONTACT US
29680-2		Pressure Reducing Valve	VICKERS-STERER	OH/REP/TEST	F100	PLEASE CONTACT US
297-140		Liquid Container	GRIMES	OH/REP/TEST	BAE125;B707	PLEASE CONTACT US
297-200		Liquid Container	GRIMES	OH/REP/TEST	B747	PLEASE CONTACT US
29C(2)	53433-004	Inertia Switch	KIDDE GRAVINER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1		AC Generator	LELAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1D		AC Generator	LELAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1E		AC Generator	LELAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1F		AC Generator	SMITHS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1H		AC Generator	LELAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1J		AC Generator	SMITHS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1K		AC Generator	SMITHS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1L		AC Generator	SMITHS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM353C1P		AC Generator	LELAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
2CM63C8		APU Generator	LELAND	OH/REP/TEST	TBD	PLEASE CONTACT US
2CM9AAA6		Tachometer Generator	AMETEK	OH/REP/TEST	B707;B727;B737;B747	PLEASE CONTACT US
2CM9AAC6		Tachometer Generator	AMETEK	OH/REP/TEST	B707;B727;B737;B747	PLEASE CONTACT US
2CM9AAH4		Tachometer Generator	AMETEK	OH/REP/TEST	BAC111(CofC only);C130;L100	PLEASE CONTACT US
2CM9AAV6		Tachometer Generator	AMETEK	OH/REP/TEST	C130;L100;B707;B727;B737;B747	PLEASE CONTACT US
2CM9AAZ6		Tachometer Generator	AMETEK	OH/REP/TEST	C130;L100;B707;B727;B737;B747	PLEASE CONTACT US
2CM9ABE6		Tachometer Generator	AMETEK	OH/REP/TEST	SD360;DC9;DC10;MD80;MD83	PLEASE CONTACT US
2CM9ABH7		Tachometer Generator	AMETEK	OH/REP/TEST	SD360;DC9;DC10;MD80;MD83	PLEASE CONTACT US
2CM9ABK7		Tachometer Generator	AMETEK	OH/REP/TEST	B707;B727;B737;B747	PLEASE CONTACT US

2CM9ABY7		Tachometer Generator	AMETEK	OH/REP/TEST	B707;B727;B737;B747	PLEASE CONTACT US
2CM9ABZ7		Tachometer Generator	AMETEK	OH/REP/TEST	C130;L100;B707;B727;B737;B747	PLEASE CONTACT US
2CM9ACE7		Tachometer Generator	AMETEK	OH/REP/TEST	B707;B727;B737;C130;L100	PLEASE CONTACT US
2CM9ACF8		Tachometer Generator	AMETEK	OH/REP/TEST	C130;L100;B707;B727;B737;B747	PLEASE CONTACT US
2CM9ACH7		Tachometer Generator	AMETEK	OH/REP/TEST	C130;L100;B707;B727;B737;B747	PLEASE CONTACT US
2CM9ADB9		Tachometer Generator	AMETEK	OH/REP/TEST	C130;L100;B707;B727;B737;B747	PLEASE CONTACT US
2CM9ADE8		Tachometer Generator	AMETEK	OH/REP/TEST	C130;L100;B707;B727;B737;B747	PLEASE CONTACT US
2CM9ADT6		Tachometer Generator	AMETEK	OH/REP/TEST	C130;L100;B707;B727;B737;B747	PLEASE CONTACT US
2LA 002 427-03		Tow Park Light	HELLA	OH/REP/TEST	A300;A320	PLEASE CONTACT US
2LA0002607-03		Cargo Compartment Light	HELLA	OH/REP/TEST	TBD	PLEASE CONTACT US
2LA001624-00		Anti Collision Lamp	HELLA	OH/REP/TEST	HELI	PLEASE CONTACT US
2LA001625-07		Tail Light Assembly	HELLA	OH/REP/TEST	BAE146	PLEASE CONTACT US
2LA002431-00		Light Assembly	HELLA	OH/REP/TEST	BAE146;JETS	PLEASE CONTACT US
2LA002606-06		Inspection Light Assembly	HELLA	OH/REP/TEST	BAE146;JETS	PLEASE CONTACT US
2LA002607-35		Cargo Compartment Light	HELLA	OH/REP/TEST	BAE146;A300;A310;JETS	PLEASE CONTACT US
2LA002692-02		Dome Light	HELLA	OH/REP/TEST	A300;A310;A320	PLEASE CONTACT US
2LA002692-05		Dome Light	HELLA	OH/REP/TEST	BAE146	PLEASE CONTACT US
2LA003926-00		Tail Position Light	HELLA	OH/REP/TEST	A310	PLEASE CONTACT US
2LA003954-00		Wing Strobe Light	HELLA	OH/REP/TEST	A300;A310	PLEASE CONTACT US
2LA004794-00		Tail Position Light	HELLA	OH/REP/TEST	A310	PLEASE CONTACT US
2LA005308-01		Wing Strobe Light	HELLA	OH/REP/TEST	A320;A340	PLEASE CONTACT US
2LA005308-05		Wing Strobe Light	HELLA	OH/REP/TEST	A320;A340	PLEASE CONTACT US
2R3052	S332N305	Back Pressure Regulating Valve	CRISSAIR	OH/REP/TEST	B757	PLEASE CONTACT US
2R3088-1		Restrictor Valve	CRISSAIR	OH/REP/TEST	B737	PLEASE CONTACT US
2S2068		Swing Check Valve	CRISSAIR	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2S2072		Swing Check Valve	CRISSAIR	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2S2474L		Swing Check Valve	CRISSAIR	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
2S2566		Swing Check Valve	CRISSAIR	OH/REP/TEST	B727;B737	PLEASE CONTACT US
2S2794		Check Valve	CRISSAIR	OH/REP/TEST	A300	PLEASE CONTACT US
2S2794-1		Check Valve	CRISSAIR	OH/REP/TEST	A300	PLEASE CONTACT US
2SV141		Shuttle Valve	GAR-KENYON CONTROLS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
30-0127-1		Tail Position Nav Light	GRIMES	OH/REP/TEST	B727;B737	PLEASE CONTACT US
30-0127-11		Tail Position Nav Light	GRIMES	OH/REP/TEST	B727;B737	PLEASE CONTACT US
30-0127-13		Tail Position Nav Light	GRIMES	OH/REP/TEST	B727;B737	PLEASE CONTACT US
30-0127-5		Tail Position Nav Light	GRIMES	OH/REP/TEST	B727;B737	PLEASE CONTACT US
30-0127-7		Tail Position Nav Light	GRIMES	OH/REP/TEST	B727;B737	PLEASE CONTACT US
30-0127-9		Tail Position Nav Light	GRIMES	OH/REP/TEST	B727;B737	PLEASE CONTACT US
30-0432-1		Emergency Egress Light	GRIMES	OH/REP/TEST	B707;B737	PLEASE CONTACT US
30-0446-7		Strobe Light Assembly	GRIMES	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
30-0447-1		Wing Illumination Light	GRIMES	OH/REP/TEST	GS1	PLEASE CONTACT US
30-0447-2		Wing Illumination Light	GRIMES	OH/REP/TEST	GS1	PLEASE CONTACT US
30-0516-1		Tail Position Light	GRIMES	OH/REP/TEST	BAE125	PLEASE CONTACT US
30-0516-3		Tail Position Light	GRIMES	OH/REP/TEST	BAE125	PLEASE CONTACT US
30-0516-5		Tail Position Light	GRIMES	OH/REP/TEST	BAE125	PLEASE CONTACT US
30-0516-7		Tail Position Light	GRIMES	OH/REP/TEST	BAE125	PLEASE CONTACT US

30-0627-1		Wing Position Light	GRIMES	OH/REP/TEST	A300;A310;B767	PLEASE CONTACT US
30-0627-2		Wing Position Light	GRIMES	OH/REP/TEST	A300;A310;B767	PLEASE CONTACT US
30-0627-3		Wing Position Light	GRIMES	OH/REP/TEST	A300;A310;B767	PLEASE CONTACT US
30-0627-4		Wing Position Light	GRIMES	OH/REP/TEST	A300;A310;B767	PLEASE CONTACT US
30-0627-5		Wing Position Light	GRIMES	OH/REP/TEST	A300;A310;B767	PLEASE CONTACT US
30-0627-6		Wing Position Light	GRIMES	OH/REP/TEST	A300;A310;B767	PLEASE CONTACT US
30-0837-1		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-11		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-13		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-15		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-17		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-19		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-21		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-23		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-25		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-27		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-29		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-3		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-31		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-33		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-35		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-37		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-39		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-41		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-43		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-45		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-47		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-5		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-7		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0837-9		Anticollision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-0849-1		Anticollision Strobe Light	GRIMES	OH/REP/TEST	TBD	PLEASE CONTACT US
30-0863-3		Wing Position Flashtube Light	GRIMES	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
30-0863-4		Wing Position Flashtube Light	GRIMES	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
30-0881-11		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	A310	PLEASE CONTACT US
30-0881-3		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	A310	PLEASE CONTACT US
30-0881-5		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	A310	PLEASE CONTACT US
30-0881-7		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	A310	PLEASE CONTACT US
30-0881-9		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	A310	PLEASE CONTACT US
30-1033-1		Anti Collision Strobe Light	GRIMES	OH/REP/TEST	SD330	PLEASE CONTACT US
30-1033-5		Anti Collision Strobe Light	GRIMES	OH/REP/TEST	SD330	PLEASE CONTACT US
30-1098-1		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	MD80;MD83;MD87;MD88	PLEASE CONTACT US
30-1099-1		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	MD80;MD83;MD87;MD88	PLEASE CONTACT US
30-1136-1		Navigational Strobe Light	GRIMES	OH/REP/TEST	TBD	PLEASE CONTACT US
30-1192-5		Anti-Collision Light	GRIMES	OH/REP/TEST	TBD	PLEASE CONTACT US
30-1192-7		Anti-Collision Light	GRIMES	OH/REP/TEST	TBD	PLEASE CONTACT US

30-1192-9		Anti-Collision Light	GRIMES	OH/REP/TEST	TBD	PLEASE CONTACT US
30-1329-1		Navigational Strobe Light	GRIMES	OH/REP/TEST	TBD	PLEASE CONTACT US
30-1401-1		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-1401-11		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-1401-13		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-1401-15		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-1401-3		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-1401-5		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-1401-7		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-1401-9		Anti-Collision Strobe Light	GRIMES	OH/REP/TEST	BAE146;B727;B737;B757	PLEASE CONTACT US
30-1588-5		Navigational Light	GRIMES	OH/REP/TEST	B767	PLEASE CONTACT US
30-1588-6		Navigational Light	GRIMES	OH/REP/TEST	B767	PLEASE CONTACT US
30-162		Main Brake Assembly	CLEVELAND WHEEL & BR	OH/REP/TEST	KING AIR 200	PLEASE CONTACT US
30-1669-1		Fwd Door Slide Light	GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
30-1669-2		Fwd Door Slide Light	GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
30-1670-1		Centre Door Slide Light	GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
30-1670-2		Centre Door Slide Light	GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
30-1671-1		Emergency Door Slide Light	GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
30-1671-2		Emergency Door Slide Light	GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
30-1672-1		AFT Door Slide Light	GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
30-1672-2		AFT Door Slide Light	GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
30-1691-1		Wing Anticollision Light	GRIMES	OH/REP/TEST	B757;B767	PLEASE CONTACT US
30-1691-2		Wing Anticollision Light	GRIMES	OH/REP/TEST	B757;B767	PLEASE CONTACT US
30-1691-3		Wing Anticollision Light	GRIMES	OH/REP/TEST	B757;B767	PLEASE CONTACT US
30-1691-4		Wing Anticollision Light	GRIMES	OH/REP/TEST	B757;B767	PLEASE CONTACT US
30-1994-1		Anti-Collision Lamp	GRIMES	OH/REP/TEST	GS4	PLEASE CONTACT US
30-1994-3		Anti-Collision Lamp	GRIMES	OH/REP/TEST	GS4	PLEASE CONTACT US
30-1994-5		Anti-Collision Lamp	GRIMES	OH/REP/TEST	GS4	PLEASE CONTACT US
30-242		Main Brake Assembly	CLEVELAND/PARKER	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
304-334		Steel Heat Sink	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
30678-17		Torque Actuator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
30678-18		Torque Actuator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3078-1	695906-1	Pressure Switch	ITT	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
30B24-1-A		DC Generator	BENDIX	OH/REP/TEST	HELI	PLEASE CONTACT US
30C17		Fuel Solenoid Valve	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
30E01-1-A		DC Generator	BENDIX	OH/REP/TEST	HELI	PLEASE CONTACT US
30E02-21-G		DC Generator	ALLIED SIGNAL	OH/REP/TEST	F27	PLEASE CONTACT US
30E02-27-A		DC Generator	ALLIED SIGNAL	OH/REP/TEST	GS1	PLEASE CONTACT US
30E20-11-C		Starter Generator	ALLIED SIGNAL	OH/REP/TEST	GS1	PLEASE CONTACT US
3-1070		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B727	PLEASE CONTACT US
310A1020-1		Engine Mount (Associated Fixtures And Fittings)	BOEING	NDT ONLY	CFM-56	PLEASE CONTACT US
310A1020-19		Engine Mount (Associated Fixtures And Fittings)	BOEING	NDT ONLY	CFM-56	PLEASE CONTACT US
310A1020-3		Engine Mount (Associated Fixtures And Fittings)	BOEING	NDT ONLY	CFM-56	PLEASE CONTACT US
3-1104		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B707	PLEASE CONTACT US
3-111794		Reservoir Drain Valve	PARKER	OH/REP/TEST	B727;B737;B747;B757;B767	PLEASE CONTACT US

3-1197		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	DHC-6	PLEASE CONTACT US
3-1209-2	101-8015-3	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	BEECH	PLEASE CONTACT US
31220-002		Generator	LEAR SIEGLER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
31220-003		Generator	LEAR SIEGLER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
31220-004	695703-2	Generator	LEAR SIEGLER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3-1251		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B707	PLEASE CONTACT US
3-1306-1	10-61287-21	Main Wheel Assembly	GOODRICH	OH/REP/TEST	B727	PLEASE CONTACT US
3-1311-3		MLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1319-1		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1319-2		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1341-1	101-8001-47	Main Wheel Assembly	GOODRICH	OH/REP/TEST	BEECH200/300	PLEASE CONTACT US
3-1349.OPT1		NLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1349.OPT2		NLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1349.OPT3		NLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1349.OPT4		NLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1349.OPT5		NLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1362		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	DHC-5	PLEASE CONTACT US
3-1365		MLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1365-1		MLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1369		Main Wheel Assembly	GOODRICH	OH/REP/TEST	DHC-5	PLEASE CONTACT US
3-1375		MLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1375-1		MLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1375-2		MLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1375-3		MLG Wheel Assembly	GOODRICH	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3-1395		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B727	PLEASE CONTACT US
3-1399-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS 650	PLEASE CONTACT US
3-1399-3		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS 650	PLEASE CONTACT US
3-1399-4		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS 650	PLEASE CONTACT US
3-1399-5	9914136-7	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS 650	PLEASE CONTACT US
3-1399-6		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS 650	PLEASE CONTACT US
3-1403		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION	PLEASE CONTACT US
3-1414	10-61287-24	Main Wheel Assembly	GOODRICH	OH/REP/TEST	B727	PLEASE CONTACT US
314160-2		Hydraulic Reservoir Pressure Regulator	CRANE HYDRO-AIRE	OH/REP/TEST	B707;B727;B737;DC10	PLEASE CONTACT US
3-1418	9914069-2	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 500/650	PLEASE CONTACT US
3-1428		Main Wheel Assembly	GOODRICH	OH/REP/TEST	B757	PLEASE CONTACT US
3-1435-2		Main Wheel Assembly	GOODRICH	OH/REP/TEST	DHC-8	PLEASE CONTACT US
3-1435-3		Main Wheel Assembly	GOODRICH	OH/REP/TEST	DHC-8	PLEASE CONTACT US
3-1435-4		Main Wheel Assembly	GOODRICH	OH/REP/TEST	DHC-8	PLEASE CONTACT US
3-1438	10-61063-23	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
3-1438-1	10-61063-25	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
3-1439-5	10-61819-37	Main Wheel Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
3-1439-6	10-61819-38	Main Wheel Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
3-1481	101-8026-5	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	BEECH200/300	PLEASE CONTACT US
3-1484	10-62174-1	Main Wheel Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
3-1490-1	9912222-11	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 500/550/560	PLEASE CONTACT US

3-1491		Main Wheel Assembly	GOODRICH	OH/REP/TEST	A320	PLEASE CONTACT US
3-1491-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	A320	PLEASE CONTACT US
3-1491-2		Main Wheel Assembly	GOODRICH	OH/REP/TEST	A320	PLEASE CONTACT US
3-1518-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	ATR42	PLEASE CONTACT US
3-1518-2		Main Wheel Assembly	GOODRICH	OH/REP/TEST	ATR42	PLEASE CONTACT US
3-1527-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS 525	PLEASE CONTACT US
3-1527-2		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS 525	PLEASE CONTACT US
3-1535	S294W522-320	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B777	PLEASE CONTACT US
3-1537		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION X	PLEASE CONTACT US
3-1537-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION X	PLEASE CONTACT US
3-1537-2		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION X	PLEASE CONTACT US
3-1545-1	6632401000-001	Main Wheel Assembly	GOODRICH	OH/REP/TEST	LEARJET 45 FALC2000	PLEASE CONTACT US
3-1546		Main Wheel Assembly	GOODRICH	OH/REP/TEST	A340	PLEASE CONTACT US
3-1550		Main Wheel Assembly	GOODRICH	OH/REP/TEST	EMB135;EMB145	PLEASE CONTACT US
3-1550-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	EMB135;EMB145	PLEASE CONTACT US
3-1551		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	EMB135;EMB145	PLEASE CONTACT US
3-1558	10-62237-7	Main Wheel Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
3-1559	10-62237-10	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B737	PLEASE CONTACT US
3-1560	GW313-1100-1	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	BD700	PLEASE CONTACT US
3-1562		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 550 BRAVO	PLEASE CONTACT US
3-1563		Main Wheel Assembly	GOODRICH	OH/REP/TEST	BD700	PLEASE CONTACT US
3-1563-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	BD700	PLEASE CONTACT US
3-1571-1	9912487-6	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION	PLEASE CONTACT US
3-1571-2	9912487-9	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION	PLEASE CONTACT US
3-1571-3	9912487-10	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION	PLEASE CONTACT US
3-1571-4		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 560-XL	PLEASE CONTACT US
3-1571-5		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 560-XL	PLEASE CONTACT US
3-1571-6	9912487-11	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS CITATION 560-XL	PLEASE CONTACT US
3-1576		Main Wheel Assembly	GOODRICH	OH/REP/TEST	RAYTHEON 390 (PREMIER 1)	PLEASE CONTACT US
3-1586		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	RAYTHEON 390 (PREMIER 1)	PLEASE CONTACT US
3-1590		Main Wheel Assembly	GOODRICH	OH/REP/TEST	EMB145	PLEASE CONTACT US
3-1599	GW313-1100-7 (27350-107)	Main Wheel Assembly	GOODRICH	OH/REP/TEST	BD700	PLEASE CONTACT US
3-1601-2	9912743-4	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESSNA CITATION JET 11	PLEASE CONTACT US
3-1601-3	9912743-6	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESSNA CITATION JET 11	PLEASE CONTACT US
3-1607	9912561-4	Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESSNA ENCORE;CJ3	PLEASE CONTACT US
3-1607-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESSNA ENCORE;CJ3	PLEASE CONTACT US
3-1609-1		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CHAL300;BD100	PLEASE CONTACT US
3-1610		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	CHAL300;BD100	PLEASE CONTACT US
3-1610-1	415-134-1	Nose Wheel Assembly	GOODRICH	OH/REP/TEST	CHAL300;BD100	PLEASE CONTACT US
3-1622		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	EMB135;EMB145	PLEASE CONTACT US
3-1640		Main Wheel Assembly	GOODRICH	OH/REP/TEST	CESS-MUSTANG	PLEASE CONTACT US
3-1641		Main Wheel Assembly	GOODRICH	OH/REP/TEST	EMB-ERJ145	PLEASE CONTACT US
3-1642		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	CESS-MUSTANG	PLEASE CONTACT US
3185800-6		L/E Slat Actuator Assy	MOOG	OH/REP/TEST	DC10	PLEASE CONTACT US
3189690-3		Actuator Assembly	MOOG	OH/REP/TEST	DC10	PLEASE CONTACT US

32005-000		Tacho Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	DHC-6;HELI	PLEASE CONTACT US
32005-002		Tacho Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
32005-007		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	DHC-6	PLEASE CONTACT US
32005-008		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	HELI	PLEASE CONTACT US
32005-023		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	BELL206	PLEASE CONTACT US
32005-025		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	HELI	PLEASE CONTACT US
32005-026		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	HELI	PLEASE CONTACT US
32005-030		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	BELL206	PLEASE CONTACT US
32005-034		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	HELI	PLEASE CONTACT US
32005-037		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	BELL212;BELL412	PLEASE CONTACT US
320115C		Butterfly Shut Off Valve	WHITTAKER	OH/REP/TEST	B727;B737;DC9;MD80;MD83	PLEASE CONTACT US
3202096-2		Recirculation Air Check Valve	HONEYWELL	OH/REP/TEST	B737;B757;B767	PLEASE CONTACT US
3202097-2		Recirculation Air Check Valve	HONEYWELL	OH/REP/TEST	B737;B757;B767	PLEASE CONTACT US
3205KGA/2		Tachometer Generator	SMITHS	OH/REP/TEST	SA341 GAZZELLE	PLEASE CONTACT US
3207KGA/1		Tachometer Generator	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
3213722-1-1		Regulating Valve	GARRETT	OH/REP/TEST	C130	PLEASE CONTACT US
3213722-2-1	697638-3	Regulating Valve	GARRETT	OH/REP/TEST	C130	PLEASE CONTACT US
3213722-3-1		Regulating Valve	GARRETT	OH/REP/TEST	C130	PLEASE CONTACT US
3213722-5-1	697638-9	Regulating Valve	GARRETT	OH/REP/TEST	C130	PLEASE CONTACT US
3213722-6-1		Regulating Valve	GARRETT	OH/REP/TEST	C130	PLEASE CONTACT US
32164-007		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	CONV;ELEC	PLEASE CONTACT US
321942-1-1		Butterfly Shutoff Valve	HONEYWELL	OH/REP/TEST	B727;B737;A300;DC8	PLEASE CONTACT US
32-2684-002		Shut Off Valve	JANITROL	OH/REP/TEST	TBD	PLEASE CONTACT US
32-2684-003		Shut Off Valve	JANITROL	OH/REP/TEST	B707;B737;B747	PLEASE CONTACT US
32-2861-001		Pneumatic Air Shutoff Valve	JANITROL	OH/REP/TEST	B727;B737	PLEASE CONTACT US
32355-1		DC Electric Motor	AIRESEARCH	OH/REP/TEST	TBD	PLEASE CONTACT US
3260011-0101		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3260011-0101/5072		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
32706-1		DC Aircraft Motor	AIRESEARCH	REP/TEST	C130;L100	PLEASE CONTACT US
3283-1	S271N303-2	Toggle Valve	PNEUDRAULICS	OH/REP/TEST	B757	PLEASE CONTACT US
3290290-1-1		2 1/2" Diam Butterfly Shutoff Valve	ALLIED SIGNAL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
32B50-12A		Inverter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
32B50-12AU		Inverter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
32B50-19B		Inverter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
32B50-21A		Inverter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
32B56-11-A		Inverter	BENDIX	OH/REP/TEST	GS1	PLEASE CONTACT US
32B56-18-A		Inverter	BENDIX	OH/REP/TEST	GS1	PLEASE CONTACT US
32C171		Check Valve	ALLEN	OH/REP/TEST	B747;B757;B767	PLEASE CONTACT US
32D26		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	DC10;MD83	PLEASE CONTACT US
32D37		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	DC10;MD83	PLEASE CONTACT US
3302196-13		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3302196-19		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3303591-1		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3303591-3		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3303595-1		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US

3303595-5		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3316498-1		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3316498-7		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3330865-7		Hydraulic Reservoir	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3330869-9		Hydraulic Reservoir	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3330873-7		Hydraulic Reservoir	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3343503-1		NLG Steering Control Valve	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
339097-11		Main Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
339814-601		Elevator Control Booster	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
339814-604		Elevator Control Booster	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
34.A1.111		Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	F27	PLEASE CONTACT US
340015-1		Rotary Selector Valve	WHITTAKER CONTROLS	OH/REP/TEST	B767	PLEASE CONTACT US
3400770-1		NLG Drag Strut Actuator Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3400770-3		NLG Drag Strut Actuator Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3400770-5		NLG Drag Strut Actuator Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3400770-7		NLG Drag Strut Actuator Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3400770-9		NLG Drag Strut Actuator Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3401095-11		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3402292-1		Generator Control Panel	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3408-12	695762-3	Ramp Manifold Valve	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3408-8		Ramp Manifold Valve	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
345726-7		NLG Drag Brace Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
345726-8		NLG Drag Brace Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
35-055	6781568	Solenoid Operated Shutoff Valve	CRANE HYDRO-AIRE	OH/REP/TEST	C130;CONV;ELEC	PLEASE CONTACT US
351485-3		Aileron Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3515000-135		Float Switch	FLIGHT REFUELLING	OH/REP/TEST	F100	PLEASE CONTACT US
354148-3		Aileron Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
354153-1		Rudder Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
354153-601		Rudder Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
355390-3		Gear Box Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3567609-3703	7609-37-M5-2	Autosyn Pressure Transmitter	BENDIX/HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3567709-7201	7709-72-A5-2	Pressure Transmitter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
3567709-7202	7709-72-B8-1	Pressure Transmitter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
3571220-5002		Dual Autosyn Synchro Indicator	ALLIED SIGNAL	OH/REP/TEST	TBD	PLEASE CONTACT US
358800-1		NLG Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
358800-5		NLG Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
358800-9		NLG Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3605812-1		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	B727;B737	PLEASE CONTACT US
36200-1C-A1		Power Failure Indicator	ALLIED SIGNAL	OH/REP/TEST	F27;HELI	PLEASE CONTACT US
363498-1		Elevator Control Booster	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-10		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-11		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-12		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-13		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-14		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US

363576-15		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-17		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-2		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-5		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-6		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-7		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363576-9		Door Uplock Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363590-1A		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363590-5		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
363590-7		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
364653-2A		NLG Strut Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
364697-1		Rudder Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
36751-1		Aircraft Direct Current Motor		OH/REP/TEST	C130;L100	PLEASE CONTACT US
36843-2		DC Motor Assembly	HONEYWELL	OH/REP/TEST	TBD	PLEASE CONTACT US
370438-1		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
370438-21		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
370442-1		MLG Torque Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
370749-1		Cylinder Assy AFT Cargo Door	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
370750-1		Ramp Cylinder Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
370751-1		Piston Rod Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
371671-1		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
371689-11		NLG Drag Brace Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
371689-12		NLG Drag Brace Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
371689-7		NLG Drag Brace Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
371689-8		NLG Drag Brace Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
371999-3		Rudder Pedal Assembly	LOCKHEED	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
372021-11		Rudder Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
372021-3		Rudder Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
372021-5		Rudder Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
372021-7		Rudder Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
373531-1		NLG Steering Control Valve	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
373531-3		NLG Steering Control Valve	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
373531-5		NLG Steering Control Valve	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
373531-7		NLG Steering Control Valve	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
374455-1		Aileron Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
374455-2		Aileron Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
374455-3		Aileron Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
374455-7		Aileron Booster Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
374461-11		Elevator Control Booster	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
374461-5		Elevator Control Booster	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
374461-601		Elevator Control Booster	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
374461-605		Elevator Control Booster	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3755-2		Actuator	JANITROL AERO DIV	OH/REP/TEST	B737;B747	PLEASE CONTACT US
386023-9		Main Wheel Assembly	ABSC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
388058-1		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US

388058-19		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388058-9		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388064-1		MLG Torque Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388064-3		MLG Torque Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388067-7		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388067-9		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388068-1		Lower Torque Arm	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388068-3		Lower Torque Arm	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388068-5		Lower Torque Arm	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388071-3		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
388074-11		Piston Assembly	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
38E01-1-A		Safety Valve	LUCAS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
38E01-7-A		Safety Valve	LUCAS	OH/REP/TEST	GS1	PLEASE CONTACT US
38E48-8A		Air Check Valve	LUCAS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
38E48-8B		Air Check Valve	LUCAS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
38E48-8C		Air Check Valve	LUCAS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
38E48-8D		Air Check Valve	LUCAS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
38E63-12A		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F50	PLEASE CONTACT US
38E63-12B		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F50	PLEASE CONTACT US
38E63-12C		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F50	PLEASE CONTACT US
38E63-14A		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
38E63-1B		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
38E63-2B		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
38E63-3B		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
38E63-3C		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
38E63-4A		Ejector Distributing Valve	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
38E73-4A		Air Control Valve Assy	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3907-1K-A1-1		Turn & Slip Indicator	BENDIX	OH/REP/TEST	HS748	PLEASE CONTACT US
3907-1M-A1-1		Turn & Slip Indicator	BENDIX	OH/REP/TEST	HS748	PLEASE CONTACT US
39-075	697397-3	Dual Pressure Control Valve	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
39-075A	697397-1	Dual Pressure Control Valve	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3919-1AJ-C1-1		Turn & Slip Indicator	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
392678-1-1		Shut Off Regulator	HONEYWELL	TEST ONLY	B737	PLEASE CONTACT US
392678-3-1		Shut Off Regulator	HONEYWELL	TEST ONLY	B737	PLEASE CONTACT US
393081-501		Fuel Quantity Totalizer Indicator	SIMMONDS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
393084-04359		Liquid Quantity Indicator	B F GOODRICH/SIMM	OH/REP/TEST	B737	PLEASE CONTACT US
393084-11358		Lox Quantity Indicator	SIMMONDS PRECISION	OH/REP/TEST	C130;L100	PLEASE CONTACT US
393090-501		Primary Fuel Qty Indicator	SIMMONDS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
393090-503		Primary Fuel Qty Indicator	SIMMONDS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
3932-1AG-A1-1		Turn & Slip Indicator	BENDIX	OH/REP/TEST	B727;B737	PLEASE CONTACT US
3932-1AG-B1-1		Turn & Slip Indicator	BENDIX	OH/REP/TEST	B727;B737	PLEASE CONTACT US
3934-1AG-B1-1		Turn And Slip Indicator	BENDIX	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
396175-11		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
396175-17		NLG Strut Assembly	DOWTY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
396308-1-1		B/A Shutoff And Flow Control Valve	ALLIED SIGNAL	OH/REP/TEST	C130;L100	PLEASE CONTACT US

396308-2-1		B/A Shutoff And Flow Control Valve	ALLIED SIGNAL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
396308-2-2		B/A Shutoff And Flow Control Valve	ALLIED SIGNAL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
396308-3-1		B/A Shutoff And Flow Control Valve	ALLIED SIGNAL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
39750-4		Electromech Rotary Actuator	AIRESEARCH	OH/REP/TEST	B707	PLEASE CONTACT US
398654-1-1		Butterfly Shutoff Valve	GARRETT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
398654-1-2		Butterfly Shutoff Valve	GARRETT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
398654-1-3		Butterfly Shutoff Valve	GARRETT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
398654-1-4		Butterfly Shutoff Valve	GARRETT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3-991-3		Nose Wheel Assembly	GOODRICH	OH/REP/TEST	B707	PLEASE CONTACT US
3A004		Pressure Reducing Valve	ARKWIN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3A016	697234-3	Pressure Reducing Valve	ARKWIN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3S2060DC102B1		Generator Control Panel	EDMOND SCIENTIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
3S2060DC102D1		Generator Control Panel	GENERAL ELECTRIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
3S2060DR113A1		Voltage Regulator	GENERAL ELECTRIC	OH/REP/TEST	C130;L100;CONV	PLEASE CONTACT US
40001-003	672435-117	Power Steering Valve	SARGENT	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
40001-004	672435-121	Power Steering Valve	SARGENT	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
40001-005	672435-127	Power Steering Valve	SARGENT	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
40-0117-1		Tandem Oscillating Light	GRIMES	OH/REP/TEST	BAE125	PLEASE CONTACT US
40057-1		Fuel Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
4-013-01		Dimmer Unit	ELDEC CORP.	OH/REP/TEST	BAE146;TRIS	PLEASE CONTACT US
4-013-02		Dimmer Unit	ELDEC CORP.	OH/REP/TEST	BAE146;TRIS	PLEASE CONTACT US
4-013-03		Dimmer Unit	ELDEC CORP.	OH/REP/TEST	BAE146;TRIS	PLEASE CONTACT US
4-013-04		Dimmer Unit	ELDEC CORP.	OH/REP/TEST	BAE146;TRIS	PLEASE CONTACT US
40-2		Landing Gear Motor	ELECTRO-MECH INC	OH/REP/TEST	TBD	PLEASE CONTACT US
40-202		Wheel Assembly	CLEVELAND	OH/REP/TEST	CESS CITATION 552 & S550	PLEASE CONTACT US
40-203	040-20300	Main Wheel Assembly	PARKER	OH/REP/TEST	KING AIR 200	PLEASE CONTACT US
40-204		Wheel Assembly	CLEVELAND	OH/REP/TEST	TBD	PLEASE CONTACT US
402306-3		NLG Steering Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
402306-5		NLG Steering Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
402306-7		NLG Steering Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
40250-10030		Brake Metering Valve Assembly	KAYABA	OH/REP/TEST	B757	PLEASE CONTACT US
40-289		Wheel Assembly	CLEVELAND	OH/REP/TEST	BEECH SK B200 AIR200	PLEASE CONTACT US
40-412		Main Wheel Assembly	CLEVELAND/PARKER	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
40-413		Nose Wheel Assembly	CLEVELAND/PARKER	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
40-424		Wheel Assembly	CLEVELAND	OH/REP/TEST	PILATUS PC-12	PLEASE CONTACT US
40-587		Wheel Speed Transducer	CRANE HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
40-6		Landing Gear Motor	ELECTRO-MECH INC	OH/REP/TEST	TBD	PLEASE CONTACT US
40600-1		Anti-Collision Light	GRIMES	OH/REP/TEST	TBD	PLEASE CONTACT US
40-621	697396-1	Wheel Speed Transducer	CRANE HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
40-621-1		Wheel Speed Transducer	CRANE HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
40-817	10-61093-181	Wheel Speed Transducer	CRANE HYDRO-AIRE	OH/REP/TEST	B737	PLEASE CONTACT US
4085992-1		Aircraft Bomb Rack	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
409-0001-1		Beverage Maker	B/E AEROSPACE	OH/REP/TEST	B757	PLEASE CONTACT US
40D830-3	695813-1	Bleed Check Valve	WESTON	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
411000-1		Suction Boost Hydraulic Pump	ROPER AVIATION	OH/REP/TEST	C130;L100	PLEASE CONTACT US

411000-2		Suction Boost Hydraulic Pump	ROPER AVIATION	OH/REP/TEST	C130;L100	PLEASE CONTACT US
411000-2	695545-5	Suction Boost Hydraulic Pump	ROPER AVIATION	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
411000-4	695545-5	Suction Boost Hydraulic Pump	ROPER AVIATION	OH/REP/TEST	C130;L100	PLEASE CONTACT US
411-11D-11		Vacuum Actuated Switch	MELETRON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
411-31-18	695345	Vacuum Actuated Switch	MELETRON	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
411600-1		Oil Tank Relief Valve	ACCESSORY PRODUCTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
411600-3	697218-1	Oil Tank Relief Valve	ACCESSORY PRODUCTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4-156-51	695699-1	Fuel Vent Valve	EDMOND SCIENTIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
416-0001-35		Coffee Maker	AIRCRAFT PRODUCTS .	OH/REP/TEST	B737;B757;DC10	PLEASE CONTACT US
416-0001-9		Coffee Maker	AIRCRAFT PRODUCTS .	OH/REP/TEST	B737;B757;DC10	PLEASE CONTACT US
4163DA	10-60598-1	Hydraulic Control Valve	SARGENT CONTROLS	OH/REP/TEST	B737	PLEASE CONTACT US
42023-01	PMP05VC-060-01	Motor Driven Hydraulic Pump	ABEX	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
42-041		Anti Skid Field Tester	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
42-041-1		Anti Skid Field Tester	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4205-002-000		Cyclic De-Icing Switch	NORMALAIR-GARRETT	OH/REP/TEST	F27	PLEASE CONTACT US
4205-003-000		Cyclic De-Icing Switch	NORMALAIR-GARRETT	OH/REP/TEST	F27	PLEASE CONTACT US
42075258-11		Motor Assembly	SAWYER IND.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
421-0001-1		Water Heater	GRIMES	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
42582-1		Program Position Indicator	AIRESEARCH	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
42800-7		Control Surface Damper	STERER	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
42800-9		Control Surface Damper	STERER	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
42895A		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42895A16870		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42895A17-16870		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42895A3		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42895A3-16870		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42895A5		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42895A5-16870		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42895A7		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42895A7-16870		Tandem Oscillating Light	GRIMES	OH/REP/TEST	F28;VISC	PLEASE CONTACT US
42D107A1		Differential Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B737	PLEASE CONTACT US
42D109-1A		Differential Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	MD83	PLEASE CONTACT US
42D110		Differential Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	MD83	PLEASE CONTACT US
42D223		Differential Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	TBD	PLEASE CONTACT US
42D275		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B727	PLEASE CONTACT US
42D275-1		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B727;B737	PLEASE CONTACT US
42D49C		Pressure Switch	CUSTOM CONTROL SENS.	OH/REP/TEST	B707;B737	PLEASE CONTACT US
42E00-2-C		Electronic De-Icer Timer	GOODRICH-LUCAS	OH/REP/TEST	F27;FH227	PLEASE CONTACT US
42E02-11-C		Electronic De-Icer Timer	GOODRICH-LUCAS	OH/REP/TEST	F27;FH227	PLEASE CONTACT US
42E06-17-A		Cyclic De Icing Switch	BENDIX	OH/REP/TEST	HS748	PLEASE CONTACT US
42E06-17-B		Cyclic De Icing Switch	BENDIX	OH/REP/TEST	HS748	PLEASE CONTACT US
42E13-17B		De-Icer Timer	BENDIX	OH/REP/TEST	TBD	PLEASE CONTACT US
42G114-1		Gage Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	MD83	PLEASE CONTACT US
42G304		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	MD83	PLEASE CONTACT US
4315DA	10-3205-2	Brake Metering Valve	SARGENT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US

43325-16870		Anti-Collision Lamp	GRIMES	OH/REP/TEST	VC10	PLEASE CONTACT US
4344D1-3		Screw Assembly (Outboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4344D2-1		Screw & Yoke Assembly	SARGENT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
4344D2-2		Screw & Yoke Assembly	SARGENT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
4344D2-3		Screw & Yoke Assembly	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4344D2-4		Screw & Yoke Assembly	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4344EA-1		Wing Flap Actuator Assembly (Outboard)	SARGENT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
4344EA-2		Wing Flap Actuator Assembly (Inboard)	SARGENT	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
4344EA-3		Wing Flap Actuator Assembly (Outboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4344EA-4		Wing Flap Actuator Assembly (Inboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4389H		Change Over Valve Assembly	FAIREY	OH/REP/TEST	F100	PLEASE CONTACT US
4391H1		Bypass Valve Assembly	FAIREY	OH/REP/TEST	F100	PLEASE CONTACT US
440-0001-1		Coffee Maker	AIRCRAFT PRODUCTS LTD	OH/REP/TEST	B737	PLEASE CONTACT US
440-0001-3		Coffee Maker	AIRCRAFT PRODUCTS LTD	OH/REP/TEST	B737	PLEASE CONTACT US
44400A		Anti-Collision Lamp	GRIMES	OH/REP/TEST	VC10	PLEASE CONTACT US
44E03-1-A		Vapor Filter	B F GOODRICH	OH/REP/TEST	F27	PLEASE CONTACT US
44E03-1B		Vapor Filter	GOODRICH	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
44E06-1A		Water Separator And Filter	LUCAS	OH/REP/TEST	DHC-6;DHC-7	PLEASE CONTACT US
44E06-1B		Water Separator And Filter	LUCAS	OH/REP/TEST	DHC-6;DHC-7	PLEASE CONTACT US
44E06-2A		Water Separator And Filter	LUCAS	OH/REP/TEST	DHC-6;DHC-7	PLEASE CONTACT US
44E06-2B		Water Separator And Filter	LUCAS	OH/REP/TEST	DHC-6;DHC-7	PLEASE CONTACT US
44E13-1A		Water Seperator	LUCAS	OH/REP/TEST	TBD	PLEASE CONTACT US
45-0060-10		Retractable Landing Light	GRIMES	OH/REP/TEST	DC8;F28;VISC	PLEASE CONTACT US
45-0060-11		Retractable Landing Light	GRIMES	OH/REP/TEST	DC8;F28;VISC	PLEASE CONTACT US
45-0060-12		Retractable Landing Light	GRIMES	OH/REP/TEST	DC8;F28;VISC	PLEASE CONTACT US
45-0060-13		Retractable Landing Light	GRIMES	OH/REP/TEST	DC8;F28;VISC	PLEASE CONTACT US
45-0060-6		Retractable Landing Light	GRIMES	OH/REP/TEST	DC8;F28;VISC	PLEASE CONTACT US
45-0060-7		Retractable Landing Light	GRIMES	OH/REP/TEST	DC8;F28;VISC	PLEASE CONTACT US
45-0083-1		Retractable Landing Light	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
45-0083-2		Retractable Landing Light	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
45-0083-3		Retractable Landing Light	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
45-0083-5		Retractable Landing Light	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
45-0083-7		Retractable Landing Light	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
452MC10		AC Motor Assembly	WESTERN GEAR	OH/REP/TEST	TBD	PLEASE CONTACT US
457EA-0		Wing Flap Actuator Assembly (Outboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
457EA-1		Wing Flap Actuator Assembly (Inboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
457EA-2		Wing Flap Screw Assembly (Outboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
457EA-3		Wing Flap Screw Assembly (Inboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
457EA-4		Flap Gearbox Assembly	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
457EA-5		Wing Flap Actuator Assembly (Outboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
457EA-6		Wing Flap Actuator Assembly (Inboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
457EA-7		Wing Flap Screw Assembly (Outboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
457EA-8		Wing Flap Screw Assembly (Inboard)	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
45C3-111	D.61778	Fan Assembly	AIRSCREW	OH/REP/TEST	BAE125	PLEASE CONTACT US
45C3-131		Fan Assembly	AIRSCREW	OH/REP/TEST	BAE125	PLEASE CONTACT US

46359-1		Alternating Current Motor	HONEYWELL	OH/REP/TEST	B707	PLEASE CONTACT US
465C-59NW	695760-1	Valve	AUTO VALVE INC.	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
468100-0-1		Propeller De-Icer Timer	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
468100-1		Propeller De-Icer Timer	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
469100-0-1		Hydraulic Hand Pump	YORK INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
475C-55WP		Valve	AUTO VALVE INC.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
475C-62W	695049-3	Fuel Drain Valve	AUTO VALVE INC.	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
48299-1		Aircraft Direct Current Motor	HONEYWELL	OH/REP/TEST	F27	PLEASE CONTACT US
482PG/SB		Oil Pressure Transmitter	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
49C65		Aircraft Heater Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
49EC1A		DC Electric Motor	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4A037-1	697339-1	Manually Operated Valve	ARKWIN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4CZ144871	TYPE C1606H/8	Motor Assembly	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
4CZ73100-1		Motor Assembly	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
4CZ92025		28V DC Motor	GEC	OH/REP/TEST	F27;GS1	PLEASE CONTACT US
4CZ92025-1		28V DC Motor	GEC	OH/REP/TEST	F27;GS1	PLEASE CONTACT US
4CZ95868	TYPE C1305A-8	Motor Assembly	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
4U4059	695723-1	Door Lock Cylinder Assy	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
4Z10765		Landing Lamp (See 17Z10348)	GRIMES	OH/REP/TEST	HS748	PLEASE CONTACT US
5000268-1		Brake Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
5000268-2		Brake Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
5000268-3		Brake Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
5000268-5		Brake Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
5000757-1		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000757-10		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000757-2		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000757-3		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000757-4		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000757-5		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000757-6		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000757-8		Main Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000758-10		Brake Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000758-10R		Brake Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000919-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC10	PLEASE CONTACT US
5000919-2		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC10;MD11	PLEASE CONTACT US
500-1-00257-002		Jaguar Actuator	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
500-1-01517-001		Jaguar Actuator	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
500-1-01517-002		Jaguar Actuator	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
500-1-01518-001		Jaguar Actuator	FR-HITEMP	OH/REP/TEST	F27	PLEASE CONTACT US
500-1-01520-001		Jaguar Actuator	FR-HITEMP	OH/REP/TEST	F27	PLEASE CONTACT US
500-1-01871		Kite Actuator	GEC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
500-1-01872		Kite Actuator	GEC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
500-1-02380		Chipmunk Actuator	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
500-1-03355-001		Jaguar Actuator	GEC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
500-1-03660-001		Jaguar Actuator	GEC	OH/REP/TEST	HARR	PLEASE CONTACT US

500-1-03660-002		Jaguar Actuator	GEC	OH/REP/TEST	HARR	PLEASE CONTACT US
500-1-03668-001		Jaguar Actuator	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
500-1-04118-001		Jaguar Actuator	FR-HITEMP	OH/REP/TEST	F27	PLEASE CONTACT US
500-1-04447-001		Jaguar Actuator	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
500-1-04447-002		Jaguar Actuator	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
500-1-04448-001		Jaguar Actuator	FR-HITEMP	OH/REP/TEST	F27	PLEASE CONTACT US
500-1-04790-001		Jaguar Actuator	GEC	OH/REP/TEST	F28	PLEASE CONTACT US
500-1-21166-000		DC Rotary Actuator	GEC	OH/REP/TEST	LYNX	PLEASE CONTACT US
500-1-21375-002		Fox Actuator	GEC	OH/REP/TEST	HAL KIRAN	PLEASE CONTACT US
500-1-21440-001		Cub Jaguar Actuator	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
500-1-21450-000		Kite Actuator	GEC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
500-1-21533-001		Actuator, Cub Jaguar	GEC	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
500-1-21533-002		Actuator, Cub Jaguar	GEC	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
50-0124-1		Fixed Landing Light	GRIMES	OH/REP/TEST	BAE146	PLEASE CONTACT US
50-0124-3		Fixed Landing Light	GRIMES	OH/REP/TEST	BAE146	PLEASE CONTACT US
50-0128-1		Taxiing Light	GRIMES	OH/REP/TEST	B737	PLEASE CONTACT US
5001445-1		Brake Assembly (LH)	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001445-2		Brake Assembly (LH)	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001445-3		Brake Assembly (LH)	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001445-4		Brake Assembly (LH)	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001446-1		Brake Assembly (RH)	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001446-2		Brake Assembly (RH)	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001446-3		Brake Assembly (RH)	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001446-4		Brake Assembly (RH)	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001446-5		Brake Assembly	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001446-6		Brake Assembly	ABSC	OH/REP/TEST	CITATION 1/2	PLEASE CONTACT US
5001477-1		Main Wheel Assembly	ABSC	OH/REP/TEST	CESS CITATION-X;CESS 500; CESS 55	PLEASE CONTACT US
5001477-2		Main Wheel Assembly	ABSC	OH/REP/TEST	CESS CITATION-X;CESS 500; CESS 55	PLEASE CONTACT US
5001477-3		Main Wheel Assembly	ABSC	OH/REP/TEST	CESS CITATION-X;CESS 500; CESS 55	PLEASE CONTACT US
50016-001		Leading Edge Flap Actuator Assembly	SARGENT INDUSTRIES	TEST ONLY	TBD	PLEASE CONTACT US
50016-002		Leading Edge Flap Actuator Assembly	SARGENT INDUSTRIES	TEST ONLY	TBD	PLEASE CONTACT US
50016-003		Leading Edge Flap Actuator Assembly	SARGENT INDUSTRIES	TEST ONLY	TBD	PLEASE CONTACT US
50016-004		Leading Edge Flap Actuator Assembly	SARGENT INDUSTRIES	TEST ONLY	TBD	PLEASE CONTACT US
50016-008		Leading Edge Flap Actuator Assembly	SARGENT INDUSTRIES	TEST ONLY	TBD	PLEASE CONTACT US
50017-001		Leading Edge Flap Actuator Assembly	SARGENT INDUSTRIES	TEST ONLY	TBD	PLEASE CONTACT US
50-0199-1		Taxiing Light	GRIMES	OH/REP/TEST	B737	PLEASE CONTACT US
5002460-1	101-8002-51	Main Wheel Assembly	ABSC	OH/REP/TEST	BEECH B200	PLEASE CONTACT US
5002460-2	101-8002-57	Main Wheel Assembly	ABSC	OH/REP/TEST	BEECH B200	PLEASE CONTACT US
5003065-2		Brake Assembly	ABSC	OH/REP/TEST	CESS406, CESS441	PLEASE CONTACT US
5003086-1		Brake Assembly	ABSC	OH/REP/TEST	F27	PLEASE CONTACT US
5003086-2		Brake Assembly	ABSC	OH/REP/TEST	F27	PLEASE CONTACT US
5003096-1		Brake Assembly	ABSC	OH/REP/TEST	LEARJET	PLEASE CONTACT US
5003096-3		Brake Assembly	ABSC	OH/REP/TEST	LEARJET	PLEASE CONTACT US
5003096-4		Brake Assembly	ABSC	OH/REP/TEST	LEARJET	PLEASE CONTACT US
5003096-6		Brake Assembly	ABSC	OH/REP/TEST	LEARJET	PLEASE CONTACT US

5003279-1		Main Wheel Assembly	ABSC	OH/REP/TEST	FALC50B	PLEASE CONTACT US
5003279-2		Main Wheel Assembly	ABSC	OH/REP/TEST	FALC50B	PLEASE CONTACT US
5003279-3		Main Wheel Assembly	ABSC	OH/REP/TEST	FALC20;FALC50B	PLEASE CONTACT US
5003426-1		Brake Assembly	ABSC	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
5003426-2		Brake Assembly	ABSC	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
5004070-2		Brake Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
5004899-3		Main Wheel Assembly	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5004899-4		Main Wheel Assembly	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5004899-5		Main Wheel Assembly	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5004899-6		Main Wheel Assembly	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5004902-2		Brake Unit Assy	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5004902-3		Brake Unit Assy	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5004902-4		Brake Unit Assy	ABSC	OH/REP/TEST	GS2;GS3;GS4	PLEASE CONTACT US
5005494-3		Brake Assembly	ABSC	OH/REP/TEST	CESS	PLEASE CONTACT US
5005495-2		Main Wheel Assembly	ABSC	OH/REP/TEST	CESS	PLEASE CONTACT US
5005495-3		Main Wheel Assembly	ABSC	OH/REP/TEST	CESS	PLEASE CONTACT US
5006450-1	600-85003-7	Nose Wheel Assembly	ABSC	OH/REP/TEST	CANA(CL600)	PLEASE CONTACT US
5006450-2		Nose Wheel Assembly	ABSC	OH/REP/TEST	CANA(CL600)	PLEASE CONTACT US
5006450-3		Nose Wheel Assembly	ABSC	OH/REP/TEST	CANA(CL600)	PLEASE CONTACT US
5006450-4		Nose Wheel Assembly	ABSC	OH/REP/TEST	CANA(CL600)	PLEASE CONTACT US
5006450-5		Nose Wheel Assembly	ABSC	OH/REP/TEST	CANA(CL600)	PLEASE CONTACT US
5006528-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	DO228	PLEASE CONTACT US
5006528-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	DO228	PLEASE CONTACT US
5006618-1		Main Wheel Assembly	ABSC	OH/REP/TEST	DO228	PLEASE CONTACT US
5006618-2		Main Wheel Assembly	ABSC	OH/REP/TEST	DO228	PLEASE CONTACT US
5006618-3		Main Wheel Assembly	ABSC	OH/REP/TEST	DO228	PLEASE CONTACT US
5006858-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	ATR42	PLEASE CONTACT US
5006858-2		Nose Wheel Assembly	ABSC	OH/REP/TEST	ATR42	PLEASE CONTACT US
500702-3021	695719-1	Axial Flow Fan	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
500702-4491	AVF63-48D1880	Blower Assembly	JOY	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
500702-4620		Mixed Flow Fan Assy	SUNDSTRAND	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
5007045-1		Main Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5007045-2		Main Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5007045-4		Main Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5007554-2		Main Wheel Assembly	ABSC	OH/REP/TEST	SIK S-76	PLEASE CONTACT US
5007555-1		Brake Assembly	ABSC	OH/REP/TEST	SIK S-76B	PLEASE CONTACT US
5007555-2		Brake Assembly	ABSC	OH/REP/TEST	SIK S-76B	PLEASE CONTACT US
5007897-1		Main Wheel Assembly	ABSC	OH/REP/TEST	MD83;MD88	PLEASE CONTACT US
5007897-2		Main Wheel Assembly	ABSC	OH/REP/TEST	MD83;MD88	PLEASE CONTACT US
5007897-3		Main Wheel Assembly	ABSC	OH/REP/TEST	MD83;MD88	PLEASE CONTACT US
5007898-1		Brake Assembly	ABSC	OH/REP/TEST	MD83;MD88	PLEASE CONTACT US
5007898-2		Brake Assembly	ABSC	OH/REP/TEST	MD83;MD88	PLEASE CONTACT US
5007898-3		Brake Assembly	ABSC	OH/REP/TEST	MD83;MD88	PLEASE CONTACT US
5007995-1		Main Wheel Assembly	ABSC	OH/REP/TEST	F50	PLEASE CONTACT US
5007996-1		Brake Assembly	ABSC	OH/REP/TEST	F50	PLEASE CONTACT US

5008131-1		Main Wheel Assembly	ABSC	OH/REP/TEST	F100;F70	PLEASE CONTACT US
5008131-2		Main Wheel Assembly	ABSC	OH/REP/TEST	F100;F70	PLEASE CONTACT US
5008131-3		Main Wheel Assembly	ABSC	OH/REP/TEST	F100;F70	PLEASE CONTACT US
5008131-4		Main Wheel Assembly	ABSC	OH/REP/TEST	F100;F70	PLEASE CONTACT US
5008131-5		Main Wheel Assembly	ABSC	OH/REP/TEST	F100;F70	PLEASE CONTACT US
5008132-2		Brake Assembly	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008132-3		Brake Assembly	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008132-4		Brake Assembly	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008132-5		Brake Assembly	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008132-6		Brake Assembly	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008132-7		Brake Assembly	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008132-8		Brake Assembly	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008133-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	F100	PLEASE CONTACT US
5008367-1		Shuttle Valve	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
5008447-1		Main Wheel Assembly	ABSC	OH/REP/TEST	GS4	PLEASE CONTACT US
5008447-2		Main Wheel Assembly	ABSC	OH/REP/TEST	GS4	PLEASE CONTACT US
5008447-3		Main Wheel Assembly	ABSC	OH/REP/TEST	GS4	PLEASE CONTACT US
5008447-4		Main Wheel Assembly	ABSC	OH/REP/TEST	GS4	PLEASE CONTACT US
5008541-1		Brake Assembly	MEGGITT/ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5009027-2		Brake Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5009027-3		Brake Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5009027-5		Brake Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5009029-1	600-85123-15	Main Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5009029R	600-85123-13	Main Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5009029R-1		Main Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL601	PLEASE CONTACT US
5010488-1		Main Wheel Assembly	ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5010488-2		Main Wheel Assembly	ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5010488-3		Main Wheel Assembly	ABSC	OH/REP/TEST	SAAB340	PLEASE CONTACT US
5010571-1		Main Wheel Assembly	ABSC	OH/REP/TEST	CRJ-200;CL600	PLEASE CONTACT US
5010571-2		Main Wheel Assembly	ABSC	OH/REP/TEST	CRJ-200;CL600	PLEASE CONTACT US
5010598-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	CL600;CL604;HAWKER 800	PLEASE CONTACT US
5010933-1		Brake Assembly	ABSC	OH/REP/TEST	GS11;GS111;GS4	PLEASE CONTACT US
5010933-2		Brake Assembly	ABSC	OH/REP/TEST	GS11;GS111;GS4	PLEASE CONTACT US
5010933-3		Brake Assembly	ABSC	OH/REP/TEST	GS11;GS111;GS4	PLEASE CONTACT US
5010933-4		Brake Assembly	ABSC	OH/REP/TEST	GS11;GS111;GS4	PLEASE CONTACT US
501-1-05640		Motor	GEC	OH/REP/TEST	BAC111(CofC only);HS748;HRLD	PLEASE CONTACT US
501-1-06110	C2520A/6	DC Motor	PLESSEY	OH/REP/TEST	TBD	PLEASE CONTACT US
501-1-06420		Motor	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
501-1-06640	C2520A/7	DC Motor	PLESSEY	OH/REP/TEST	TBD	PLEASE CONTACT US
501-1-06800	C2016B/2	DC Motor	PLESSEY	OH/REP/TEST	HAL KIRAN	PLEASE CONTACT US
501-1-07130		Motor Assembly	GEC	OH/REP/TEST	BAC111(CofC only);HRLD	PLEASE CONTACT US
501-1-08440	C1106-D12	DC Motor	GEC	OH/REP/TEST	LYNX	PLEASE CONTACT US
501-1-13615-002		Motor-Tacho Unit	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
5011809-1		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
5011809-2		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US

5011809-3		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
5014199-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	FALC900	PLEASE CONTACT US
50150-20	695197	Hydraulic Selector Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
50150-28		Hydraulic Selector Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
50150-3		Hydraulic Selector Valve	HYDRAULIC RESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
50-1571-26		Elevator Control Snubber Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-1571-27		Elevator Control Snubber Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50233-19		Pressure Indicator	ROGERSON-KRATOS	OH/REP/TEST	B747;DC10	PLEASE CONTACT US
50233-20		Pressure Indicator	ROGERSON-KRATOS	OH/REP/TEST	B747;DC10	PLEASE CONTACT US
502600-5		Directional Control Valve	ACCESSORY PRODUCTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
502600-7	695680-7	Directional Control Valve	ACCESSORY PRODUCTS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
503-1-04827-006		AC Generator	GEC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
503-1-04827-009		AC Generator	GEC	OH/REP/TEST	F27	PLEASE CONTACT US
503-1-06390-000		Tacho Generator	GEC	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
50405-100		Coffee Maker	NORDSKOG IND.	OH/REP/TEST	MD87;MD88	PLEASE CONTACT US
50-5530-5		Main Gear Side Strut Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-5531-1		Nose Gear Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
5059-2		Hydraulic Shuttle Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
5059-4		Hydraulic Shuttle Valve	BOEING	OH/REP/TEST	B747	PLEASE CONTACT US
5060-1		Hydraulic Shuttle Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
5060-2		Hydraulic Shuttle Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
5060-3		Hydraulic Shuttle Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
5060-4		Hydraulic Shuttle Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
5060-5		Hydraulic Shuttle Valve	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
5060-6		Hydraulic Shuttle Valve	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
506-1-00488		Windscreen Controller	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
506-1-00830		Windscreen Controller	GEC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
506-1-00837-002		Controller Type 27	GEC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
506-1-07380		Windscreen Control Unit	GEC	OH/REP/TEST	JETS	PLEASE CONTACT US
506-1-07571-001		Controller Type 33	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
506-1-07571-101		Controller Type 33	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
506-1-08484-000		Contactora	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
5064-01		Control Motor	LITTON	OH/REP/TEST	B727;B737	PLEASE CONTACT US
50652-1		Pressure Transmitter	NEGRETTI	OH/REP/TEST	BAE146	PLEASE CONTACT US
50-6809-2		Nose Gear Lock Actuator	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-6819-4		Nose Gear Actuator Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-6819-5		Nose Gear Actuator Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-6832		MLG Door Actuator Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-6832-10		MLG Door Actuator Assembly	BOEING	OH/REP/TEST	TBD	PLEASE CONTACT US
50-6832-11		MLG Door Actuator Assembly	BOEING	OH/REP/TEST	TBD	PLEASE CONTACT US
50-6833-4		Main Gear Actuator Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-6834		Main & Nose Gear Lock Actuator	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50781-200G-01		Pressure Transducer	NEGRETTI	TEST ONLY	ATR42	PLEASE CONTACT US
50781-200G-02		Pressure Transducer	NEGRETTI	TEST ONLY	ATR42	PLEASE CONTACT US
50-820208		Nose Landing Gear Actuator	BEECHCRAFT	OH/REP/TEST	BEECH	PLEASE CONTACT US

509-1-01060		Static Inverter	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
50-9725-2		Main Gear Oleo Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-9731		Main Gear Cylinder Centering Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-97320-1		Main Gear Snubber Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-9760-1		Truck Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
50-9760-30		Oleo & Truck Assy L & R	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
5110-001-000		Electro-Pneumatic Gate Valve	HONEYWELL	OH/REP/TEST	HS748	PLEASE CONTACT US
5110-002-000		Electro-Pneumatic Gate Valve	HONEYWELL	OH/REP/TEST	HS748	PLEASE CONTACT US
5110-003-000		Electro-Pneumatic Gate Valve	HONEYWELL	OH/REP/TEST	HS748	PLEASE CONTACT US
51102-000		Voltage Regulator	LUCAS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
51102-001		Voltage Regulator	LUCAS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
51102-002		Voltage Regulator	LUCAS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
51102-003		Voltage Regulator	LUCAS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
51102-007		Voltage Regulator	LUCAS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
51107-003		Voltage Regulator	LUCAS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
51115-000		Voltage Regulator	LUCAS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
516029-1		AC Motor	HONEYWELL	OH/REP/TEST	A300;A310;B727;B737;DC9	PLEASE CONTACT US
516029-2		AC Motor	HONEYWELL	OH/REP/TEST	A300;A310;B727;B737;DC9	PLEASE CONTACT US
516508-1		Alternating Current Motor	HONEYWELL	OH/REP/TEST	B707	PLEASE CONTACT US
519852-2		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	A300;DC10;MD11	PLEASE CONTACT US
519852-3		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	A300;DC10;MD11	PLEASE CONTACT US
519852-4		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	A300;DC10;MD11	PLEASE CONTACT US
519858-1		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	A300	PLEASE CONTACT US
519858-2		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	A310	PLEASE CONTACT US
519858-3		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	A310-200	PLEASE CONTACT US
519858-4		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	A310-300	PLEASE CONTACT US
519858-5		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	B757	PLEASE CONTACT US
519858-6		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	B767	PLEASE CONTACT US
519858-7		Engine Starter Motor	ALLIED SIGNAL	OH/REP/TEST	B767-300	PLEASE CONTACT US
525068-2		Linear Actuator	GARRETT	OH/REP/TEST	B707	PLEASE CONTACT US
525364-6		Rotary Actuator	GARRETT AIRESEARCH	OH/REP/TEST	B707	PLEASE CONTACT US
525386-1		Linear Actuator	GARRETT	OH/REP/TEST	DC8	PLEASE CONTACT US
525760-1		Rotary Actuator	AIRESEARCH	OH/REP/TEST	DC8	PLEASE CONTACT US
5302KPT-02		Torque Pressure Transmitter	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
5304KPT-02		Torque Pressure Transmitter	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
53150-1	695197	Rudder Diverter Valve	STERER	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
53183-109		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
53183-111		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
53183-113		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
53183-118		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
53183-215-03		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
53183-218-03		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
53183-260-03		High Speed Resetting Detector	KIDDE GRAVINER	TEST ONLY	BAE146	PLEASE CONTACT US
53230-1	695812-2	Shut Off Valve	STERER	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
53942100021MCOA		Clogging Indicator Unit	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US

540158-4-2		Rotary Electromechanical Actuator	ALLIED SIGNAL	OH/REP/TEST	BAE125	PLEASE CONTACT US
540200-2		Linear Actuator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540200-3		Linear Actuator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540538-2-1	697235-1	Linear Actuator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540604-2-1		Linear Actuator	GARRETT	OH/REP/TEST	F27	PLEASE CONTACT US
540604-4 Series 1		Linear Actuator	GARRETT	OH/REP/TEST	F27	PLEASE CONTACT US
540906-2-2		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540906-2-4		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540906-2-5		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540906-2-6		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540906-3-1		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540906-3-3		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540906-3-4		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540906-3-5		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540907-16		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540907-17		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540907-18		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540907-19		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540907-20		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
540907-6		Electromechanical Rotary Actuator	AIRSEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
541208-1		Electromechanical Rotary Actuator	GARRETT	OH/REP/TEST	B707;B737	PLEASE CONTACT US
541208-2		Electromechanical Rotary Actuator	GARRETT	OH/REP/TEST	B707;B737	PLEASE CONTACT US
541296-3-1		Rotary Actuator	AIRESEARCH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
541558-2-1		Linear Actuator	GARRETT	OH/REP/TEST	DC8	PLEASE CONTACT US
541932-1-1		Rotary Actuator	HONEYWELL	OH/REP/TEST	B727;B737;A300	PLEASE CONTACT US
544548-1		Linear Actuator	GARRETT	OH/REP/TEST	B707	PLEASE CONTACT US
544622-2		Actuator	ALLIED SIGNAL	OH/REP/TEST	DC10	PLEASE CONTACT US
549460-1		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	TBD	PLEASE CONTACT US
549460-7		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	TBD	PLEASE CONTACT US
54C00		Sealed Control Assembly	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
550-1-00170		Fuel Pump	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
550-1-21118	DP022-2	Motorized Type Gear Pump	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
550-1-21735	DP022-5	Motorized Type Gear Pump	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
550-1-21736	DP022-6	Motorized Type Gear Pump	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
55076-02		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727	PLEASE CONTACT US
55076-03		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727	PLEASE CONTACT US
55098-01	10-60470-10	Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
55098-04		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
55098-05		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
55098-06		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
55098-07		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
55098-08	10-60470-8	Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
551050-1		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
551050-10		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
551050-12		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US

551050-3		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
551200-1		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
551200-11		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
551200-13		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
551200-17		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
551200-3		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
551200-5		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
55204-6		Valve Assembly	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
55204-8		Valve Assembly	ADEL	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
55204-81		Valve Assembly	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
552430-1		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
552430-3		Cylindrical Hyd Pressure Accumulator	BENDIX-PACIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5542000-4		Nose Gear Assembly	CESSNA	OH/REP/TEST	CESS	PLEASE CONTACT US
557-10D		Air Check Valve	LUCAS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
557-17E		Air Check Valve	LUCAS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
557-2C		Air Check Valve	LUCAS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
557-2D		Air Check Valve	LUCAS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
55J4312		Aircraft Bomb Rack	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5669-17		Flow Control Valve	SUNDSTRAND	OH/REP/TEST	B707;B727	PLEASE CONTACT US
5669-4		Flow Control Valve	SUNDSTRAND	OH/REP/TEST	B707;B727	PLEASE CONTACT US
5669-6		Flow Control Valve	SUNDSTRAND	OH/REP/TEST	B707;B727	PLEASE CONTACT US
5669-9		Flow Control Valve	SUNDSTRAND	OH/REP/TEST	B707;B727	PLEASE CONTACT US
568-1-24704		Fuel Transfer Pump	GEC	OH/REP/TEST	JAG	PLEASE CONTACT US
568-8-21028	SPE6210.MK1	Fuel Booster Pump	GEC AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
568-8-21028		Fuel Booster Pump	GEC AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
56B3A	MS28034-1	Temperature Bulb	LEWIS	TEST ONLY	C130;L100;L382;ELEC	PLEASE CONTACT US
56B3A8		Temperature Bulb	LEWIS	TEST ONLY	C130;L100;L382;ELEC	PLEASE CONTACT US
5716694-521		NLG Shock Strut Assembly	DOUGLAS AIRCRAFT	OH/REP/TEST	DC8	PLEASE CONTACT US
5719176-5511		Main Gear Torque Tube (LH)	DOUGLAS AIRCRAFT	OH/REP/TEST	DC8	PLEASE CONTACT US
5719176-5512		Main Gear Torque Tube (RH)	DOUGLAS AIRCRAFT	OH/REP/TEST	DC8	PLEASE CONTACT US
571925-1-1		Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
571925-2-1		Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
571925-3-1		Cooling Turbine	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
575-315	695455-3	Ice Detector Assy	COOK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5759101-5507		Main Gear Assembly (LH)	DOUGLAS AIRCRAFT	OH/REP/TEST	DC8	PLEASE CONTACT US
5759101-5508		Main Gear Assembly (RH)	DOUGLAS AIRCRAFT	OH/REP/TEST	DC8	PLEASE CONTACT US
57B28A		Fuel Temperature Bulb	LEWIS	TEST ONLY	B727;B737;B757	PLEASE CONTACT US
57J46099		Aircraft Bomb Rack	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5-83069-3003		Outer Cylinder Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
5-88763-10		Aileron Snubber Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
5-88763-7		Aileron Snubber Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
59600-5003		Hydraulic Solenoid Valve Assy	PARKER	OH/REP/TEST	B737;B747;DC10	PLEASE CONTACT US
59600-5011		Hydraulic Solenoid Valve Assy	PARKER	OH/REP/TEST	B737;B747;B757;DC10	PLEASE CONTACT US
5A527	697226-1	Oil Cooler	STANDARD THOMSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5A844		Oil Cooler Valve	STANDARD THOMSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US

5C5787-3		Hydraulic Servo Control Valve	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5787-7		Hydraulic Servo Control Valve	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5788-3		Hydraulic Booster Control Valve	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5788-4		Hydraulic Booster Control Valve	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5791		Aileron Actuator	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5791	695434	Aileron Actuator	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5792-1		Rudder Actuator	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5792-1	695497-5	Rudder Actuator	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5794		Cargo Door Snubber	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5C5803		Elevator Booster Actuator	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
5E2476-1		Heated Drain Mast	B F GOODRICH	OH/REP/TEST	BAE146	PLEASE CONTACT US
5E2476-2		Heated Drain Mast	B F GOODRICH	OH/REP/TEST	BAE146	PLEASE CONTACT US
6.1001.0004		Sync Alternator	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
6001036-1		Wheel Drive Unit	ABSC	OH/REP/TEST	GS1	PLEASE CONTACT US
6004123-1		Wheelspeed Sensor	ABSC	OH/REP/TEST	F50	PLEASE CONTACT US
6004682-1		Brake Temperature Sensor	ABSC	TEST ONLY	F100	PLEASE CONTACT US
60-0883-1		Emergency Exit Light Power Supply	GRIMES	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
60-0883-1LB		Emergency Exit Light Power Supply	GRIMES	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
60-0883-3LB		Emergency Exit Light Power Supply	GRIMES	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
601-0001-1		Oven Controller	GRIMES/MIDLAND ROSS	OH/REP/TEST	F50	PLEASE CONTACT US
60-1321-1		Exit Light Battery Power Supply	GRIMES	OH/REP/TEST	B707;B727;B737;B747;BAE ATP;CHA	PLEASE CONTACT US
60-1321-1LB		Exit Light Battery Power Supply	GRIMES	OH/REP/TEST	B707;B727;B737;B747;BAE ATP;CHA	PLEASE CONTACT US
60-1321-5		Exit Light Battery Power Supply	GRIMES	OH/REP/TEST	B707;B727;B737;B747;BAE ATP;CHA	PLEASE CONTACT US
60-1321-5LB		Exit Light Battery Power Supply	GRIMES	OH/REP/TEST	B707;B727;B737;B747;BAE ATP;CHA	PLEASE CONTACT US
60-1321-7		Exit Light Battery Power Supply	GRIMES	OH/REP/TEST	B707;B727;B737;B747;BAE ATP;CHA	PLEASE CONTACT US
60-1321-7LB		Exit Light Battery Power Supply	GRIMES	OH/REP/TEST	B707;B727;B737;B747;BAE ATP;CHA	PLEASE CONTACT US
6014-1		Oil Temperature Thermostat	DATA PRODUCTS	TEST ONLY	C130;L100	PLEASE CONTACT US
60-1755-1		Strobe Light Power Supply	GRIMES	OH/REP/TEST	BAE125	PLEASE CONTACT US
60-1755-3		Strobe Light Power Supply	GRIMES	OH/REP/TEST	BAE125	PLEASE CONTACT US
60187-A2		Cold Air Valve	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
60188-A2		Cold Air Valve	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
60-2388-1		Anti Collision Lamp Power Supply	GRIMES	OH/REP/TEST	BAE146;B737	PLEASE CONTACT US
60-2388-101		Anti Collision Lamp Power Supply	GRIMES	OH/REP/TEST	BAE146;B737	PLEASE CONTACT US
60-3146-3		Strobe Power Supply	GRIMES	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
60-3550-1		Exit Light Battery Power Supply	GRIMES	OH/REP/TEST	BAE146;BAE ATP	PLEASE CONTACT US
60-3606-1	S214N101-1	Foot Warmer	AIRCRAFT PROD/GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
60-3606-3	S214N101-2	Foot Warmer	AIRCRAFT PROD/GRIMES	OH/REP/TEST	B757	PLEASE CONTACT US
60-369		Fuel Booster Pump Assembly	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
60-369A	695768-1	Fuel Booster Pump Assembly	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
60-371A		Fuel Booster Pump Assembly	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
60-371B	695769-1	Fuel Booster Pump Assembly	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
60-371C		Fuel Booster Pump Assembly	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
60-371D		Fuel Booster Pump Assembly	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
60-4705-1		Exit Light Battery Power Supply	GRIMES	OH/REP/TEST	BAE ATP;JETS41	PLEASE CONTACT US
60-551		Fuel Transfer Pump	HYDRO-AIRE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US

60-611A		Fuel Booster Pump	CRANE HYDRO-AIRE	OH/REP/TEST	DHC-6	PLEASE CONTACT US
607518-2 SERIES 2		Temperature Control	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
607518-2 SERIES 3		Temperature Control	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
607518-2 SERIES 4		Temperature Control	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
60946-3		Accumulator Assy	PARKER AEROSPACE	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
60946-4		Accumulator Assy	PARKER AEROSPACE	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
60946-5		Accumulator Assy	PARKER AEROSPACE	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
60C1-131		Fan Unit	AIRSCREW	OH/REP/TEST	HS748	PLEASE CONTACT US
61073-1		Double Compartment Oven	RUMBOLD	OH/REP/TEST	B737	PLEASE CONTACT US
61-2275-1		Battery Assembly	GRIMES	OH/REP/TEST	BAE146;BAE ATP	PLEASE CONTACT US
614-1-03460		Emergency Light Unit	PLESSEY AEROSPACE	OH/REP/TEST	HS748;HRLD;SKY	PLEASE CONTACT US
614-1-03460-001		Emergency Light Unit	PLESSEY AEROSPACE	OH/REP/TEST	HS748;HRLD;SKY	PLEASE CONTACT US
614-1-03470		Exit Light Unit	GEC	OH/REP/TEST	HS748;HRLD;SKY	PLEASE CONTACT US
614-1-03470-001		Exit Light Unit	GEC	OH/REP/TEST	HS748;HRLD;SKY	PLEASE CONTACT US
614-1-04670-001		Anti-Collision Lamp	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
614-1-04670-002		Anti-Collision Lamp	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
6147-1		Hyd Flow Regulator Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6147-2		Hyd Flow Regulator Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6147-3		Hyd Flow Regulator Valve	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6174-1		Flow Regulator Valve	PNEUDRAULICS	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
6174-2		Flow Regulator Valve	PNEUDRAULICS	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
6211-1		Flow Regulator Valve	PNEUDRAULICS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
6211-2		Flow Regulator Valve	PNEUDRAULICS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
62197-001-001		Water Boiler	RUMBOLD	OH/REP/TEST	B737	PLEASE CONTACT US
62198-001-001		Water Boiler	RUMBOLD	OH/REP/TEST	B767	PLEASE CONTACT US
6271-1		Hydraulic Fuse	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6272-1	10-61245-24	Hydraulic Fuse	PNEUDRAULICS	OH/REP/TEST	B737;B747	PLEASE CONTACT US
6273-1	10-61245-17	Hydraulic Fuse	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6273-5	10-61245-23	Hydraulic Fuse	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6274-1		Hydraulic Fuse	PNEUDRAULICS	OH/REP/TEST	B737	PLEASE CONTACT US
6300-C38A-155-B1		Single Synchro Indicator	BENDIX	OH/REP/TEST	HELI	PLEASE CONTACT US
6300-C49A-155-B1		Single Synchro Indicator	BENDIX	OH/REP/TEST	HELI	PLEASE CONTACT US
6301-1	695974-3	Shut Off Valve	J.C.CARTER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
632184-3	95024	Oil Pressure Switch	HYDRA ELECTRIC	TEST ONLY	C130;ELEC	PLEASE CONTACT US
634-24-10P		Aircraft Clock	WAKMANN	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
638005205-1		Motor Assembly	DOWTY	OH/REP/TEST	SAAB340	PLEASE CONTACT US
645405-1	10-62009-1	Cabin Air Recirculation Fan	HONEYWELL	OH/REP/TEST	B737	PLEASE CONTACT US
645405-2	10-62009-1	Cabin Air Recirculation Fan	ALLIED SIGNAL	OH/REP/TEST	B737	PLEASE CONTACT US
64752-001-003		Beverage Maker	L.A.RUMBOLD	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
64761-001-005		Beverage Maker	RUMBOLD	OH/REP/TEST	B767;A320	PLEASE CONTACT US
64763-2		Coffee Maker	BRITAX SELL	OH/REP/TEST	TBD	PLEASE CONTACT US
64763-201-003		Coffee Maker	BRITAX SELL	OH/REP/TEST	TBD	PLEASE CONTACT US
64767-001-001		Beverage Maker	RUMBOLD	OH/REP/TEST	MD83	PLEASE CONTACT US
64771-001-001		Beverage Maker	RUMBOLD-SELL	OH/REP/TEST	A320	PLEASE CONTACT US
64820-409-1		Oil Pressure Indicator	JAEGER	OH/REP/TEST	A300	PLEASE CONTACT US

64820-411-1		Oil Pressure Indicator	JAEGER	OH/REP/TEST	A300	PLEASE CONTACT US
64820-418-1		Oil Pressure Indicator	JAEGER	OH/REP/TEST	A300	PLEASE CONTACT US
64820-420-1		Oil Pressure Indicator	JAEGER	OH/REP/TEST	A300	PLEASE CONTACT US
65-0475-7		Indicator Light Assembly	GRIMES	OH/REP/TEST	B747	PLEASE CONTACT US
65075-01	10-60470-11	Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
65075-02		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
65075-03		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
65075-04		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
65075-05		Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
65075-06	10-60470-13	Variable Delivery Hydraulic Pump	ABEX-PARKER	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
651-12-24-15		Aircraft Clock	WAKMANN	OH/REP/TEST	B707;B737	PLEASE CONTACT US
65-11711-5		Thrust Reverser Lower Actuator Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-1325-5		Main Gear Side Strut Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-17868-8		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B727	PLEASE CONTACT US
65-17978-1		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B727	PLEASE CONTACT US
65-2346-1		Galley Door Snubber Assembly	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-2346-3		Galley Door Snubber Assembly	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-2346-4		Galley Door Snubber Assembly	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-2346-5		Galley Door Snubber Assembly	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-27501-3		Nose Landing Gear Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-27501-4		Nose Landing Gear Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-27501-5		Nose Landing Gear Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-27501-6		Nose Landing Gear Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-33733-10		NLG Oleo Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-37558-1		Ground Speed Brake Control Actuator	BOEING	OH/REP/TEST	B727	PLEASE CONTACT US
65-37558-2		Ground Speed Brake Control Actuator	BOEING	OH/REP/TEST	B727	PLEASE CONTACT US
65-37559-2		Ground Speed Brake Control Actuator	BOEING	OH/REP/TEST	B727	PLEASE CONTACT US
65-40181-7		Rudder Gearbox Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-44503-10		Feel Actuator Cylinder Assy	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-44503-3		Rudder & Elevator Feel Actuator Cyl Assy	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-44503-4		Rudder & Elevator Feel Actuator Cyl Assy	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-44503-5		Rudder & Elevator Feel Actuator Cyl Assy	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-44503-6		Rudder & Elevator Feel Actuator Cyl Assy	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-44503-7		Feel Actuator Cylinder Assy	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-44503-8		Feel Actuator Cylinder Assy	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-44503-9		Rudder & Elevator Feel Actuator Cyl Assy	BOEING	OH/REP/TEST	B727;B737	PLEASE CONTACT US
65-44550-14		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44550-15		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44550-16		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44550-18		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44550-20		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44551-5		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44551-6		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44551-7		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44551-9		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US

65-44610-3		Nose Gear Hydraulic Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44610-4		Nose Gear Hydraulic Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44625-11		Nose Gear Hydraulic Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44625-18		Nose Gear Lock Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44625-5		Nose Gear Hydraulic Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44625-8		Nose Gear Hydraulic Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44625-9		Nose Gear Hydraulic Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44691-3		Landing Gear Modular Package Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44691-4		Landing Gear Modular Package Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44691-5		Landing Gear Modular Package Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44691-6		Landing Gear Modular Package Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44710-2		Nose Wheel Steering Cylinder Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44710-3		Nose Wheel Steering Cylinder Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44710-4		Nose Wheel Steering Cylinder Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44710-5		Nose Wheel Steering Cylinder Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44710-6		Nose Wheel Steering Cylinder Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44710-8		Nose Wheel Steering Cylinder Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44710-9		Nose Wheel Steering Cylinder Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44713-13		Nose Wheel Steering Cover Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44713-16		Nose Wheel Steering Cover Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44713-17		Nose Wheel Steering Cover Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-101		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-102		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-103		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-104		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-105		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-45		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-47		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-48		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-50		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-52		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-54		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-55		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-57		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-58		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-59		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-60		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-61		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-62		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-63		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-64		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-65		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-76		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-77		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-79		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US

65-44725-85		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-86		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-87		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-88		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-89		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-90		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-91		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-92		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-93		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-94		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-95		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-96		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-97		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-98		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44725-99		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-10		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-11		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-12		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-13		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-14		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-15		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-22		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-23		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-24		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-25		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-26		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-27		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-5		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-7		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44760-8		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-10		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-12		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-13		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-14		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-3		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-4		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-5		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-6		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44851-7		Ground Spoiler Locking Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-10		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-11		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-12		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-13		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-27		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-28		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US

65-44910-29		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-30		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-31		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-32		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-6		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-7		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-8		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44910-9		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-10		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-11		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-12		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-15		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-16		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-21		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-22		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-27		Main Gear Retract Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-28		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-29		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-30		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-31		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-32		Main Gear Retract Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-33		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-34		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-35		Main Gear Retract Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-36		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-41		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-42		Main Gear Retract Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-7		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-8		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44925-9		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-10		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-11		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-13		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-15		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-2		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-23		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-24		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-25		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-27		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-28		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-29		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-30		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-4		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-5		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-44960-6		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US

65-46108-15		Actuator Beam Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46108-17		Actuator Beam Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46108-19		Actuator Beam Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46108-21		Actuator Beam Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46108-23		Actuator Beam Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46108-3		Actuator Beam Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46108-6		Actuator Beam Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-13		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-16		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-19		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-22		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-26		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-28		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-30		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-31		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46112-9		Actuator Beam Support Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-10		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-11		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-12		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-15		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-16		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-17		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-18		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-19		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-20		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-21		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-22		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-23		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-24		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-25		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-26		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-5		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-6		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-7		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-8		Main Gear Uplock Assy (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46141-9		Main Gear Uplock Assy (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-60		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-61		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-62		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-68		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-69		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-74		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-76		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-77		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-78		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US

65-46200-80		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-81		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-82		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46200-83		Nose Gear Shock Strut Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46232-1		Brake Assy Upper Drag Strut	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46232-3		Brake Assy Upper Drag Strut	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46232-5		Brake Assy Upper Drag Strut	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46232-6		Brake Assy Upper Drag Strut	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-1		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-10		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-11		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-12		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-13		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-14		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-3		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-4		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-5		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-6		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-7		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-8		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-46245-9		Nose Gear Lock Link Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-5706-1		Elevator Snubber Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-5706-2		Elevator Snubber Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-5706-2		Elevator Gust Snubber Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-5718-33		Main Gear Oleo & Truck Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-5722-1		Main Gear Oleo Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-5743-1		Maingear Assy L & R	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
65-63415-1		Fitting Assy-Outboard Door Actuation	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-63415-2		Fitting Assy-Outboard Door Actuation	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-63415-7		Fitting Assy-Outboard Door Actuation	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-63415-8		Fitting Assy-Outboard Door Actuation	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-71680-1		Ground Speed Brake Control Actuator	BOEING	OH/REP/TEST	B727	PLEASE CONTACT US
65-71680-2		Ground Speed Brake Control Actuator	BOEING	OH/REP/TEST	B727	PLEASE CONTACT US
65-73761-103		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-105		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-106		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-107		Main Gear Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-108		Main Gear Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-109		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-111		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-110		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-111		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-112		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-113		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-114		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US

65-73761-115		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-116		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-12		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-121		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-122		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-123		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-124		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-125		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-126		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-127		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-128		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-13		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-14		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-15		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-16		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-21		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-22		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-23		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-24		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-25		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-26		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-31		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-32		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-33		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-34		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-35		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-36		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-37		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-38		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-39		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-40		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-41		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-42		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-43		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-44		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-45		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-46		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-47		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-48		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-49		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-50		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-55		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-56		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-65		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-66		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US

65-73761-77		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-78		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-81		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-82		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-85		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-86		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-87		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-88		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-93		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-94		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-95		Main Gear Side Strut Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-96		Main Gear Side Strut Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-97		Main Gear Assembly (LH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73761-98		Main Gear Assembly (RH)	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73762-21		Nose Gear Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73762-25		Nose Gear Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73762-26		Nose Gear Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73762-27		Nose Gear Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73762-28		Nose Gear Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-73762-5		Nose Gear Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
6577-1		Fan Assembly	SUNDSTRAND	OH/REP/TEST	B727;B737;B747;B757	PLEASE CONTACT US
6577-2		Fan Assembly	SUNDSTRAND	OH/REP/TEST	B727;B737;B747;B757	PLEASE CONTACT US
65-77496-10		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-11		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-12		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-13		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-14		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-17		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-18		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-19		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-20		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-21		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-22		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-23		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-26		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-27		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-28		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-29		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-30		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-5		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-6		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-7		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-8		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-77496-9		Main Gear Actuator Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
6577-7		Fan Assembly	SUNDSTRAND	OH/REP/TEST	B727;B737;B747;B757	PLEASE CONTACT US

6577-7		Fan Assembly	SUNDSTRAND	OH/REP/TEST	B727;B737;B747;B757	PLEASE CONTACT US
65-84161-1		AFT Trunnion Fuse Nut Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65-84161-4		AFT Trunnion Fuse Nut Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C26816-2		Valve Assembly	BOEING	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
65C26833-2		Steering Depress Valve Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C26833-3		Steering Depress Valve Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C26864-1		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C26864-2		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C26864-3		Outboard Ground Spoiler Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C26885-5		Steering Depress Valve Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C26885-6		Steering Depress Valve Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C31099-1		Nose Gear Lock Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C31099-2		Nose Gear Lock Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C32956-1		Main Gear Retract Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C32956-3		Main Gear Retract Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C32956-4		Main Gear Retract Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C32956-6		Main Gear Retract Actuator Assy	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C36408-10		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C36408-11		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C36408-12		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C36408-5		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C36408-7		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C36408-8		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-10		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-11		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-12		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-13		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-14		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-15		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-22		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-23		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-24		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-5		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-7		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38058-8		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-10		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-11		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-12		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-13		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-14		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-15		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-5		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-7		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65C38059-8		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
65J46343		Aircraft Bomb Rack	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US

660PG/SB		Desynn Pressure Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
664-1		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
664-2		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
664-2HEA		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
66WU400-1		Hydraulic Pump	STRATOPOWER	OH/REP/TEST	TBD	PLEASE CONTACT US
671CPL-10-031		Altimeter	KOLLSMAN	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
671CPX-10-05		Altimeter	KOLLSMAN	OH/REP/TEST	B707;CONV;F27	PLEASE CONTACT US
67251-1		Single Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	B737;A300;A320	PLEASE CONTACT US
67262-001-001		Single Compartment Oven	RUMBOLD	OH/REP/TEST	B737	PLEASE CONTACT US
67262-001-002		Single Compartment Oven	RUMBOLD	OH/REP/TEST	B737	PLEASE CONTACT US
67262-001-003		Single Compartment Oven	RUMBOLD	OH/REP/TEST	B737	PLEASE CONTACT US
67262-001-004		Single Compartment Oven	RUMBOLD	OH/REP/TEST	B737	PLEASE CONTACT US
67-2734-001		Dual Butterfly Valve	AERO-CORRY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
67-2735-001		Dual Butterfly Valve	AERO-CORRY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
67-2752-001		Shut Off Valve	JANITROL	OH/REP/TEST	TBD	PLEASE CONTACT US
67-2790-001		Modulating Hot Air Valve	AERO-CORRY	TEST ONLY	C130;L100	PLEASE CONTACT US
67-2790-002		Modulating Hot Air Valve	AERO-CORRY	TEST ONLY	C130;L100	PLEASE CONTACT US
686-9	695836-9	Aircrew Swivel Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
687-7A		Aircrew Swivel Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
687-9	695837-9	Aircrew Swivel Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
68A0511		Fan Unit	AIRSCREW	OH/REP/TEST	HS748	PLEASE CONTACT US
68A0511/2		Fan Unit	AIRSCREW	OH/REP/TEST	HS748	PLEASE CONTACT US
68B850059-1003		Oxygen Regulator	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
68C6122	68C6-122	Fan Unit	AIRSCREW	OH/REP/TEST	HS748	PLEASE CONTACT US
6902MK4		Fuel Transfer Pump	GEC	OH/REP/TEST	JAG	PLEASE CONTACT US
691-14A		Suction Relief Valve	LUCAS	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
692545-1	V5000-40	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-10	V5000-146	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-11	V5000-159	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-12	V5000-153	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-13	V5000-160	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-14	V5000-161	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-17	V5000-169	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-18	V5000-256	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-2	V5000-41	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-3	V5000-43	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-400	V5000-40110	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-500	V5000-1001	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-6	V5000-123	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-7	V5000-147	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
692545-9	V5000-10011	Solenoid Shutoff Valve	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
69-35852-1		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
69-35879-2		L/Edge Flap Actuator	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
695043-1		NLG Uplock Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695043-3		NLG Uplock Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US

695049-3	475C-62W	Fuel Drain Valve	AUTO VALVE INC.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695069-1		NLG Steering Control Valve	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695069-3		NLG Steering Control Valve	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695-2-12		Pressure Transducer	SCHLUMBERGER	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
695224-1	A846-6	Frequency Relay	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695304-7	25430135-08	Temperature Control Box	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695304-8	25430135-09	Temperature Control Box	VAPOR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695305-1	DYLZ3990-3	Valve Assy Dual Butterfly	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695316-1	DYLZ3991-2	Valve Assy Dual Butterfly	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695335-5	G-5400-5	Landing Lamp	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695383-13	AW1821AC02	Cabin Diff Pressure Gauge	AMETEK	TEST ONLY	C130;L100	PLEASE CONTACT US
695422-10	1855E95	Wing Flap Emergency Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695422-11	1855E96	Wing Flap Emergency Brake	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695455-3	575-315	Ice Detector Assy	COOK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
69-54784-1		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
695485-3	1334-3	Hydraulic Servo Valve	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695500AA000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
695500AB000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
695526-3	14080-1	Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695545-5	143752	Hydraulic Boost Pump	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695547-1	47610	Emergency Flap Brake Valve	STERER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695548-3		NLG Steering Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695568-1		NLG Steering Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695568-3		NLG Steering Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
695568-5		NLG Steering Cylinder Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695579-39	1650E412	MLG Ballscrew Assembly	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695592-3	60-551	Fuel Transfer Pump	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695594-3	1372-3	Hydraulic Boost Control Assy	NATIONAL WATERLIFT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695699-1	4-156-51	Fuel Vent Valve	EDMOND SCIENTIFIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695700-3	A489	Trim Tab Actuator	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695715-1	B-123J	Contacto	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695719-1	500702-3021	Axial Flow Fan	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695723-1	4U4059	Door Lock Cylinder Assy	RONSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695743-1	EA-1045-037-1A	Hydraulic Motorpump	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695747-5	B52C22	Shutoff Valve	JANITROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695747-7	C52C22	Shutoff Valve	JANITROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695748-13	121000-1	Air Control Valve	ROCKER IND.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695748-15	121010	Air Control Valve	ROCKER IND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695752-1	7-115945	Dual Level Control Valve	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695755-1	1184R125	Retrieving Winch	WESTERN GEAR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695759-7	C7088-1A	Wing Flap Drive Gearbox	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695760-1	465C-59NW	Valve	AUTO VALVE INC.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695762-3	1012200-4	Ramp Control Valve Assy	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695769-1	60-371B	Fuel Booster Pump Assembly	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695769-3	123510-011-01	Fuel Booster Pump	PESCO	OH/REP/TEST	C130;L100	PLEASE CONTACT US

695775-1	C7041-1	Aileron Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695775-2	C7041-2	Rudder Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695789-11	A456-1	Landing Gear Control Unit	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695792-2	A-700AQ-4	Reverse Current Cut Out	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695795-1	B-124K	Contactora	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695797-1	JG402A2	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695797-3	JG402A3	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695797-5	JG402A4	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695797-9	JG412A2	Fuel Quantity Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695805-1	26130010-01	Shut Off Valve	SUNDSTRAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695807-1	880T100	Linear Actuator	TELEFLEX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695807-5	L16-8-5	Linear Actuator	GEC-MARCONI	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695810-3	UA524240-1	Fuel Heater Strainer	UNITED AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695812-2	132555-1	Shutoff Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695813-1	CYLB51055	Engine Bleed Air Check Valve	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695833-1	1111-578574	Valve Fuel Check	LOCKHEED	TEST ONLY	C130;L100	PLEASE CONTACT US
695855-5	1000	Oven Assembly	SPERRY FRANK INC.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695872-1	10-1026	Hydraulic Valve Assy	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695890-51	XW20345-318-46	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695915-1	1112-587331	Valve	LOCKHEED	TEST ONLY	C130;L100	PLEASE CONTACT US
695919-1	AC-2291-104	Hydraulic Oil Filter	AIRCRAFT POROUS MED.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695943-3	M9201A-1B	Vane Axial Fan	DYNAMIC AIR ENG.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695960-1	A487-3	Elevator Trim Tab Screw Jack	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
695960-3	A487-4	Elevator Trim Tab Screw Jack	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
696-1-18		Multi-Pointer Indicator	SCHLUMBERGER	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
69-69882-1		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
69-69882-2		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
69-69882-3		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
69-69882-4		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
69-69882-5		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
69-69882-6		Hydraulic Swivel Assembly	BOEING	OH/REP/TEST	B737	PLEASE CONTACT US
697100AA000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
697100AB000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
697149-1	98G41-1	Low Pressure Switch	CUSTOM COMPONENTS	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
697195-1	8118	Aileron Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697195-3	8118A	Rudder Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697218-1	411600-3	Oil Tank Relief Valve	ACCESSORY PRODUCTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697219-1	70262	Restrictor Valve	ADEL-CRANE HYD-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697226-1	5A527	Oil Cooler	STANDARD THOMSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697232-1	MF30-3913-30ZE5	Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697234-3	3A016	Pressure Reducing Valve	ARKWIN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697235-1	540538-2-1	Linear Actuator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697244-1	6829274	Torquemeter Indicator	TEXAS INSTRUMENTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697260-1	13V600-6	Shuttle Valve	ALTAIR-GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697283-1	9900-39	Regulator Valve	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US

697396-1	40-621	Wheel Speed Transducer	CRANE HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697397-1	39-075A	Dual Pressure Control Valve	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697397-3	39-075	Dual Pressure Control Valve	HYDRO-AIRE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
697489-1	219A967	Nose Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
698611-1		Torquemeter Indicator	TEXAS INSTRUMENTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
698900AA000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
698900AB000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
698900AC000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
699000AA000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
699000AB000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
6F2136		Restrictor Valve	CRISSAIR	OH/REP/TEST	DC9;MD83	PLEASE CONTACT US
6F2190		Restrictor Valve	CRISSAIR	OH/REP/TEST	DC9;MD83	PLEASE CONTACT US
6F2314		Restrictor Check Valve	CRISSAIR	OH/REP/TEST	DC9;MD83	PLEASE CONTACT US
6F2322		Restrictor Valve	CRISSAIR	OH/REP/TEST	DC9;MD83	PLEASE CONTACT US
6F2362		Restrictor Valve	CRISSAIR	OH/REP/TEST	B707;B737	PLEASE CONTACT US
6F2380		Restrictor Valve	CRISSAIR	OH/REP/TEST	DC9;MD83	PLEASE CONTACT US
6F2396		Restrictor Valve	CRISSAIR	OH/REP/TEST	B737	PLEASE CONTACT US
6F2436		Restrictor Valve	CRISSAIR	OH/REP/TEST	B737	PLEASE CONTACT US
6F2604		Restrictor Valve	CRISSAIR	OH/REP/TEST	B737	PLEASE CONTACT US
6F2624		Restrictor Valve	CRISSAIR	OH/REP/TEST	B737	PLEASE CONTACT US
6F2626		Restrictor Valve	CRISSAIR	OH/REP/TEST	B737	PLEASE CONTACT US
6F2628		Restrictor Valve	CRISSAIR	OH/REP/TEST	B737	PLEASE CONTACT US
70-0039-3		Strobe Light Flasher	GRIMES	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
700-1-12680		Protection Unit	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
700-1-12980		Undervoltage Protection Unit	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
7047M1		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	B737	PLEASE CONTACT US
7047M2		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	B737	PLEASE CONTACT US
7047M3		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	B737	PLEASE CONTACT US
706AA16		Non Return Valve	FLIGHT REFUELLING	OH/REP/TEST	F27	PLEASE CONTACT US
708CB02/2		Non Return Valve	FLIGHT REFUELLING	OH/REP/TEST	HS748	PLEASE CONTACT US
71-100-1		Nose Gear Leg Assembly	DE HAVILLAND/HEROUX	OH/REP/TEST	DHC-7;DHC-6	PLEASE CONTACT US
7-115945		Dual Level Control Valve	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
71190400010NCOA		Sampling Valve	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
71-200-1		Steering Actuator Assembly	DE HAVILLAND/HEROUX	OH/REP/TEST	DHC-6	PLEASE CONTACT US
7-1261-5		Hand Pump	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
724CU-4-012		True Airspeed Indicator	KOLLSMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
724DX-4-012		True Airspeed Indicator	KOLLSMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
72532-1		Check Valve	CRANE-HYDRO AIRE	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
72532-2		Check Valve	CRANE-HYDRO AIRE	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
72532-3		Check Valve	CRANE-HYDRO AIRE	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
72553-2		NLG Ret/Actuator Shuttle Valve	CRANE HYDRO-AIRE	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
72554-4		MLG Ret/Actuator Relief Valve	CRANE HYDRO-AIRE	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
72554-5		MLG Ret/Actuator Relief Valve	CRANE HYDRO-AIRE	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
72555-2		NLG Ret/Actuator Relief Valve	CRANE HYDRO-AIRE	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
72556-1		MLG Bogie Positioner Valve	CRANE HYDRO-AIRE	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US

731300-3		Dual Level Control Valve	ACCESSORY PRODUCTS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
732-16660-01		Check Valve	SHIMADZU	OH/REP/TEST	B737	PLEASE CONTACT US
732-16810-01		Lateral Trim Actuator	SHIMADZU CORP	OH/REP/TEST	B747;B757;B767	PLEASE CONTACT US
738440A		Charge Pump	SUNDSTRAND	OH/REP/TEST	F100	PLEASE CONTACT US
738440B		Charge Pump	SUNDSTRAND	OH/REP/TEST	F100	PLEASE CONTACT US
73AM		Cabin Height Indicator	SMITHS	OH/REP/TEST	BAE125;HS748;F27	PLEASE CONTACT US
74AM		Altimeter	SMITHS	OH/REP/TEST	HELI	PLEASE CONTACT US
7572-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
7572-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
7572-3		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
7572-4		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
75D30-1		Differential Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	DC9;MD80;MD90	PLEASE CONTACT US
75MA1-571	D101588	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
7609-37-H5-1		Pressure Transmitter	BENDIX-MONTROSE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
7-702755		Dual Level Control Valve	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
7707-111A25-1	3567707-9801	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7707-2-C5-1	3567707-0202	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7707-2-D5-1	3567707-0203	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7707-30-A23-1	3567707-3004	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7707-30-B8-2	3567707-3005	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7707-30-D5-1	3567707-3001	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7707-30-D5-2	3567707-3002	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7707-7-A5-1	3567707-0701	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7707-99-A5-1	3567707-9901	Pressure Transmitter	BENDIX	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
7709-15-B5-1	3567709-1501	Pressure Transmitter (Ms28005-1)	BENDIX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
7709-55-B8-1	3567709-5501	Pressure Transmitter	BENDIX	OH/REP/TEST	TBD	PLEASE CONTACT US
7709-72-A5-2	3567709-7201	Pressure Transmitter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
7709-72-B8-1	3567709-7202	Pressure Transmitter	BENDIX	OH/REP/TEST	F27	PLEASE CONTACT US
7-716835		Dual Level Control Valve	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
78-10066-748		Cyclic De Icing Switch	NORTHERN AERO	OH/REP/TEST	F27	PLEASE CONTACT US
78-10066BP		Cyclic De Icing Switch	NORTHERN AERO	OH/REP/TEST	F27	PLEASE CONTACT US
78-10066BP-C		Cyclic De Icing Switch	NORTHERN AERO	OH/REP/TEST	F27	PLEASE CONTACT US
782689-1		Brush Block Housing Assembly	HAMILTON STANDARD	OH/REP/TEST	ATR72; DHC8	PLEASE CONTACT US
782689-2		Brush Block Housing Assembly	HAMILTON STANDARD	OH/REP/TEST	ATR72	PLEASE CONTACT US
782689-3		Brush Block Housing Assembly	HAMILTON STANDARD	OH/REP/TEST	DHC8	PLEASE CONTACT US
782689-4		Brush Block Housing Assembly	HAMILTON STANDARD	OH/REP/TEST	ATR72	PLEASE CONTACT US
782689-5		Brush Block Housing Assembly	HAMILTON STANDARD	OH/REP/TEST	DHC8	PLEASE CONTACT US
782689-6		Brush Block Housing Assembly	HAMILTON STANDARD	OH/REP/TEST	ATR72;DHC8	PLEASE CONTACT US
78500-A2		Master Valve Assembly	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
786PG/SB		Torque Pressure Transmitter	SMITHS	OH/REP/TEST	F27;GS1;HRLD	PLEASE CONTACT US
7913001F		Spherical Plug Valve	FLIGHT REFUELLING	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
792PG/SB		Differential Pressure Switch	SMITHS	OH/REP/TEST	HS748;F27;HRLD	PLEASE CONTACT US
7933141J		Spherical Plug Valve	FLIGHT REFUELLING	OH/REP/TEST	F100	PLEASE CONTACT US
7933156J		Spherical Plug Valve	FLIGHT REFUELLING	OH/REP/TEST	F100	PLEASE CONTACT US
7980-1		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US

7980-2		Selector Valve Assembly	WHITTAKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
7CZ105648		Relay	GEC	TEST ONLY	HS748	PLEASE CONTACT US
7CZ105648/1	7CZ105648-1	Relay	GEC	TEST ONLY	HS748	PLEASE CONTACT US
7CZ105648/2	7CZ105648-2	Relay	GEC	TEST ONLY	HS748	PLEASE CONTACT US
7CZ105649		Relay	GEC	TEST ONLY	HS748	PLEASE CONTACT US
7CZ105649/1	7CZ105649-1	Relay	GEC	TEST ONLY	HS748	PLEASE CONTACT US
7CZ105649/2	7CZ105649-2	Relay	GEC	TEST ONLY	HS748	PLEASE CONTACT US
7CZ105834		Relay	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
7CZ106800/8		Controller Type 4 Mk.1	GEC	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
7CZ106800/9		Controller Type 4 Mk.1	GEC	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
7CZ107352		Relay	GEC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
7CZ107626		Magnetic Indicator	GEC	OH/REP/TEST	BAC111(CofC only);HS748;F27	PLEASE CONTACT US
7CZ143684		Magnetic Indicator	GEC	OH/REP/TEST	SD330;SD360	PLEASE CONTACT US
7CZ97508-1		Relay	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
7G110-3		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B707;B737;B747;B757;B767	PLEASE CONTACT US
7G110-6		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B727;B737	PLEASE CONTACT US
7G754		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B757	PLEASE CONTACT US
7G754-2		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B757	PLEASE CONTACT US
80-0300-1		Centralised Warning Panel	GRIMES	OH/REP/TEST	LYNX	PLEASE CONTACT US
8037M1	695700-3	Elevator Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8037M2	695700-3	Elevator Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8059-2B		Airspeed Indicator	AERO MECHANISM	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
8067-1A		Elevator Trim Tab Screwjack	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8067-2A		Elevator Trim Tab Screwjack	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8067-3A		Elevator Trim Tab Screwjack	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
806740-401		Coffee Maker	WEBER AIRCRAFT	OH/REP/TEST	B707;B727;B737;DC10	PLEASE CONTACT US
806740-403		Coffee Maker	WEBER AIRCRAFT	OH/REP/TEST	B707;B727;B737;DC10	PLEASE CONTACT US
806740-405		Coffee Maker	WEBER AIRCRAFT	OH/REP/TEST	B707;B727;B737;DC10	PLEASE CONTACT US
806740-407		Coffee Maker	WEBER AIRCRAFT	OH/REP/TEST	B707;B727;B737;DC10	PLEASE CONTACT US
8067-4A		Elevator Trim Tab Screwjack	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
80810-1	S271T462-2	Reservoir Fill Selector Valve	EATON	OH/REP/TEST	B727;B737	PLEASE CONTACT US
8101-000-400		Engine Mount Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
8101-000-401		Engine Mount Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
8101-000-403		Engine Mount Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
8101-000-405		Engine Mount Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
8101-000-407		Engine Mount Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
81037SHT29		Strut Engine Mount	BRITISH AEROSPACE	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
810-4		Hydraulic Fuse	WATERMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
810-8		Hydraulic Fuse	WATERMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
811-6		Hydraulic Fuse	WATERMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
81-1774		Centralised Warning Panel	GRIMES	OH/REP/TEST	LYNX	PLEASE CONTACT US
811-8		Hydraulic Fuse	WATERMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8118A	697195-3	Rudder Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
811B		Digital Clock	DAVTRON	OH/REP/TEST	BAE125	PLEASE CONTACT US
8127-003-401		Fuel Heater Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US

8127-003-403	27.1-8127-003	Fuel Heater Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
8127-003-901		Fuel Heater Assembly	FOKKER	OH/REP/TEST	F27	PLEASE CONTACT US
813640-401		Oven Assembly	WEBER	OH/REP/TEST	TBD	PLEASE CONTACT US
813640-407		Oven Assembly	WEBER	OH/REP/TEST	TBD	PLEASE CONTACT US
8160-121		Starter Generator	AUXILEC	OH/REP/TEST	DO328	PLEASE CONTACT US
816629-401		Rotary Actuator	WEBER	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
816629-405		Rotary Actuator	WEBER	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
81940-3	695295	Water Separator	AIRESEARCH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8256M1		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	DC10	PLEASE CONTACT US
8256M2		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	DC10	PLEASE CONTACT US
8256M3		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	DC10	PLEASE CONTACT US
8256M4		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	DC10	PLEASE CONTACT US
8260-121		Starter Generator	THALES	OH/REP/TEST	ATR42	PLEASE CONTACT US
8260-123		Starter Generator	THALES	OH/REP/TEST	ATR42	PLEASE CONTACT US
830-8		Hydraulic Fuse	WATERMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
83120-0		Water Separator	AIRESEARCH	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
83120-2-1		Water Separator	AIRESEARCH	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
831-8		Hydraulic Fuse	WATERMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8340922-30		Main Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8340922-50		Main Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8348M1	695579-69	Manual Gear Box With Brake	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
836390-403		Coffee Maker	WEBER AIRCRAFT	OH/REP/TEST	A320	PLEASE CONTACT US
836390-409		Coffee Maker	WEBER AIRCRAFT	OH/REP/TEST	A320	PLEASE CONTACT US
836390-411		Coffee Maker	WEBER AIRCRAFT	OH/REP/TEST	A320	PLEASE CONTACT US
837SD-8-6-50		Quantity Measuring Fuse	WATERMAN HYD CORP	OH/REP/TEST	DC8	PLEASE CONTACT US
838550-401		Oven Assembly	WEBER	OH/REP/TEST	A320	PLEASE CONTACT US
838FL/BR		Desynn Position Transmitter	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
838FL/BU		Desynn Position Transmitter	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
8408-1		Yaw Trim Actuator	SAGEM	OH/REP/TEST	DO328	PLEASE CONTACT US
8409-1		Pitch Trim Actuator	SAGEM	OH/REP/TEST	DO328	PLEASE CONTACT US
8409-2		Pitch Trim Actuator	SAGEM	OH/REP/TEST	DO328	PLEASE CONTACT US
8409-3		Pitch Trim Actuator	SAGEM	OH/REP/TEST	DO328	PLEASE CONTACT US
8410-1		Roll Trim Actuator	SAGEM	OH/REP/TEST	DO328	PLEASE CONTACT US
841FL/BR		Desynn Position Transmitter	SMITHS	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
841FL/BU		Desynn Position Transmitter	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
8421-001	MS28700-1	Hydraulic Accumulator	YORK INDUSTRIES	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8422-001		Hydraulic Accumulator	YORK INDUSTRIES	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8422-030		Hydraulic Accumulator	YORK INDUSTRIES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8424-001	MS28700-4	Hydraulic Accumulator	YORK INDUSTRIES	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8428-1		Limiter Actuator	SAGEM	TEST ONLY	DO328	PLEASE CONTACT US
8428-2		Limiter Actuator	SAGEM	TEST ONLY	DO328	PLEASE CONTACT US
8428-3		Limiter Actuator	SAGEM	TEST ONLY	DO328	PLEASE CONTACT US
8428-4		Limiter Actuator	SAGEM	TEST ONLY	DO328	PLEASE CONTACT US
8430M1		MLG Ballscrew Assembly	CEF INDUSTRIES (CALCO)	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
8430M2		MLG Ballscrew Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US

8430M3		MLG Ballscrew Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8430M4		MLG Ballscrew Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8432-1		Stick Pusher Actuator	SAGEM	OH/REP/TEST	DO328	PLEASE CONTACT US
8440-2		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8445M1		Wing Flap Actuator Assembly (Inboard)	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8446M1		Wing Flap Actuator Assembly (Outboard)	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
85027-1	695294-21	Cooling Turbine Heat Exchanger	AIRESEARCH	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
8518-5A		Elevator Trim Tab Actuator Screwjack	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8518-6A		Elevator Trim Tab Actuator Screwjack	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8545M1		Wing Flap Ballscrew Assembly (Inboard)	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8546M1		Wing Flap Ballscrew Assembly (Outboard)	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M1		Landing Light Actuator Assy	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M2		Landing Light Actuator Assy	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M3		Landing Light Actuator Assy	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M4		Landing Light Actuator Assy	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M5		Landing Light Actuator Assy	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M6		Landing Light Actuator Assy	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M7		Landing Light Actuator Assy	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M8		Landing Light	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8555M9		Landing Light	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
85900-A1		Master Valve Assembly	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
8656M2		Oil Cooler Door Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
880T100	695807-1	Linear Actuator	TELEFLEX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
880T100-3		Linear Actuator	TELEFLEX	OH/REP/TEST	C130;L100	PLEASE CONTACT US
890405-0100-01		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890405-0100-02		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890405-0100-03		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890405-0300-01		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890405-1000-01		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890405-1000-02		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890405-1000-03		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890406-0090-01		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890406-0090-03		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890406-0100-01		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890406-0100-02		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890406-0100-03		Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890409-1000		Pneumatic Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890409-1100		Pneumatic Pressure Reducer	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890411-02		Solenoid Valve Assembly	VALCOR	OH/REP/TEST	F27	PLEASE CONTACT US
890FL		Desynn Position Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
8921270G2		Heated Drain Mast Assy	B F GOODRICH	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
8921270G4		Heated Drain Mast Assy	B F GOODRICH	OH/REP/TEST	B737;B747	PLEASE CONTACT US
8921340G1		Lavatory Water Heater	GOODRICH ICE PROT.	OH/REP/TEST	B757	PLEASE CONTACT US
892541-100		Fire Detector Control Unit	WALTER KIDDE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8AW59FAA1		Frequency Meter	GENERAL ELECTRIC	OH/REP/TEST	BAC111(CofC only);C130	PLEASE CONTACT US

8AW59FAC1		Frequency Meter	GENERAL ELECTRIC	OH/REP/TEST	BAC111(CofC only);B707	PLEASE CONTACT US
8AW59HAH1		AC Watt-Varmeter	GENERAL ELECTRIC	OH/REP/TEST	B707	PLEASE CONTACT US
8AW60F2AA1		Frequency Indicator	GENERAL ELECTRIC	OH/REP/TEST	B707	PLEASE CONTACT US
8C(2)	53433-003	Inertia Switch	KIDDE GRAVINER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8C167		Manifold Drain Valve	ALLEN	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
8DJ100AAA1		Temperature Indicator	AMETEK	OH/REP/TEST	GS11	PLEASE CONTACT US
8DJ100WBD2		Temperature Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8DJ125LWF4		Flowmeter Indicator	AMETEK	OH/REP/TEST	B737;DC8;DC9;DC10;MD80	PLEASE CONTACT US
8DJ125LWR3		Flowmeter Indicator	AMETEK	OH/REP/TEST	B737;DC8;DC9;DC10;MD80	PLEASE CONTACT US
8DJ125LWR4		Flowmeter Indicator	AMETEK	OH/REP/TEST	B737;DC8;DC9;DC10;MD80	PLEASE CONTACT US
8DJ125LXC3		Flowmeter Indicator	AMETEK	OH/REP/TEST	B737;DC8;DC9;DC10;MD80	PLEASE CONTACT US
8DJ125LXC4		Flowmeter Indicator	AMETEK	OH/REP/TEST	B737;DC8;DC9;DC10;MD80	PLEASE CONTACT US
8DJ125LXE4		Flowmeter Indicator	AMETEK	OH/REP/TEST	B737;DC8;DC9;DC10;MD80	PLEASE CONTACT US
8DJ172LWA1		Oil Quantity Indicator	AMETEK	OH/REP/TEST	DC10	PLEASE CONTACT US
8DJ172LWD1		Oil Quantity Indicator	AMETEK	OH/REP/TEST	DC10	PLEASE CONTACT US
8DJ172LWE1		Oil Quantity Indicator	AMETEK	OH/REP/TEST	DC10	PLEASE CONTACT US
8DJ172LWK1		Oil Quantity Indicator	AMETEK	OH/REP/TEST	DC10	PLEASE CONTACT US
8DJ172LWR1		Oil Quantity Indicator	AMETEK	OH/REP/TEST	DC10	PLEASE CONTACT US
8DJ172LWY1		Oil Quantity Indicator	AMETEK	OH/REP/TEST	DC10	PLEASE CONTACT US
8DJ174LWA1		EPR Indicator	GENERAL ELECTRIC	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
8DJ174LWM1		EPR Indicator	GENERAL ELECTRIC	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
8DJ174LWP1		EPR Indicator	GENERAL ELECTRIC	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
8DJ175LXV1		T.G.T. Indicator	GENERAL ELECTRIC	OH/REP/TEST	B747;DC10;TRIS	PLEASE CONTACT US
8DJ179KBA2		Temperature Indicator	AMETEK	OH/REP/TEST	B727;B737	PLEASE CONTACT US
8DJ179LAD4		Temperature Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8DJ179WAD1		Temperature Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8DJ179WAD4		Temperature Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8DJ185LWE1		Turbine Temperature Indicator	GENERAL ELECTRIC	OH/REP/TEST	DC10;TRIS	PLEASE CONTACT US
8DJ186LWF1		Engine Speed Indicator	GENERAL ELECTRIC	OH/REP/TEST	DC10;TRIS	PLEASE CONTACT US
8DJ186LWW1		Engine Speed Indicator	GENERAL ELECTRIC	OH/REP/TEST	DC10;TRIS	PLEASE CONTACT US
8DJ48FAL2	MS28023-1	Oil Flap Position Indicator	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8DJ48FAR2	695187-1	Oil Flap Position Indicator	GENERAL ELECTRIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GAW1		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GAW2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GAX1		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GAX2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GAY1		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GAY2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GBV2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GEP2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GER2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49GET2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LAL2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LAM2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LAN2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US

8DJ49LAV2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LBK2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LBL2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LBM2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LWC2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LWD2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LWE2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LWF2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LWG2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ49LWH2		Position Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ64GAF1		Flowmeter Indicator	AMETEK	OH/REP/TEST	C130;ELEC	PLEASE CONTACT US
8DJ64GAS1		Flowmeter Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ64GAT1		Flowmeter Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ64GAX1		Flowmeter Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ64GBA1		Flowmeter Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ64GBC1		Flowmeter Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8DJ64GBH1		Flowmeter Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ64GBW1		Flowmeter Indicator	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8DJ71GAB1		Rate Of Fuel Flow Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8DJ71GAK2		Rate Of Fuel Flow Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8DJ81BLB4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81BLC4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81CAA1		Tachometer Indicator	AMETEK	OH/REP/TEST	B707;SEA KING	PLEASE CONTACT US
8DJ81CAA2		Tachometer Indicator	AMETEK	OH/REP/TEST	B707;SEA KING	PLEASE CONTACT US
8DJ81CAA4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CAN4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CBD4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;B707;B737;DC8;DC9;DC1	PLEASE CONTACT US
8DJ81CDR4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CDS4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CDW4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CDX4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CDY4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CDZ4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CER4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81CFA4		Tachometer Indicator	AMETEK	OH/REP/TEST	C130;L100;L382;B707;B737;DC8;DC9	PLEASE CONTACT US
8DJ81LAA4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LBS2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LCP4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LCR4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LCT4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LSC4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LVA4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LVB4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LVF4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LVG4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US

8DJ81LVL4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWA4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWC4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWM2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWN2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWR2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWR4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWS4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWT2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWT4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWY4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LWZ4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LXF4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LXG2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LXG4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LXH4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LXK2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LXK4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LXT4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LYP4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LYT2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LYT4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LYV2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LYV4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LYX4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LZC4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LZE2		Tachometer Indicator	AMETEK	OH/REP/TEST	GS1	PLEASE CONTACT US
8DJ81LZE4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LZF2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81LZF4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WAG2		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WAG4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WAL4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WAP4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WAP4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WAY4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WAY4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBA4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBB4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBC4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBD4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBF4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBG4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBL4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBM4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US

8DJ81WBS4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WBT4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WCF4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WCG4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WCR4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WCS4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WCT4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WCW4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WCX4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WDK4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ81WDL4		Tachometer Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8DJ88LWC3		Flowmeter Indicator	AMETEK	OH/REP/TEST	B727;B737	PLEASE CONTACT US
8DJ88LWD3		Flowmeter Indicator	AMETEK	OH/REP/TEST	B727;B737	PLEASE CONTACT US
8DJ88LWH3		Flowmeter Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
8DJ88LWK3		Flowmeter Indicator	AMETEK	OH/REP/TEST	GSII	PLEASE CONTACT US
8DJ88LWM3		Flowmeter Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
8DJ88LWY3		Flowmeter Indicator	AMETEK	OH/REP/TEST	B727;B737	PLEASE CONTACT US
8DJ88LXC3		Flowmeter Indicator	AMETEK	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
8E5002769-03		Power Supply Unit	HELLA	OH/REP/TEST	TBD	PLEASE CONTACT US
8E5004631-00		Power Unit	HELLA	OH/REP/TEST	A310	PLEASE CONTACT US
8E5005304-00		Power Supply Unit (Energy Box)	HELLA	OH/REP/TEST	A320;A340	PLEASE CONTACT US
8E5005309-00		Power Supply Unit (Energy Box)	HELLA	OH/REP/TEST	A320;A340	PLEASE CONTACT US
8G441-1		Gage Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	MD80;MD90	PLEASE CONTACT US
8TJ124GGC1		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B757	PLEASE CONTACT US
8TJ124GGD3	9377M61P01	Fuel Flow Transmitter	AMETEK	OH/REP/TEST	A300;A310;B747;B767/MD11	PLEASE CONTACT US
8TJ124GGL1		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B757	PLEASE CONTACT US
8TJ124GGM1		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B737	PLEASE CONTACT US
8TJ124GGR1	1324M10P01	Fuel Flow Transmitter	AMETEK	OH/REP/TEST	A318;A319;A320;A321;A340	PLEASE CONTACT US
8TJ124GGT1	9377M61P02	Fuel Flow Transmitter	AMETEK	OH/REP/TEST	A310	PLEASE CONTACT US
8TJ124GHG1	1324M10P02	Fuel Flow Transmitter	AMETEK	OH/REP/TEST	A318;A319;A320;A321;A340	PLEASE CONTACT US
8TJ146AAA1	9377M45P02	Oil Level Sensor	AMETEK	OH/REP/TEST	A300	PLEASE CONTACT US
8TJ50GAB1		Flowmeter Transmitter	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ50GAB3		Flowmeter Transmitter	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ50GAS4		Flowmeter Transmitter	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ50GAS5		Flowmeter Transmitter	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ50GAY3		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B707;B727	PLEASE CONTACT US
8TJ50GBM5		Flowmeter Transmitter	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ50GBX3		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B707;B727	PLEASE CONTACT US
8TJ50GBX4		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B707;B727	PLEASE CONTACT US
8TJ50GBZ3		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B707;B727	PLEASE CONTACT US
8TJ50GCA3		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B707;B727	PLEASE CONTACT US
8TJ50GCE3		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B707;B727	PLEASE CONTACT US
8TJ50GCE4		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	B707;B727	PLEASE CONTACT US
8TJ51GAA1		Flowmeter Power Supply	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ51GAA2		Flowmeter Power Supply	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US

8TJ51GAA4		Flowmeter Power Supply	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ51GAA5		Flowmeter Power Supply	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ51GBB5		Flowmeter Power Supply	GENERAL ELECTRIC	OH/REP/TEST	B707;ELEC	PLEASE CONTACT US
8TJ64GAC1		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GAF1		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GAL1		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBA1		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBD1		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBE1		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBK2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBL2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBN2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBR2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBS2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GBW2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
8TJ64GCC2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GCM2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ64GDT2		Flowmeter Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
8TJ80GAA1		Flowmeter Power Supply	AMETEK	OH/REP/TEST	B737	PLEASE CONTACT US
8TJ80GAA2		Flowmeter Power Supply	AMETEK	OH/REP/TEST	B737	PLEASE CONTACT US
8TJ85GAK1		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GAK2		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GAT1		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GAT2		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GAZ1		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GAZ1S		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GAZ2		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GAZ2S		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GBA1		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ85GBA2		Fuel Flow Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only);GS1;B727;B737;	PLEASE CONTACT US
8TJ88GAD1		Fuel Flow Power Supply	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
8TJ88GAD3		Fuel Flow Power Supply	AMETEK	OH/REP/TEST	BAC111(CofC only);B737;DC8;DC9;D	PLEASE CONTACT US
8TJ88GAP1		Fuel Flow Power Supply	AMETEK	OH/REP/TEST	B727;B737	PLEASE CONTACT US
8TJ88GAP3		Fuel Flow Power Supply	AMETEK	OH/REP/TEST	BAC111(CofC only);B737;DC8;DC9;D	PLEASE CONTACT US
8TJ88GAR1		Fuel Flow Power Supply	AMETEK	OH/REP/TEST	FALCON 20DC	PLEASE CONTACT US
8TJ88GAT1		Fuel Flow Power Supply	AMETEK	OH/REP/TEST	BAC111(CofC only);B737;DC8;DC9;D	PLEASE CONTACT US
8TJ88GAV1		Fuel Flow Power Supply	AMETEK	OH/REP/TEST	GII	PLEASE CONTACT US
8TJ99GBC1		Liquid Quantity Transmitter	ALLIED SIGNAL	OH/REP/TEST	MD11;B747	PLEASE CONTACT US
8TJ99GBU2		Liquid Level Transmitter	AMETEK	OH/REP/TEST	B757	PLEASE CONTACT US
8TJ99GGE1		Liquid Level Transmitter	AMETEK	OH/REP/TEST	B747;B757;B767	PLEASE CONTACT US
90000233-1		Main Wheel Assembly	MEGGITT	OH/REP/TEST	HAWKER 4000	PLEASE CONTACT US
90000581-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	EMB170;EMB190	PLEASE CONTACT US
90002021-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	DO328	PLEASE CONTACT US
90002024-1		Main Wheel Assembly	ABSC	OH/REP/TEST	DO328	PLEASE CONTACT US
90002317-1		Main Wheel Assembly	MEGGITT	OH/REP/TEST	EMB-195	PLEASE CONTACT US

90002317-2		Main Wheel Assembly	MEGGITT	OH/REP/TEST	EMB-195	PLEASE CONTACT US
90002746-1		Nose Wheel Assembly	MEGGITT	OH/REP/TEST	FALCON 7X	PLEASE CONTACT US
90005023-1		Nose Wheel Assembly	MEGGITT	OH/REP/TEST	EMB-500	PLEASE CONTACT US
90-10072		Entry Door Snubber Assembly	BOEING	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
90-10072-1		Entry Door Snubber Assembly	BOEING	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
90-10072-2		Entry Door Snubber Assembly	BOEING	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
90-2247-3000		Rod Assy Door Radius	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
90-5265		NLG Retention Actuator Assy	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
9057-3619		Relay	LEACH	OH/REP/TEST	F27	PLEASE CONTACT US
905D977-3		Volt Regulator	SUNDSTRAND	OH/REP/TEST	B707	PLEASE CONTACT US
907FL		Desynn Position Transmitter	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
90C13		Aircraft Heater Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
90G137		Hydraulic Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
90G37		Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	B737;B747;DC10	PLEASE CONTACT US
90G62-1A		Gage Pressure Switch	CUSTOM COMPONENTS	OH/REP/TEST	DC8;DC9;MD83	PLEASE CONTACT US
9100-3-C3		Fuel Flow Transmitter	BENDIX	OH/REP/TEST	GS1	PLEASE CONTACT US
910FL		Desynn Position Transmitter	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
9-112-01		Fuel Flow Transmitter	CRANE-ELDEC	OH/REP/TEST	B747;MD90	PLEASE CONTACT US
9-114-02		Fuel Flow Transmitter	CRANE-ELDEC	OH/REP/TEST	B747;DC10	PLEASE CONTACT US
9-114-04		Fuel Flow Transmitter	CRANE-ELDEC	OH/REP/TEST	A300;B747	PLEASE CONTACT US
9-114-05		Fuel Flow Transmitter	CRANE-ELDEC	OH/REP/TEST	A300;B747	PLEASE CONTACT US
9-114-06		Fuel Flow Transmitter	CRANE-ELDEC	OH/REP/TEST	A300;B747	PLEASE CONTACT US
9120-1		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9120-2		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9-127-48		Fuel Flow Transmitter	CRANE-ELDEC	OH/REP/TEST	BAE146	PLEASE CONTACT US
915F213-3		Bus Protection Panel	HAM-SUND/WESTINGHOUSE	OH/REP/TEST	B737	PLEASE CONTACT US
915F213-4		Bus Protection Panel	HAM-SUND/WESTINGHOUSE	OH/REP/TEST	B737	PLEASE CONTACT US
9180-1		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9180-2		Four Way Selector Valve	WESTON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9254-1		Relay	LEACH	OH/REP/TEST	F27	PLEASE CONTACT US
9274-3765		Relay	LEACH	OH/REP/TEST	F27	PLEASE CONTACT US
9-328-19		Fuel Flow Indicator	ELDEC	OH/REP/TEST	BAE146	PLEASE CONTACT US
9-328-20		Fuel Flow Indicator	CRANE-ELDEC	OH/REP/TEST	BAE146	PLEASE CONTACT US
9330-4026		Relay	LEACH	OH/REP/TEST	F27	PLEASE CONTACT US
941D335-2		Circuit Breaker	WESTINGHOUSE	OH/REP/TEST	B737	PLEASE CONTACT US
941D335-4		Circuit Breaker	WESTINGHOUSE	OH/REP/TEST	B737	PLEASE CONTACT US
941D339-1		Current Transformer	SUNDSTRAND	OH/REP/TEST	B737	PLEASE CONTACT US
941D340-1		Current Transformer	SUNDSTRAND	OH/REP/TEST	B737	PLEASE CONTACT US
952800AA000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
952800BB000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
9543705-1		Nose Wheel Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
9543809-1		Main Wheel Assembly	MEGGITT	OH/REP/TEST	FALCON 20	PLEASE CONTACT US
9543991-1		Main Wheel Assembly	ABSC	OH/REP/TEST	LEAR 35	PLEASE CONTACT US
9543991-4		Main Wheel Assembly	ABSC	OH/REP/TEST	LEAR 35	PLEASE CONTACT US
9543991-5		Main Wheel Assembly	ABSC	OH/REP/TEST	LEAR 35	PLEASE CONTACT US

9543991-6		Main Wheel Assembly	ABSC	OH/REP/TEST	LEAR 35	PLEASE CONTACT US
9543991-7		Main Wheel Assembly	ABSC	OH/REP/TEST	LEAR 35	PLEASE CONTACT US
9544207-2		Nose Wheel Assembly	ABSC	OH/REP/TEST	BEECH;CESS;LEAR	PLEASE CONTACT US
9544207-3		Nose Wheel Assembly	ABSC	OH/REP/TEST	BEECH;CESS;LEAR	PLEASE CONTACT US
9544207-4		Nose Wheel Assembly	ABSC	OH/REP/TEST	BEECH;CESS;LEAR 31;FALC2000	PLEASE CONTACT US
9544207-5		Nose Wheel Assembly	ABSC	OH/REP/TEST	BEECH;CESS;LEAR	PLEASE CONTACT US
9544207-6		Nose Wheel Assembly	ABSC	OH/REP/TEST	BEECH;CESS;LEAR	PLEASE CONTACT US
9544207-7		Nose Wheel Assembly	ABSC	OH/REP/TEST	BEECH;CESS;LEAR	PLEASE CONTACT US
9550207-2		Main Wheel Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
9550267-2		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC9;MD83;MD87;MD88;MD90	PLEASE CONTACT US
9550267-3		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC9;MD83;MD87;MD88;MD90	PLEASE CONTACT US
9550267-5		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC9;MD83;MD87;MD88;MD90	PLEASE CONTACT US
9550267-6		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC9;MD83;MD87;MD88;MD90	PLEASE CONTACT US
9550267-6A		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC9;MD83;MD87;MD88;MD90	PLEASE CONTACT US
9550267-7		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC9;MD83;MD87;MD88;MD90	PLEASE CONTACT US
9550267-7A		Nose Wheel Assembly	ABSC	OH/REP/TEST	DC9;MD83;MD87;MD88;MD90	PLEASE CONTACT US
9550377-1		Brake Assembly	ABSC	OH/REP/TEST	DHC-6	PLEASE CONTACT US
9550377-2		Brake Assembly	ABSC	OH/REP/TEST	DHC-6	PLEASE CONTACT US
9550377-4		Brake Assembly	ABSC	OH/REP/TEST	DHC-6	PLEASE CONTACT US
9550463-2		Main Wheel Assembly	ABSC	OH/REP/TEST	F28	PLEASE CONTACT US
9550616-1		Main Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9550616-1		Main Wheel Assembly	ABSC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9550616-1LC		Main Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9560571B		Main Wheel Assembly	BOEING	OH/REP/TEST	B707	PLEASE CONTACT US
9560685-1		Multiple Disk Brake	ABSC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9560685-1		Brake Unit	ABSC	OH/REP/TEST	L382J	PLEASE CONTACT US
9561061-5		Main Wheel Assembly	ABSC	OH/REP/TEST	GS2	PLEASE CONTACT US
9561061-7		Main Wheel Assembly	ABSC	OH/REP/TEST	GS2	PLEASE CONTACT US
9561061-9	1159SC-L203-9	Main Wheel Assembly	ABSC	OH/REP/TEST	GS2	PLEASE CONTACT US
960500AA000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
960500BB000PCOA		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
976J063-2		AC Generator	HAMILTON SUNDSTRAND	OH/REP/TEST	B707;B727	PLEASE CONTACT US
976J119-11		AC Generator	HAMILTON SUNDSTRAND	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
976J119-12		AC Generator	HAMILTON SUNDSTRAND	OH/REP/TEST	B707;B727	PLEASE CONTACT US
976J119-6		AC Generator	HAMILTON SUNDSTRAND	OH/REP/TEST	B707;B727	PLEASE CONTACT US
976J119-8		AC Generator	HAMILTON SUNDSTRAND	OH/REP/TEST	C135F	PLEASE CONTACT US
976J186-3		DC Power Supply	SUNDSTRAND	OH/REP/TEST	F28;F100	PLEASE CONTACT US
976J186-4		DC Power Supply	SUNDSTRAND	OH/REP/TEST	F28;F100	PLEASE CONTACT US
976J255-5		AC Generator	WESTINGHOUSE	OH/REP/TEST	F28	PLEASE CONTACT US
976J366-2		AC Generator	WESTINGHOUSE	OH/REP/TEST	TBD	PLEASE CONTACT US
976J449-1		AC Generator	SUNDSTRAND	OH/REP/TEST	B727;B737	PLEASE CONTACT US
976J498-1		AC Generator	SUNDSTRAND	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
976J498-2		AC Generator	SUNDSTRAND	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
976J598-1		AC Generator	SUNDSTRAND	OH/REP/TEST	B727;B737	PLEASE CONTACT US
9840044H		Non Return Valve	FR-HI TEMP	OH/REP/TEST	F28;F100	PLEASE CONTACT US

98-AA1-542	B92881	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE146	PLEASE CONTACT US
98-AA1-542/2	F103823	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE146	PLEASE CONTACT US
98G41-1	697149-2	Low Pressure Switch	CUSTOM COMPONENTS	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
9900-39	697283-1	Valve Hyd Regulator	STERER	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
99-1836-001		AC Motor Assembly	LUNDY	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
9A022-1	695899-1	Shut Off Valve	ARKWIN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A-1036-2		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A-1040		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A1100		Torquemeter Indicator	TRANSICOIL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A2100		Torquemeter Indicator	TRANSICOIL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A-225		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A-360		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	B707;C130	PLEASE CONTACT US
9A-360HEA		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	B707;C130	PLEASE CONTACT US
9A-375	EHU-15A/A	Temperature Indicator	PENN AIRBOURNE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A-400	MS24569-1	Temperature Indicator	PENN AIRBOURNE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A-4HEA		Lox Quantity Indicator	PENN AIRBORNE PROD.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9A-550	MS24569-1	Temperature Indicator	PENN AIRBOURNE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
9AG		Fuel Quantity Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
A11C30		Ignition Unit	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
A11C30-1M		Ignition Unit	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
A12		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
A-13A-2	400202	A/C Mechanical Clock	WALTHAM PRECISION	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A15522-P1		Clock	HAYDON	OH/REP/TEST	B747	PLEASE CONTACT US
A15544-P1		Clock	HAYDON	OH/REP/TEST	DC10	PLEASE CONTACT US
A15551-P1		Clock	HAYDON	OH/REP/TEST	B747;DC10	PLEASE CONTACT US
A15580P1		Clock	HAYDON	OH/REP/TEST	B747;DC10	PLEASE CONTACT US
A1605		Turn And Slip Indicator	R.C.ALLEN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
A24		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
A24A9430		Windscreen Temperature Controller	WESTINGHOUSE	OH/REP/TEST	F27;F50	PLEASE CONTACT US
A24A9430-1		Windscreen Temperature Controller	WESTINGHOUSE	OH/REP/TEST	F27;F50	PLEASE CONTACT US
A25363-10-003		Rate Of Climb Indicator	KOLLSMAN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
A26877 10 001		Rate Of Climb Indicator	KOLLSMAN	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
A2733-1		Strut Assembly	NORCO	OH/REP/TEST	TBD	PLEASE CONTACT US
A27817 10 001		Tachometer Indicator	KOLLSMAN	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
A28071-11-302		Tacho Generator	KOLLSMAN	OH/REP/TEST	DC8	PLEASE CONTACT US
A3		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
A3615710067		Standby Airspeed Indicator	KOLLSMAN	OH/REP/TEST	B747;B757;B767	PLEASE CONTACT US
A3615710072		Standby Airspeed Indicator	KOLLSMAN	OH/REP/TEST	B747;B767	PLEASE CONTACT US
A36HN		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
A38119 10 001		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	B727;B737	PLEASE CONTACT US
A38119 10 004		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	B727;B737	PLEASE CONTACT US
A3946910014		Air Speed Indicator	KOLLSMAN	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
A3946910035		Airspeed Indicator	KOLLSMAN	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
A40179-10-020		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	BAC111(CofC only);B727;B737	PLEASE CONTACT US
A40179-10-024		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	BAC111(CofC only);B727;B737	PLEASE CONTACT US

A40179-10-025		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	B707	PLEASE CONTACT US
A40179-10-034		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
A4361710001		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	DC10	PLEASE CONTACT US
A456-1	695789-11	Landing Gear Control Unit	AVIONIC PRODUCTS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
A4619710001		Standby Altimeter	KOLLSMAN	OH/REP/TEST	B757;B767	PLEASE CONTACT US
A487-3	695960-1	Elevator Trim Tab Screw Jack	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A487-4	695960-3	Elevator Trim Tab Screw Jack	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A489-3		Elevator Trim Tab Rotary Actuator	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A489-4	695700-3	Elevator Trim Tab Rotary Actuator	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A489-5	695700-3	Elevator Trim Tab Rotary Actuator	LUNDY	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
A49C65		Aircraft Heater Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
A5011809		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
A5011809-1		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
A5011809-2		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
A5011809-3		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
A54C00		Sealed Control Assembly	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
A555-1A		Linear Actuator	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A555-2A		Linear Actuator	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A61499		Pressure Relief Valve	CRANE	OH/REP/TEST	B727;B737	PLEASE CONTACT US
A-700AQ-1		Reverse Current Cut Out	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A-700AQ-4	695792-2	Reverse Current Cut Out	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A701AA		Motor Unit	FR-HITEMP	OH/REP/TEST	HS748	PLEASE CONTACT US
A701AB		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A701AC		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A701AD		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A701AE		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A701EC		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A702AA		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A702AB		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A702AC		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A702AD		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A702AE		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only);HS748	PLEASE CONTACT US
A702CA		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
A702CB		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
A702EC		Motor Unit	FR-HITEMP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
A-703B		Contactactor	HARTMAN	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
A-703CD		Start Contactactor	HARTMAN	OH/REP/TEST	DC9	PLEASE CONTACT US
A-703CSM		Contactactor	HARTMAN	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
A-703FB		Contactactor	HARTMAN	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
A-703FSS		Contactactor	HARTMAN	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
A-703ZS		Contactactor	HARTMAN	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
A70D10		Fuel Pump & Motor Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
A70D19		Fuel Pump & Motor Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
A-825		Frequency Relay	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A-846		Frequency Relay	HARTMAN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US

A-902-3	Frequency Relay	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A9026Y	Uplock Unit	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
A903J803-1	DC Power Supply	WESTINGHOUSE	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
A90C13	Aircraft Heater Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
A9550616	Main Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
A9550616	Main Wheel Assembly	ABSC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AB15A101	L/H APU Engine Mount	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB15A102	R/H APU Engine Mount	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB15A313	APU Engine Mount	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB30A19	Nose U/C Door Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB32A4047	Spring Tie Cable Tensioner	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB33A2225	Gust Damper	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB33A2755	Gust Damper	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB34A3021	Centralising Spring Pot	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB34A3069	Centralizing Spring Pot	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB34A4129	L/H Connecting Rod	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB34A927	L/H Connecting Rod	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A11	Main U/C Support Structure	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A12	Main U/C Support Structure	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A15MK3	Main U/C Downlock Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A1877	Door Stabilizer	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A29	Switch Box Assy	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A43	Switch Box Assy	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A45	Switch Box Assy	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A61	Downlock Switchbox	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB43A911	Downlock Spring Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB44A1509	Twin Relief And Choke Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB44A17	Drive Cam Servo Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB44A1969	Nose U/C Up/Downlock Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB44A1969MK2	Nose U/C Up/Downlock Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB48A1065	Restrictor Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB48A1257	Servo Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB48A1273	Vent Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB48A53	Shuttle Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB48A589	Steering Centre Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB48A69	Steering & Lock Change Over Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB48A781	Door Control Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB48A821	Relay Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AB50B1221	Pressure Release Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC11184	Ram Uplock Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC11654	Brake Control Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC12154	Brake Control Valve	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AC12562	Emergency Selector Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC13228	Emergency Brake Selector Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC13328	Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US

AC13340		Ram Uplock Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC13342		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC13346		Pressure Converter	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC13970		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC13976		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC14444		Control Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC14446		Valve Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC14592		Hydraulic Pressure Reducing Valve	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AC-2291-104	695919-1	Hydraulic Oil Filter	AIRCRAFT POROUS MED.	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
AC43A131		LH Forestay Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC43A3		Shock Absorber Strut	BAE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC43A3MK2		Shock Absorber Strut	BAE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC60150		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC60160		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC60188		Rudder Bias Strut	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC60194		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC61078		Selector Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC61190		Windscreen Wiper Pump Unit	DUNLOP	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AC61348		Brake Control Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC61422		Steering Motor	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC61516		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC61518		Pressure Reducing Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC61520		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC61772		Hydraulic Control Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC61906		Control Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC62136		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC62136-3		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC62142		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC62276		Control Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC62598		Wiper Control Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC62602		Brake Control Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC62838		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC62840		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC62898		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC62982		Brake Control Valve	DUNLOP	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
AC62984		Pressure Reducing Valve	DUNLOP	OH/REP/TEST	VC10	PLEASE CONTACT US
AC63094		Windscreen Wiper Motor	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC63096		Windscreen Wiper Motor	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AC63538		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC63538-2		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC63544		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC63544-2		Maxaret Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC63546		Steering Motor	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC63552		Steering Motor	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC63880		Brake Control Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US

AC64130		Ram Uplock Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC64166		Rudder Bias Strut	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC64208		Selector Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC64240		Brake Control Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC65180		Pressure Regulating Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC65184		Pressure Regulating Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC65216		Axle Mounted Maxaret Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC65218		Axle Mounted Maxaret Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC65716		Control Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC65718		Solenoid Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC66150		Steering Motor	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC66414		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC66472		Brake Control Valve	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AC67002		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67004		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67006		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67006-4		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67008		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67010		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67070		Brake Temperature Indicator	DUNLOP	TEST ONLY	BAE146	PLEASE CONTACT US
AC67132		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67132-4		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67134		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67134-4		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67214		Rudder Bias Strut	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC67352		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC67674		Solenoid Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC67732		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC67738		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC67740		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC67742		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC67764		Pressure Regulating Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC67846		Ram (Nose Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67848		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC67850		Ram (Main Undercarriage)	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AC69006		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC69078		Pressure Regulating Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC69618		Pressure Regulating Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC69648		Pressure Regulating Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AC69784		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC69788		Brake Control Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AC7680-6		Filling Filter Assembly	AIRCRAFT POROUS MED.	OH/REP/TEST	B727;B737;B747;B757;B777	PLEASE CONTACT US
ACA1218		Rudder Bias Strut	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
ACA1266		Pneumatic Spring Return Ram	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
ACA1316		Pneumatic Spring Return Ram	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US

ACC-1-75		Filter Unit	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
ACM16936		Relief Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM17036		Air Filter	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM17708		H.P.Regulator Assy	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM17856		Push Button Switch	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
ACM17892		Pneumatic Isolating Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM18048		Trap Assy Oil And Water	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM18304		Porous Metal Filter	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM18540		Non-Return Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM18798		Hydraulic Pressure Relay	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
ACM18802		Rapid Exhaust Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM18952		Dehydrator	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM18982		Selector Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM19148		Damper Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM19660		Master Cylinder	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
ACM19924		Pressure Switch	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM20344		Reducing Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM20570		Damper Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM20818		Pressure Switch	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM21172		Maxaret Coupling	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
ACM21174		Hydraulic Modulator	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
ACM22070		H.P.Regulator Assy	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM22090		Dehydrator	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM22174		Actuating Arm Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
ACM22176		Actuating Arm Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
ACM22232		Pressure Switch	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
ACM22234		Pressure Switch	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM22372		Hydraulic Coupling Assembly	DUNLOP	TEST ONLY	BAE125	PLEASE CONTACT US
ACM22392		Master Cylinder	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM22394		Shuttle Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM22426		Relief Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM22426-3		Relief Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM22740		Modulator (L/H)	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
ACM22742		Modulator (R/H)	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
ACM23042		Dehydrator	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM23310		Non-Return Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM23442		Rapid Exhaust Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM23460		Master Cylinder	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM23480		Slave Cylinder	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM24698		Pneumatic Relief Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM24892		Relief Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM24900		Pressure Switch	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM25128		Reducing Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM26214		Pneumatic Isolating Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM26230		Pneumatic Isolating Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US

ACM26230-3		Pneumatic Isolating Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM26276		Master Cylinder	DUNLOP	OH/REP/TEST	BAC111(CofC only);SKY	PLEASE CONTACT US
ACM26278		Master Cylinder	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM26592		Pressure Switch	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM26666		Master Cylinder	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACM28076		Wheel Speed Transducer	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
ACM28248		Shuttle Valve	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
ACM28766		Pressure Reducing Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM28786		Air Filter	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM28788		H.P.Regulator Assy	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM28978		H.P.Regulator Assy	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM28980		H.P.Regulator Assy	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM28982		H.P.Regulator Assy	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM29650		Dehydrator	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM30056		Dehydrator	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM30152		Non-Return Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACM30336		Rudder Compensator Damper	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
ACM30368		Twin Modulators	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
ACM30370		Twin Modulators	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
ACO1223		Restrictor	DUNLOP	TEST ONLY	F27	PLEASE CONTACT US
ACO27610		Pressure Switch	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACO29567		Pivot Pin Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACO31060		Shuttle Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACO32268		Non-Return Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACO32270		Non-Return Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
ACO32408		Shuttle Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ACO35772		Pivot Pin Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AD-9221-167		Pressure Line Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
AE20745		Brake Temperature Indicator	DUNLOP	TEST ONLY	BAE146	PLEASE CONTACT US
AE4123 MK1		Linear Actuator	LUCAS	OH/REP/TEST	SD360	PLEASE CONTACT US
AE4540MK1		Actuator	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
AE5600		Under Voltage Phase Sequence Unit	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
AE5600MK1		Under Voltage Phase Sequence Unit	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
AE5601		Under Voltage Phase Sequence Unit	LUCAS	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AE5601MK1		Under Voltage Phase Sequence Unit	LUCAS	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AE5607		Under Voltage Phase Sequence Unit	LUCAS	OH/REP/TEST	BAE125;TRID	PLEASE CONTACT US
AE-9222-242		Dual Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	TBD	PLEASE CONTACT US
AE-9222-243		Dual Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	TBD	PLEASE CONTACT US
AE-9222-243M		Dual Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	TBD	PLEASE CONTACT US
AE-9222-244		Dual Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	TBD	PLEASE CONTACT US
AE-9319-82		Single Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
AE-9319-83		Single Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
AE-9319-83M		Single Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
AE-9319-84		Single Filter Housing	AIRCRAFT POROUS MED.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
AF200		Cabin Pressure Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US

AF200A		Cabin Pressure Indicator	AEROSONIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
AH50786		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH50822		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51123		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51128		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51129		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51292		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51299		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51453		Propeller Brake	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51458		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51461		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51502		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51585		Main Wheel Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51589		Maxaret Unit	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51650		Main Wheel Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51696		Propeller Brake	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51760		Maxaret Unit	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51862		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51892		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51893		Main Wheel Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH51900		Brake Unit	DUNLOP	OH/REP/TEST	HS748;AND	PLEASE CONTACT US
AH51909		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AH51940		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH51953		Brake Unit	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH51955		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52031		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52075		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AH52108		Main Wheel Assembly	DUNLOP	OH/REP/TEST	CASA C212;SKYVAN	PLEASE CONTACT US
AH52109		Brake Unit	DUNLOP	OH/REP/TEST	SKY	PLEASE CONTACT US
AH52206		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AH52216		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52218		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52220		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52222		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52228		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52250		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52279		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52286		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AH52339	25-8UA3-185A	Nose Wheel Assembly	DUNLOP	OH/REP/TEST	HAWKER 125-800XP	PLEASE CONTACT US
AH52443		Main Wheel Assembly	DUNLOP	OH/REP/TEST	CASA C212;SKYVAN	PLEASE CONTACT US
AH52477		Brake Unit	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52479		Brake Unit	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52481		Brake Unit	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52582		Brake Unit	DUNLOP	OH/REP/TEST	VC10	PLEASE CONTACT US
AH52584		Brake Unit	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US

AH52606		Main Wheel Assembly	DUNLOP	OH/REP/TEST	CASA C212;SKYVAN	PLEASE CONTACT US
AH52627		Brake Unit	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52685		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52733		Brake Unit	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52742		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52764		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52765		Brake Unit	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH52786		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AH52802		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH52803		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52805		Hydraulic Plate Brake	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52807		Maxaret Unit	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH52828		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52837		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52838		Main Wheel Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH52841		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52894		Hydraulic Plate Brake	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52899		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH52930		Main Wheel Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH52946		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH53032		Maxaret Unit	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH53166		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH53168		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH53176		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH53177		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH53178		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH53179		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH53180		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH53181		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH53182		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AH53225		Main Wheel Assembly	DUNLOP	OH/REP/TEST	HS748	PLEASE CONTACT US
AH53352		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH53411		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AH54452		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	ATR42;ATR72	PLEASE CONTACT US
AH54474		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	ATR42;ATR72	PLEASE CONTACT US
AH55055		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	G55	PLEASE CONTACT US
AHA1137		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA1211		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AHA1215		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AHA1287		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AHA1288		Brake Unit	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AHA1290	10-61063-20	Nose Wheel Assembly	DUNLOP	OH/REP/TEST	B737	PLEASE CONTACT US
AHA1343		Main Wheel Assembly	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AHA1348		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA1349		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US

AHA1412		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA1413		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA1455		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA1489		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA1490		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA1539		Brake Unit	DUNLOP	OH/REP/TEST	ATP	PLEASE CONTACT US
AHA1558		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA1559		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA1582		Main Wheel Assembly	DUNLOP	OH/REP/TEST	TBD	PLEASE CONTACT US
AHA1606		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AHA1634		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AHA1648	S160N020-6	Main Wheel Assembly	MEGGITT	OH/REP/TEST	B757	PLEASE CONTACT US
AHA1653		Brake Unit	DUNLOP	OH/REP/TEST	ATR72	PLEASE CONTACT US
AHA1663		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
AHA1683		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AHA1686		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AHA1737		Main Wheel Assembly	DUNLOP	OH/REP/TEST	JETS	PLEASE CONTACT US
AHA1752		Main Wheel Assembly	DUNLOP	OH/REP/TEST	ATR72	PLEASE CONTACT US
AHA1814		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125;HAWKER900XP	PLEASE CONTACT US
AHA1835		Brake Unit	DUNLOP	OH/REP/TEST	JETS41	PLEASE CONTACT US
AHA1881		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AHA1890		Main Wheel Assembly	DUNLOP	OH/REP/TEST	ATR42;ATR72	PLEASE CONTACT US
AHA1892		Brake Unit	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AHA1897		Hydraulic Plate Brake	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AHA1900		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA1925		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2063	1159SCL403-4	Main Wheel Assembly	DUNLOP	OH/REP/TEST	GS4	PLEASE CONTACT US
AHA2114	1159SCL503-5	Main Wheel Assembly	DUNLOP	OH/REP/TEST	GS5	PLEASE CONTACT US
AHA2120		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
AHA2122		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
AHA2141		Nose Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA2174		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA2175		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA2177		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA2178		Brake Unit	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA2218		Main Wheel Assembly	DUNLOP	OH/REP/TEST	BAE146;RJ	PLEASE CONTACT US
AHA2226-2		Main Wheel Assembly	DUNLOP	OH/REP/TEST	DO328	PLEASE CONTACT US
AHA2331		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2331-2		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2331-3		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2331-4		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2332		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2332-2		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2332-3		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2332-4		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US

AHA2334		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2334-2		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2334-3		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2334-4		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2335		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2335-2		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2335-3		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHA2335-4		Brake Unit	DUNLOP	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHM5604		Shuttle Valve	DUNLOP	OH/REP/TEST	F27	PLEASE CONTACT US
AHM5839		Shuttle Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AHM6613		Shuttle Valve	DUNLOP	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AHM8077		Brake Fan Motor	GEC	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHM9050		Brake Fan Motor	AMETEK AIRSCREW	OH/REP/TEST	BAE146	PLEASE CONTACT US
AHO81963		Shuttle Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AHO81964		Shuttle Valve	DUNLOP	OH/REP/TEST	BAE125	PLEASE CONTACT US
AHO85813		Shuttle Valve	DUNLOP	OH/REP/TEST	SKY	PLEASE CONTACT US
AHO85814		Shuttle Valve	DUNLOP	OH/REP/TEST	SKY	PLEASE CONTACT US
AI.895A		Elevator Trim Tab Indicator	APPLEBY & IRELAND	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AI.896C		Elevator Trim Tab Indicator	APPLEBY & IRELAND	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR104000		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR105600		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR108000		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR111500		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR150700		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR150700-11		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR150700-14		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR151900		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR155590		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR158540		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR41194		Pressure Relief Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR41726		Pressure Relief Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR41916		Cut-Out Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR43378		Hand Pump	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44218		Hydraulic Accumulator	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44414		Relief Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44420		Hydraulic Accumulator	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44434		Non Return Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44434-1		Non Return Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44462		Flow Indicator Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44486		Relief Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44494		Non Return Valve	APPH	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AIR44496		Non Return Valve	APPH	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AIR44498		Non Return Valve	APPH	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AIR44504		Flow Indicator Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44508		Non Return Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US

AIR44716		Flow Indicator Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44866		Relief Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR44880		Selector Valve	APPH	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AIR44882		Selector Valve	APPH	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AIR44906		Pressure Relief Valve	APPH	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
AIR45082		Cut-Out Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR45428		Flow Indicator	APPH	OH/REP/TEST	BAE125;HS748	PLEASE CONTACT US
AIR45428/2		Flow Indicator	APPH	OH/REP/TEST	BAE125;HS748	PLEASE CONTACT US
AIR45428/3		Flow Indicator	APPH	OH/REP/TEST	BAE125;HS748	PLEASE CONTACT US
AIR45428/4		Flow Indicator	APPH	OH/REP/TEST	BAE125;HS748	PLEASE CONTACT US
AIR45428/5		Flow Indicator	APPH	OH/REP/TEST	BAE125;HS748	PLEASE CONTACT US
AIR47250		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR47258		Flow Indicator Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR48414		Flow Indicator Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR48530/3		Accumulator	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR48838		Flow Indicator Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR48920		Cut-Out Valve	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR68000		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR69500		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR75032		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR86486-1		Uplock Actuator	APPH	OH/REP/TEST	JETS41	PLEASE CONTACT US
AIR87224-0		Relief Valve	APPH	OH/REP/TEST	SD3	PLEASE CONTACT US
AIR87230		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR87254		Accumulator	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
AIR87390-0		Emergency Selector Valve	APPH	OH/REP/TEST	JETS41	PLEASE CONTACT US
AIR90400		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR91000		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR91088		Mk.9 Series Pump	APPH	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
AIR91110		Accumulator	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91140		Pressure Release Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91142		Landing Gear Control Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91144		Servo Power Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91174		Non Return Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91176		Non Return Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91178		Non Return Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91180		Non Return Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91182		Non Return Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91186		Thermal Relief Valve	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AIR91654-0		Non Return Valve	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91656-0		Non Return Valve	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91660-0		Non Return Valve	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91666-0		Accumulator	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91666-1		Accumulator	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91666-2		Accumulator	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91708		Flow Control Valve	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US

AIR91728-1		Transfer Cylinder/Accumulator	APPH	OH/REP/TEST	B757;B777	PLEASE CONTACT US
AIR91748-0		Lift Spoiler Selector Valve	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91748-1		Lift Spoiler Selector Valve	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91762		Flow Control Valve	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR91762-1	AIR91762/1	Flow Control Valve	APPH	OH/REP/TEST	BAE146	PLEASE CONTACT US
AIR93078		Accumulator	APPH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK32A281		Auto Brake Mechanism	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK32A4851		Uplock Drive Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK32A4853		Uplock Drive Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK33A1257		Spring Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK33A1258		Spring Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK33A1261		Spring Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK33A1262		Spring Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK33A2405		Spring Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A11		Main U/C Support Structure	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A1181		Main U/C Door Uplock	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A1182		Main U/C Door Uplock	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A12		Main U/C Support Structure	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A139		Free Fall Return Spring	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A15/16		Main U/C Downlock Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A15MK3		Main U/C Downlock Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A15MK4		Main U/C Downlock Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A16MK5		Main U/C Downlock Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A3		Shock Absorber Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A39		Main U/C Door Uplock	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A4		Shock Absorber Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A47		Weight Switch Override Mech	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A7		Main U/C Retraction Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A8		Main U/C Retraction Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A803		Sequence Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK43A805		Sequence Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK44A11		Drag Link Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK44A15		Steering Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK44A33		Rudder Steering Seq Valve Mounting	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK44A39		Nose U/C Up/Downlock Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK44A63		Steering Control Sleeve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK44A7		Nose U/C Retraction Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK44B69		Nose Landing Gear	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK48A163		Rudder Fine Steering Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK48A179		Brake Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK48A201		Selector Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK48A231		Twin Reducing Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK48A449		Double Restrictor Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK48A471		Restrictor Assy	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AK48A487		Relay Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US

AK48A517		Rudder Fine Steering Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AKO9A1263		Flap Carriage	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AKO9A1275		Flap Carriage	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AL/1036PG		Pressure Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
AL/1037PG		Pressure Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
AL/259PG		Pressure Gauge	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
AL/323PG		Pressure Gauge	SMITHS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
AL/95RV/SB		Engine Speed Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
AL597FL		Desynn Position Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
AL660PG/SB		Desynn Pressure Indicator	SMITHS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
AL751PG/SB		Desynn Pressure Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
AL830FL		Desynn Position Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
AL8ACR/MB		Oil Pressure Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
AN3203V30	135244	DC Voltmeter	WESTON INSTR.	OH/REP/TEST	C130;L100;L382;CONV	PLEASE CONTACT US
AN3353-2	613332	Relay	LEACH	TEST ONLY	C130;L100	PLEASE CONTACT US
AN5787-1		Position Transmitter	LIQUIDOMETER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AN5831-1A		Static Pressure Selector Valve	REPUBLIC MAN.	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AN6209-4	20355	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AN6248-2		Hydraulic Hand Pump	GLADDEN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AN6248-3	10-1382-1	Hydraulic Hand Pump	PARKER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AN6277-4	20348	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AN6277-6	20349	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AN6277-8	20350	Hydraulic Shuttle Valve	ADEL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AN6279-12CD	1032	Hydraulic Pressure Relief Valve	DROITCOUR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AN6279-6CD	1030	Hydraulic Pressure Relief Valve	DROITCOUR	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AQ43A137		Door Jack	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A139		Door Return Spring	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A23		Walking Joint	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A3		Main Shock Absorber Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A4		Main Shock Absorber Strut	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A5		Sidestay Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A511		LH Pintle Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A512		RH Pintle Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A6		Sidestay Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A61		Main Undercarriage	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AQ43A62		Main Undercarriage	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AS-19570-B		Hydraulic Motorpump	VICKERS	OH/REP/TEST	B727	PLEASE CONTACT US
AS-19570-B-GB1		Hydraulic Motorpump	VICKERS	OH/REP/TEST	B727	PLEASE CONTACT US
AS-19570-C		Hydraulic Motorpump	VICKERS	OH/REP/TEST	B727	PLEASE CONTACT US
AS-63665-LE		Hydraulic Pump	VICKERS	OH/REP/TEST	DC8	PLEASE CONTACT US
AS-63668-LE		Hydraulic Pump	VICKERS	OH/REP/TEST	DC8	PLEASE CONTACT US
AS-66651-L8A		Hydraulic Pump	VICKERS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AS-66691-L8A		Hydraulic Pump	VICKERS	OH/REP/TEST	B707	PLEASE CONTACT US
AS-66692-L8A		Hydraulic Pump	VICKERS	OH/REP/TEST	B707	PLEASE CONTACT US
AS-66693-L8A		Hydraulic Pump	VICKERS	OH/REP/TEST	B707	PLEASE CONTACT US

AS-66698-L8A		Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
AS-66699-R8A		Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ASH664-1		Static Inverter	LELAND	OH/REP/TEST	BAE146	PLEASE CONTACT US
ASH664-1PB		Static Inverter	LELAND	OH/REP/TEST	BAE146	PLEASE CONTACT US
AV13J5100		Selector Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV13J5101		Selector Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV13J5102		Selector Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV13J5105		Selector Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV13J5144		Selector Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV13J5145		Selector Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV13J5146		Selector Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV13J5147		Selector Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV16B1262B		Motor Operated Gate Valve	ITT CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV16B1330D		Motor Operated Gate Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV16B1331C		Motor Operated Gate Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV16B1350		Motor Operated Gate Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV16B1446C		Motor Operated Gate Valve	GENERAL CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV16B1451C		Shut Off Valve	GENERAL CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV16B1464C	695916-1	Motor Operated Gate Valve	WHITTAKER CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV16B1467D	695746-1	Shut Off Valve	WHITTAKER CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV16B1470C	695745-1	Shut Off Valve	GENERAL CONTROLS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
AV16B1470C	695745-1	Shut Off Valve	GENERAL CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV16B1517C		Motor Operated Gate Valve	ITT CONTROLS	OH/REP/TEST	B707	PLEASE CONTACT US
AV16B1519D		Motor Operated Gate Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV16B1520C		Motor Operated Gate Valve	ITT CONTROLS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
AV-16B1578A		Motor Operated Gate Valve	WHITTAKER CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV-16B1579C		Motor Operated Gate Valve	WHITTAKER CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV-16B1580D		Motor Operated Gate Valve	WHITTAKER CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV16B1659C		Motor Operated Gate Valve	ITT CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV16B1950		Motor Operated Gate Valve	ITT GEN. CONTROLS	OH/REP/TEST	B747	PLEASE CONTACT US
AV16B1965B		Motor Operated Gate Valve	ITT	OH/REP/TEST	B727;B737;B767	PLEASE CONTACT US
AV16B2003D		Motor Operated Gate Valve	ITT	OH/REP/TEST	TBD	PLEASE CONTACT US
AV16B2100B		Motor Operated Gate Valve	ITT	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
AV16E1209D		Shut Off Valve	ITT CONTROLS	OH/REP/TEST	B737	PLEASE CONTACT US
AV17B1038D	695974-1	Motor Operated Butterfly Valve	ITT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AV17B1246		Motor Operated Butterfly Valve	ITT	OH/REP/TEST	SD360	PLEASE CONTACT US
AV24B1318D-1		Motor Operated Ball Valve	ITT	OH/REP/TEST	DHC-7;DHC-8	PLEASE CONTACT US
AV24B1319D-1		Motor Operated Ball Valve	ITT	OH/REP/TEST	DHC-7;DHC-8	PLEASE CONTACT US
AV24B1319D-2		Motor Operated Ball Valve	ITT	OH/REP/TEST	DHC-7;DHC-8	PLEASE CONTACT US
AV24B1319D-3		Motor Operated Ball Valve	ITT	OH/REP/TEST	DHC-7;DHC-8	PLEASE CONTACT US
AV24B1343D		Motor Operated Ball Valve	ITT	OH/REP/TEST	DHC-7;DHC-8	PLEASE CONTACT US
AV24E1144		Shut Off Valve	ITT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
AV33		Fuel Shut Off Valve	mitsubishi	OH/REP/TEST	B757	PLEASE CONTACT US
AVR-834B	695839-1	AC Undervoltage Relay	MARSHALL	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
AW1026AE01		Gauge	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US

AW1821AC02	695383-1	Cabin Diff Pressure Gauge	AMETEK	TEST ONLY	C130;L100	PLEASE CONTACT US
AW2017AC01		Hydraulic Pressure Gauge	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
AW2017AC02		Pressure Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AW2017AC07		Hydraulic Pressure Gauge	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
AW-2-17-G		Hydraulic Pressure Gauge	AMETEK	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
AW-2-17-H		Hydraulic Pressure Gauge	AMETEK	OH/REP/TEST	BAE125	PLEASE CONTACT US
AW-2-17-J		Hydraulic Pressure Gauge	AMETEK	OH/REP/TEST	B707;B727	PLEASE CONTACT US
AZ48		Adapter-Shaft	MITSUBISHI	OH/REP/TEST	B757;B767	PLEASE CONTACT US
B 13-18		A/C Mechanical Clock	THOMMEN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B00A214271A		Relief Valve	BAE	OH/REP/TEST	BAE146	PLEASE CONTACT US
B00A702925A		Maingear Port	APPH	OH/REP/TEST	JETSTREAM	PLEASE CONTACT US
B00A702926A		Maingear Stbd	APPH	OH/REP/TEST	JETSTREAM	PLEASE CONTACT US
B0600-71104		Alt/Diff Pressure Indicator	ASTEK	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
B0707 10001		Overspeed Limit Sensor	LEAR SIEGLER-SMITHS	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
B-123B		Contactor	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B-123J	695715-1	Contactor	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B-123JA		Contactor	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B-124C		Contactor	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B-124K	695795-1	Contactor	HARTMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B2112/1		DC Generator	ROTAX	OH/REP/TEST	HS748;VISC	PLEASE CONTACT US
B2130		Generator	LUCAS	OH/REP/TEST	HELI	PLEASE CONTACT US
B2131		Generator	LUCAS	OH/REP/TEST	HELI	PLEASE CONTACT US
B22420		Rapid Water Boiler	AIM (HENSHALLS)	OH/REP/TEST	B737	PLEASE CONTACT US
B2700-14	10-3205-1	Brake Metering Valve	SARGENT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
B2807112302		Tacho Generator	KOLLSMAN	OH/REP/TEST	HELI	PLEASE CONTACT US
B3508		DC Generator	LUCAS	OH/REP/TEST	HS748;AND	PLEASE CONTACT US
B3512		DC Generator	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
B40550-1	CRU-73/A	Oxygen Regulator	CARLETON TECH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B40860-1	CRU-92/A	Oxygen Regulator	CARLETON TECH	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B4361710001		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	DC10	PLEASE CONTACT US
B4361710004		Pressure Altimeter	KOLLSMAN	OH/REP/TEST	DC10	PLEASE CONTACT US
B-459		Generator Contactor/Mechanical	HARTMAN AEROSPACE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B-459A		Generator Contactor/Mechanical	HARTMAN AEROSPACE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B-460		Generator Contactor/Mechanical	HARTMAN AEROSPACE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B-460A		Generator Contactor/Mechanical	HARTMAN AEROSPACE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B49C65		Aircraft Heater Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
B5011809		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
B5011809-1		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
B5011809-2		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
B5011809-3		Brake Assembly	ABSC	OH/REP/TEST	F28;F70;F100	PLEASE CONTACT US
B52C22	695747-5	Shut Off Valve	JANITROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
B54C00		Sealed Control Assembly	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
B66182	34.A1.111	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	F27	PLEASE CONTACT US
B90C13		Aircraft Heater Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
B92881	98.AA1.542	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE146	PLEASE CONTACT US

BA1001		AC Generator	TRW-LUCAS	OH/REP/TEST	GS1	PLEASE CONTACT US
BC0104/1		Starter Generator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
BC0107/2		Starter Generator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
BC0107/2C		Starter Generator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
BC0111		Starter Generator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
BP1/RSMK6		Booster Pump	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
BP5 MK5		Fuel Booster Pump	PLESSEY	OH/REP/TEST	TBD	PLEASE CONTACT US
BPS7-2	S283T014-2	Battery Power Supply	RADIANT POWER CORP	OH/REP/TEST	B727;B737;B747;B757;B767	PLEASE CONTACT US
BPS7-3	S283T014-3	Battery Power Supply	RADIANT POWER CORP	OH/REP/TEST	B727;B737;B747;B757;B767	PLEASE CONTACT US
BR9172-501		Window Reveal Light	BRUCE IND.	OH/REP/TEST	B737;B767:MD90	PLEASE CONTACT US
BR9172-503	10-61773	Window Reveal Light	BRUCE IND.	OH/REP/TEST	B737;B767:MD90	PLEASE CONTACT US
BT25-1		Cable Box	SMITHS	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
BT25-4		Cable Box	SMITHS	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
BYLB51044	697752-1	Temperature Control Valve	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
BYLB51045	697753-1	Temperature Control Valve	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
BYLB7606		Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
BYLG5697-2		Heat Exchanger Actuator	BARBER COLMAN	OH/REP/TEST	DC8	PLEASE CONTACT US
BYLG5697-3		Heat Exchanger Actuator	BARBER COLMAN	OH/REP/TEST	DC8	PLEASE CONTACT US
C-07202-2		Control Shaker Assy	SAFE FLIGHT	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
C-07202-2 MOD A		Control Shaker Assy	SAFE FLIGHT	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
C-07202-3		Control Shaker Assy	SAFE FLIGHT	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
C-07202-3 MOD A		Control Shaker Assy	SAFE FLIGHT	OH/REP/TEST	B737;B747;B757	PLEASE CONTACT US
C-07202-5		Control Shaker Assy	SAFE FLIGHT	OH/REP/TEST	B777	PLEASE CONTACT US
C-07202-5 MOD A		Control Shaker Assy	SAFE FLIGHT	OH/REP/TEST	B777	PLEASE CONTACT US
C1220YMK134		Drum Switch	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
C1224YMK10		Undercarriage Indicator	DOWTY	REP/TEST	HS748;F27	PLEASE CONTACT US
C1224YMK8		Undercarriage Indicator	DOWTY	REP/TEST	HS748;F27	PLEASE CONTACT US
C1224YMK8R		Undercarriage Indicator	DOWTY	REP/TEST	HS748;F27	PLEASE CONTACT US
C19A513	695324	Centrifugal Fan	GLOBE INDUSTRIES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
C20175100		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	A300	PLEASE CONTACT US
C20180110		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180110-1		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180110-2		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180110-3		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180110-4		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180120		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180120-1		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180120-2		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180400		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20180410		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20181100-1		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20181100-2		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20181100-3		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20181100-4		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20181100-5		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US

C20181100-6		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20181100-7		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20181100-8		Brake Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20182000		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20182100		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 900	PLEASE CONTACT US
C20195000		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A310	PLEASE CONTACT US
C20195000-1		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A310	PLEASE CONTACT US
C20195000-2		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A310	PLEASE CONTACT US
C20195000-3		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A310	PLEASE CONTACT US
C20195000-4		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A310	PLEASE CONTACT US
C20195000-5		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A310	PLEASE CONTACT US
C20195000-6		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A310	PLEASE CONTACT US
C20195000-7		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A310	PLEASE CONTACT US
C20195162		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A320;A319CJ	PLEASE CONTACT US
C20383000		Nose Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 2000	PLEASE CONTACT US
C20384100		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 2000	PLEASE CONTACT US
C20384110		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 2000	PLEASE CONTACT US
C20384200		Main Wheel Assembly	MESSIER-BUG/DASSAULT	OH/REP/TEST	FALCON 2000	PLEASE CONTACT US
C20498000		Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	SIK-92	PLEASE CONTACT US
C20498100		Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	SIK-92	PLEASE CONTACT US
C20500000		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	A320;A321	PLEASE CONTACT US
C20545000		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 2000	PLEASE CONTACT US
C20545100		Main Wheel Assembly	MESSIER-BUGATTI	OH/REP/TEST	FALCON 2000	PLEASE CONTACT US
C20546000		Nose Wheel Assembly	DASSAULT AVIATION	OH/REP/TEST	FALCON 2000	PLEASE CONTACT US
C26707-2		Lift Transducer	SAFE FLIGHT	OH/REP/TEST	DC8	PLEASE CONTACT US
C26707-3		Lift Transducer	SAFE FLIGHT	OH/REP/TEST	DC8	PLEASE CONTACT US
C28-1		Control Assembly	P.L.PORTER	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
C44TS/4		H.E.Ignition Unit	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
C5068		Rotary Actuator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
C5104		Starter Motor	LUCAS	OH/REP/TEST	HS748;F27;GS1;AND	PLEASE CONTACT US
C5108		Starter Motor	LUCAS	OH/REP/TEST	HS748;F27;GS1;AND	PLEASE CONTACT US
C5219		Rotary Actuator	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
C5221		Rotary Actuator	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
C52C22	695747-7	Shutoff Valve	JANITROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
C54C00		Sealed Control Assembly	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
C63TS/1		H.E.Ignition Unit	LUCAS	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
C63TS/3		H.E.Ignition Unit	LUCAS	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
C7041-1	695775-1	Aileron Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
C7041-2	695775-2	Rudder Trim Tab Actuator	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
C7047		Air Compressor Pump	CEF INDUSTRIES (CALCO)	OH/REP/TEST	B737	PLEASE CONTACT US
C7088-1A	695759-7	Wing Flap Drive Gearbox	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
C7088-63		Shaft Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
C7088-93		Brake & Nest Assembly	CEF INDUSTRIES (CALCO)	OH/REP/TEST	C130;L100	PLEASE CONTACT US
C7379		Oil Reservoir	STRABOR	OH/REP/TEST	HS748	PLEASE CONTACT US
C-74002		Control Shaker Assy	SAFE FLIGHT	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US

C-74006		Signal Summing Unit	SAFE FLIGHT	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
C-74007-2		Lift Transducer	SAFE FLIGHT	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
C-74007-3		Lift Transducer	SAFE FLIGHT	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
C-74007-4		Lift Transducer	SAFE FLIGHT	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
C7499		Jack Assembly	STRABOR	OH/REP/TEST	HS748	PLEASE CONTACT US
C9500/06/17A		Rotary Selector Switch	PAGE	OH/REP/TEST	BAE146	PLEASE CONTACT US
C9500/07/18A		Rotary Selector Switch	PAGE	OH/REP/TEST	BAE146	PLEASE CONTACT US
C9603		Motor & Brake Unit	LUCAS	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
CC.208/S/2		3/4In Aircraft Unit	AVERY HARDOLL	OH/REP/TEST	HS748	PLEASE CONTACT US
CC.704/S/2		3/4In Aircraft Unit	AVERY HARDOLL	OH/REP/TEST	HS748	PLEASE CONTACT US
CC.706/S/2		3/4In Bsp Hose Unit	AVERY HARDOLL	OH/REP/TEST	HS748	PLEASE CONTACT US
CCMX706/S/2		3/4In Bsp Hose Unit	AVERY HARDOLL	OH/REP/TEST	HS748	PLEASE CONTACT US
CG12313	6827995	Fuel Filter Pressure Switch	WESTPORT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
CG12313F	6827995	Fuel Filter Pressure Switch	WESTPORT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
CG12313G	6827995	Fuel Filter Pressure Switch	WESTPORT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
CPTG14-30		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	GS1	PLEASE CONTACT US
CPTG14-31		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	GS1	PLEASE CONTACT US
CPTG14-7		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	GS1	PLEASE CONTACT US
CPTG14-8		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	GS1	PLEASE CONTACT US
CR2795B105A1		Voltage Regulator	GENERAL ELECTRIC	OH/REP/TEST	CESS;HELI	PLEASE CONTACT US
CR2795E100A1		Voltage Regulator	GENERAL ELECTRIC	OH/REP/TEST	CESS;HELI	PLEASE CONTACT US
CVA2		Air Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
CX175705		Gearbox (Dp6Forma1)	LUCAS AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
CYLB51055	695813-1	Engine Bleed Air Check Valve	BARBER COLMAN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
CYLZ4271		Windshield Control Box	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
CYLZ4271-1		Windshield Control Box	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
CYLZ4271-2	695277	Windshield Control Box	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
CYLZ7655		Control Box	BARBER COLMAN	OH/REP/TEST	HELI	PLEASE CONTACT US
CYLZ7655-1		Control Box	BARBER COLMAN	OH/REP/TEST	HELI	PLEASE CONTACT US
CZ26817		DC Motor Assembly	PLESSEY	OH/REP/TEST	TBD	PLEASE CONTACT US
CZ54249	TYPE C1606H/1	Motor Assembly	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
CZ77917		Jaguar Actuator	GEC	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
CZ77917F		Jaguar Actuator	GEC	OH/REP/TEST	HS748;HRLD	PLEASE CONTACT US
CZ78311		DC Motor Assembly	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
D10120-20	1095	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D10120-30	1095A	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D10120-30A	1095-30A	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D10120-40	1095B	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D10120-50	1095C	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D10120-60	1095D	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D10120-70	1095BC	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D10134-20	1097	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D101588	75MA1-571	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
D101589	68.AA7.593	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
D102740	I60-45-511	Brake Fan Motor	AMETEK AIRSCREW	OH/REP/TEST	BAE146	PLEASE CONTACT US

D103549	70.AA6.521	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE146	PLEASE CONTACT US
D104219	108.AA4.511	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE146	PLEASE CONTACT US
D10605-20	1158	Liquid Container	MIDWEST AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D11803/2		Contactora	ROTAX	OH/REP/TEST	BAE125;YS11	PLEASE CONTACT US
D11804		Contactora	ROTAX	OH/REP/TEST	HS748	PLEASE CONTACT US
D11986		Airspeed Transducer	PENNY & GILES	OH/REP/TEST	BAE146	PLEASE CONTACT US
D125140HB-5A		DC Motor Assy	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D12804		Latched Relay	LUCAS	OH/REP/TEST	BAE125;HS748	PLEASE CONTACT US
D1740		Control Unit & Base Assembly	KIDDE GRAVINER	OH/REP/TEST	TBD	PLEASE CONTACT US
D1760		Control Unit	KIDDE GRAVINER	OH/REP/TEST	TBD	PLEASE CONTACT US
D19115		Swivel Coupling	MEGGITT	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
D19115/1		Swivel Coupling	MEGGITT	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
D19116		Swivel Coupling	MEGGITT	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
D19116/1		Swivel Coupling	MEGGITT	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
D291-2A		Heat Exchanger	MARSTON	OH/REP/TEST	F27	PLEASE CONTACT US
D291-52A		Heat Exchanger	MARSTON	OH/REP/TEST	HS748	PLEASE CONTACT US
D291-8A		Heat Exchanger	MARSTON	OH/REP/TEST	HS748	PLEASE CONTACT US
D-31C		Contactora Assembly	HARTMAN	OH/REP/TEST	B737;B747;B757;B767	PLEASE CONTACT US
D4190		Magnetic Relay	HENDREY	OH/REP/TEST	F27	PLEASE CONTACT US
D4195		Magnetic Relay	HENDREY	OH/REP/TEST	F27	PLEASE CONTACT US
D4600		Magnetic Relay Switch	HENDREY	REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
D4801/1		Contactora	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D4802/1		Contactora	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D4803		Contactora	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D4804		Contactora	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D52C22		Shutoff Valve	JANITROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
D5317		Solenoid Locking Unit	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D5327		Solenoid Locking Unit	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D5339		Solenoid Locking Unit	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D5340		Solenoid Locking Unit	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D54C00		Sealed Control Assembly	JANITROL	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
D-5725		Landing Light Motor	GRIMES	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
D5900		Magnetic Relay Switch	HENDREY	REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
D6311		Contactora	LUCAS	OH/REP/TEST	HS748;BRIT	PLEASE CONTACT US
D6311/1		Contactora	LUCAS	OH/REP/TEST	HS748;BRIT	PLEASE CONTACT US
D7-8		Rotary Actuator	LUCAS AVITRON	OH/REP/TEST	F27	PLEASE CONTACT US
D7-9		Rotary Actuator	LUCAS AVITRON	OH/REP/TEST	F27	PLEASE CONTACT US
D8483		Time Delay Switch	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D8498		Time Delay Switch	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
D9042Y		Spring Box	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
D92098	100.CC1.511	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE146	PLEASE CONTACT US
D9311		Reversing Contactora	LUCAS	OH/REP/TEST	BAE125;HS748;BAE ATP;VISC	PLEASE CONTACT US
D93641	70.AA6.511	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE146	PLEASE CONTACT US
DAP00098-01		Main Wheel Assembly	MEGGITT	OH/REP/TEST	PHENOM 300	PLEASE CONTACT US
DAP00098-02		Main Wheel Assembly	MEGGITT	OH/REP/TEST	PHENOM 300	PLEASE CONTACT US

DAP00099-01		Nose Wheel Assembly	MEGGITT	OH/REP/TEST	PHENOM 300	PLEASE CONTACT US
DAP00099-02		Nose Wheel Assembly	MEGGITT	OH/REP/TEST	PHENOM 300	PLEASE CONTACT US
DC.30		Fan Motor	AIRSCREW HOWDEN	OH/REP/TEST	BAE125	PLEASE CONTACT US
DCL 1.1.		Fan Motor	AIRSCREW	OH/REP/TEST	HS748	PLEASE CONTACT US
DL1326M11	695838-3	Linear Actuator	NASH/SIMMONDS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
DP022-2	550-1-21118	Motorized Type Gear Pump	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
DP022-5	550-1-21735	Motorized Type Gear Pump	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
DP022-6	550-1-21736	Motorized Type Gear Pump	GEC	OH/REP/TEST	BAE125	PLEASE CONTACT US
DP6-A1		Gearbox	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
DST-16		Thermocouple Temperature Indicator	CONSOLIDATED AIR.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DST-29-1		Thermocouple Temperature Indicator	CONSOLIDATED AIR.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DST-29-2		Thermocouple Temperature Indicator	CONSOLIDATED AIR.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DST-29-3		Thermocouple Temperature Indicator	CONSOLIDATED AIR.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLM43402-3		Motor & Brake Assembly	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLM43403-3		Motor & Brake Assembly	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLM43700-4		DC Split-Series Motor	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3990		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3990-1		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3990-2		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3990-2		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3990-3	695305-1	Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3990A		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3991		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3991-1		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3991-2		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3991-2		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3991-3	695316-1	Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
DYLZ3991A		Dual Butterfly Valve And Actuator Assy	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
E07241-04-003		True Air Speed Indicator	KOLLSMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
E07241-04-004		True Air Speed Indicator	KOLLSMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
E07391 04 56		Airspeed Indicator	KOLLSMAN	OH/REP/TEST	F27	PLEASE CONTACT US
E07391 10 057		Airspeed Indicator	KOLLSMAN	OH/REP/TEST	F27	PLEASE CONTACT US
E12A/10A/390		Air Speed Contactor	R.W.MUNRO	OH/REP/TEST	F27	PLEASE CONTACT US
E12A/10A/478		Air Speed Contactor	R.W.MUNRO	OH/REP/TEST	F27	PLEASE CONTACT US
E20C30		Fuel Pressure Relief Valve Assembly	JANITROL	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
E-308AH		Voltage Sensing Relay	HARTMAN	OH/REP/TEST	B747;B757;B767	PLEASE CONTACT US
E-323E		Frequency Relay	HARTMAN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
E-323E-1		Frequency Relay	HARTMAN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
E52C22		Shutoff Valve	JANITROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
E6011M13-1		Aircraft DC Motor	GEC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
E6011M13-5		Aircraft DC Motor	GEC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
E6015M106		Motor & Brake Assembly	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
E6015M64-1		Motor And Brake Assembly	GEC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
E6015M78		Direct Current Motor	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
E6020M32-1		Motor And Brake Assembly	GEC	OH/REP/TEST	B727;B737	PLEASE CONTACT US

E6430M21		Motor And Brake Assembly	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
EA100ANH		Quantity Indicator	LIQUIDOMETER	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
EA100ANH144	695788-1	Oil Quantity Indicator	LIQUIDOMETER	OH/REP/TEST	C130;L100;L382;ELECTRA	PLEASE CONTACT US
EA102AN44		Anti Ice Fluid Quantity Indicator	LIQUIDOMETER	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
EA102ANH-D163H		Water Methanol Quantity Indicator	SIMMONDS-LIQUIDOMETR	OH/REP/TEST	B707;CONV;ELEC;F27	PLEASE CONTACT US
EA-1045-037-1A		Hydraulic Motorpump	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA-1045-037-2	695743-1	Hydraulic Motorpump	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA-1045-037-2B		Hydraulic Motorpump	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA1065AW-1827		Oil Quantity Tank Unit	LIQUIDOMETER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA1065AW-2315	695800-3	Oil Quantity Tank Unit	LIQUIDOMETER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA1204		Tandem Aileron Booster Actuator	ELECTROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA1205-1		Dual Rudder Booster Actuator	ELECTROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA1261-1		Ramp Door Uplock Cylinder Assembly	ELECTROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA1261-2		Ramp Door Uplock Cylinder Assembly	ELECTROL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA-1320-442		Hydraulic Motorpump	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA-1320-442 -1		Hydraulic Motorpump	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA148AN46		Quantity Indicator	LIQUIDOMETER	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
EA148ANH-D126H		Water Methanol Totalizing Indicator	SIMMONDS-LIQUIDOMETR	OH/REP/TEST	B707;CONV;ELEC;F27	PLEASE CONTACT US
EA148ANH-D129H		Water Methanol Totalizing Indicator	SIMMONDS-LIQUIDOMETR	OH/REP/TEST	B707;CONV;ELEC;F27	PLEASE CONTACT US
EA321-22		Position Indicator	LIQUIDOMETER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA-50182-7		Hydraulic Motor Pump	VICKERS	OH/REP/TEST	CONV;ELEC	PLEASE CONTACT US
EA-50182-8		Hydraulic Motor Pump	VICKERS	OH/REP/TEST	CONV;ELEC	PLEASE CONTACT US
EA573A-1	695292	Flap Position Transmitter	LIQUIDOMETER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
EA7722856		Fuel Quantity Tank Unit	HONEYWELL	TEST ONLY	C130;F27	PLEASE CONTACT US
EA7722857		Fuel Quantity Tank Unit	HONEYWELL	TEST ONLY	C130;F27	PLEASE CONTACT US
EA7722858		Fuel Quantity Tank Unit	HONEYWELL	TEST ONLY	C130;F27	PLEASE CONTACT US
EA7722859		Fuel Quantity Tank Unit	HONEYWELL	TEST ONLY	C130;F27	PLEASE CONTACT US
EAP2340		Supply Monitor	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
EAP2340-5		Supply Monitor	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
ED43A61 MK2		Main Undercarriage Assy	BRITISH AEROSPACE	OH/REP/TEST	TBD	PLEASE CONTACT US
ED43A61 MK3		Main Undercarriage Assy	BRITISH AEROSPACE	OH/REP/TEST	TBD	PLEASE CONTACT US
ED43A62 MK2		Main Undercarriage Assy	BRITISH AEROSPACE	OH/REP/TEST	TBD	PLEASE CONTACT US
ED43A62 MK3		Main Undercarriage Assy	BRITISH AEROSPACE	OH/REP/TEST	TBD	PLEASE CONTACT US
ED48A111		Spool Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ED48A219		Spool Valve	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
EH1831		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH1832		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH1833		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH1837		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH1838		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH1839		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH1885		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH1886		Main Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH1887		Nose Undercarriage	DOWTY AEROSPACE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
EH5059		Shock Absorber	MESSIER DOWTY	OH/REP/TEST	SKYVAN	PLEASE CONTACT US

EH5066		Shock Absorber	MESSIER DOWTY	OH/REP/TEST	SKYVAN	PLEASE CONTACT US
ELA4905		A.F.M Indicator Test Set	KEARSLEY/AFLO	OH/REP/TEST	TBD	PLEASE CONTACT US
EM91-80		Shutoff Ball Valve	CIRCLE SEAL CONTROLS	OH/REP/TEST	B757	PLEASE CONTACT US
EN81A11063		Air Valve	B A C	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ES113/02		Electro Pneumatic Valve	NET SENSORS	TEST ONLY	F27	PLEASE CONTACT US
ES113/03		Electro Pneumatic Valve	NET SENSORS	OH/REP/TEST	BAE146	PLEASE CONTACT US
EZ43A39		Door Uplock Assembly (LH)	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
EZ43A41		Door Uplock Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
EZ43A42		Door Uplock Assembly	BRITISH AEROSPACE	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
F103823	98.AA1.542/2	Fan Assembly	AIRSCREW HOWDEN	OH/REP/TEST	BAE146	PLEASE CONTACT US
F1727		Relay	ROTAX	OH/REP/TEST	HS748;BAE ATP;F27;VISC	PLEASE CONTACT US
F45-10		Rotary Inverter	LEAR SIEGLER	OH/REP/TEST	TBD	PLEASE CONTACT US
F6801		Switching Unit	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
F6802		Switching Unit	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
F6812		Switching Unit	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
F6813		Switching Unit	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
F6815		Switching Unit	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
F7501		Protection Unit	ROTAX	OH/REP/TEST	HS748	PLEASE CONTACT US
FC103MK2		Coupling, Refuel	AVERY HARDOLL	OH/REP/TEST	TBD	PLEASE CONTACT US
FC110MK2		Coupling, Refuel	AVERY HARDOLL	OH/REP/TEST	TBD	PLEASE CONTACT US
FC113MK2		1 1/2" Refuelling Aircraft Unit	AVERY HARDOLL	OH/REP/TEST	HS748;HAWK	PLEASE CONTACT US
FC129MK2		Coupling, Refuel	AVERY HARDOLL	OH/REP/TEST	TBD	PLEASE CONTACT US
FCMX113MK2		1 1/2" Refuelling Aircraft Unit	AVERY HARDOLL	OH/REP/TEST	HS748;HAWK	PLEASE CONTACT US
FCMX129MK2		Coupling, Refuel	AVERY HARDOLL	OH/REP/TEST	HS748;HAWK	PLEASE CONTACT US
FCMX242NMK2		Coupling, Refuel	AVERY HARDOLL	OH/REP/TEST	BAE125	PLEASE CONTACT US
FCMX246MK2		Coupling, Refuel	AVERY HARDOLL	OH/REP/TEST	BAE125	PLEASE CONTACT US
FCMX248MK2		Coupling, Refuel	AVERY HARDOLL	OH/REP/TEST	BAE125	PLEASE CONTACT US
FD2173		Aircraft Fuel Filter	BRITISH FILTERS	OH/REP/TEST	HS748	PLEASE CONTACT US
FD2179		Aircraft Fuel Filter	BRITISH FILTERS	OH/REP/TEST	HS748	PLEASE CONTACT US
FG220A100	695799-31	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A101	695799-33	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A102	695799-35	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A103	695799-37	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A104	695799-39	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A105	695799-41	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A106	695799-43	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A107	695799-45	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A108	695799-9	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A109	695799-11	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A110	695799-13	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A111	695799-15	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A112	695799-17	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A113	695799-19	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A114	695799-21	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A115	695799-51	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US

FG220A155		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A156		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A175		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A176	695799-55	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A177	695799-53	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A178	695799-49	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A179	695799-51	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A192		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A193		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A194		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A195	695799-89	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A196	695799-91	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A197	695799-93	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A198	695799-95	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A199	695799-97	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A200	695799-99	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A201	695799-101	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A202	695799-103	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A203	695799-105	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A204	695799-107	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A205	695799-71	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A206	695799-73	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A207	695799-75	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A208	695799-77	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A209	695799-79	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A210	695799-81	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A211	695799-83	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A212	695799-85	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A213	695799-117	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A214	695799-115	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A215	695799-111	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A216	695799-113	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A237	695799-125	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A237	695799-125	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A238	695799-123	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A238	695799-123	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A239	695799-121	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A239	695799-121	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A240	695799-147	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A240	695799-147	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A241	695799-149	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A241	695799-149	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A242	695799-151	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A242	695799-151	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A243	695799-153	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US

FG220A243	695799-153	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A244	695799-155	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A244	695799-155	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A245	695799-157	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A245	695799-157	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;F27	PLEASE CONTACT US
FG220A246	695799-159	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A246	695799-159	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A247	695799-161	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A247	695799-161	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A248	695799-163	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A248	695799-163	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A249	695799-165	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A249	695799-165	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A250	695799-129	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A250	695799-129	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A251	695799-131	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A251	695799-131	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;F27	PLEASE CONTACT US
FG220A252	695799-133	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A252	695799-133	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A253	695799-135	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A253	695799-135	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;F27	PLEASE CONTACT US
FG220A254	695799-137	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A254	695799-137	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A255	695799-139	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A255	695799-139	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A256	695799-141	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A256	695799-141	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A257	695799-143	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A257	695799-143	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A258	695799-175	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A258	695799-175	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A259	695799-173	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A259	695799-173	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A260	695799-169	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A260	695799-169	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A261	695799-171	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A261	695799-171	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100;L382;F27	PLEASE CONTACT US
FG220A60		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A61		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A62		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A63		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A64		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A65		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A66		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A67		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US

FG220A68		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A75		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A76		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A77		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	ELECTRA;F27	PLEASE CONTACT US
FG220A83		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A88		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	ELECTRA;F27	PLEASE CONTACT US
FG220A95		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A96	695799-3	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A97	695799-1	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A98	695799-27	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG220A99	695799-29	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;F27	PLEASE CONTACT US
FG250A42		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG250A43		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG250A44		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG250A51		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG250A52		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG250A53		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG250A6		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG250A7		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG250A8		Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A237	695799-183	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A238	695799-181	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A239	695799-179	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A240	695799-205	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A241	695799-207	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A242	695799-209	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A243	695799-211	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A244	695799-213	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A245	695799-215	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A246	695799-217	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A247	695799-219	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A248	695799-221	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A249	695799-223	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A250	695799-187	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A251	695799-189	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A252	695799-191	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A253	695799-193	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A254	695799-195	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A255	695799-197	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A256	695799-199	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A257	695799-201	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A259	695799-231	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A260	695799-227	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG430A261	695799-229	Fuel Quantity Tank Unit	HONEYWELL	REP/TEST	C130;L100	PLEASE CONTACT US
FG450A51	695799-185	Fuel Quantity Tank Unit	HONEYWELL	TEST ONLY	C130;L100	PLEASE CONTACT US

FG450A53	695799-225	Fuel Quantity Tank Unit	HONEYWELL	TEST ONLY	C130;L100	PLEASE CONTACT US
FHE19-6L	CR104-2	High Energy Igniter Plugs	ROLLS ROYCE	REP/TEST	F27;HS748;GULFSTREAM 1	PLEASE CONTACT US
FHM/A/39		Cyclic De-Icing Switch	TEDDINGTON	OH/REP/TEST	TBD	PLEASE CONTACT US
FLDXF20307A		Frequency Meter	WACLIN INC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
FLZ/A/15		Cyclic De-Icing Switch	TEDDINGTON	OH/REP/TEST	TBD	PLEASE CONTACT US
FMA/A/50		Hot Air Valve	HONEYWELL	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
FMA/A/51		Hot Air Valve	HONEYWELL	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
FMA/SA/387		Solenoid	HONEYWELL	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
FS-20		Direct Current Motor	TALLEY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
G3800A3		Landing Lamp	GRIMES	OH/REP/TEST	F27	PLEASE CONTACT US
G3800A5		Landing Lamp	GRIMES	OH/REP/TEST	CONV;F27	PLEASE CONTACT US
G-5400-1		Landing Lamp	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
G-5400-2		Landing Lamp	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
G-5400-3		Landing Lamp	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
G-5400-4		Landing Lamp	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
G-5400-5	695335-5	Landing Lamp	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
G-6965-34		Rotating Warning Nav Light	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
G6965-6	695521-3	Rotating Warning Nav Light	GRIMES	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
G-6965-8		Rotating Warning Nav Light	GRIMES	OH/REP/TEST	C130;L100	PLEASE CONTACT US
G8400A10-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A11-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A12		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A12-12		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A13-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A14-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A15-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A21-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A22-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A23-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A24-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A3-12		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A31-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A3-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A36-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A37-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A39-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A41-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A43-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A45-12		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A47-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A49-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A8-12		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A8-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US
G8400A9-24		Rotating Warning Light	GRIMES	OH/REP/TEST	HS748;DHC6;EMB120;F27;F50;CL41	PLEASE CONTACT US

G9220-1		Tandem Oscillating Light Assembly	GRIMES	OH/REP/TEST	DC8	PLEASE CONTACT US
G9220-3		Tandem Oscillating Light Assembly	GRIMES	OH/REP/TEST	DC8	PLEASE CONTACT US
G9220-4		Tandem Oscillating Light Assembly	GRIMES	OH/REP/TEST	DC8	PLEASE CONTACT US
G9325A1		Rotating Warning Light	GRIMES	OH/REP/TEST	B707;B737;DC10	PLEASE CONTACT US
G9325A2		Rotating Warning Light	GRIMES	OH/REP/TEST	B707;B737;DC10	PLEASE CONTACT US
G9325A3		Rotating Warning Light	GRIMES	OH/REP/TEST	B707;B737;DC10	PLEASE CONTACT US
G9325A4		Rotating Warning Light	GRIMES	OH/REP/TEST	B707;B737;DC10	PLEASE CONTACT US
G9325A5		Rotating Warning Light	GRIMES	OH/REP/TEST	B707;B737;DC10	PLEASE CONTACT US
G9325A6		Rotating Warning Light	GRIMES	OH/REP/TEST	B707;B737;DC10	PLEASE CONTACT US
GD20/12	GD20-12	Gearbox Drive Shaft	DOWTY AEROSPACE	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
GD20/2	GD20-2	Gearbox Drive Shaft	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
GD20/3	GD20-3	Gearbox Drive Shaft	DOWTY AEROSPACE	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
GD20/6	GD20-6	Gearbox Drive Shaft	DOWTY AEROSPACE	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
GD20/7	GD20-7	Gearbox Drive Shaft	DOWTY AEROSPACE	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
GD21/1	GD21-1	Gearbox Drive Shaft	DOWTY	OH/REP/TEST	YS11	PLEASE CONTACT US
GSH10-1		Retrieval Winch Motor	ATOS	OH/REP/TEST	C130	PLEASE CONTACT US
GW313-1100-7	3-1599	Main Wheel Assembly	GOODRICH	OH/REP/TEST	BD700	PLEASE CONTACT US
GYLC7619		Rotary Actuator	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
GYLC9102		Rotary Actuator	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
GYLC9103		Rotary Actuator	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
H5063	102348007	Double Relief Valve	DOWTY	OH/REP/TEST	HS748	PLEASE CONTACT US
H5077		One-Way Restrictor Valve	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
H5078		One-Way Restrictor Valve	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
HE53384		Rapid Water Boiler	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE61058		Double Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
HE61070		Double Compartment Oven	HERMAN SMITH	OH/REP/TEST	DC10	PLEASE CONTACT US
HE62001		Rapid Water Boiler	HERMAN SMITH	OH/REP/TEST	BAC111(CofC only);HELI	PLEASE CONTACT US
HE62010		Rapid Water Boiler	L.A.RUMBOLD	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
HE62160		Rapid Water Boiler	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE62161		Rapid Water Boiler	HERMAN SMITH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
HE62172		Rapid Water Boiler	L.A.RUMBOLD	OH/REP/TEST	B737	PLEASE CONTACT US
HE62190		Water Boiler	RUMBOLD	OH/REP/TEST	BAE146;B737;B757	PLEASE CONTACT US
HE62191		Water Boiler	RUMBOLD	OH/REP/TEST	B767	PLEASE CONTACT US
HE62194		Water Boiler	RUMBOLD	OH/REP/TEST	B757	PLEASE CONTACT US
HE62195		Water Boiler	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE62195-1		Water Boiler	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE62195-2		Water Boiler	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE62195-3		Water Boiler	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE64100		Oven Controller	L.A.RUMBOLD	OH/REP/TEST	B737;B757	PLEASE CONTACT US
HE64102		Oven Controller	HERMAN SMITH	OH/REP/TEST	B757	PLEASE CONTACT US
HE65040		Beverage Container	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE65070		Beverage Container	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE65080		Beverage Container	L.A.RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE67087 MOD1		Single Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	B737;B757	PLEASE CONTACT US
HE67087 MOD2		Single Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	B737;B757	PLEASE CONTACT US

HE67087 MOD4		Single Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	B737;B757	PLEASE CONTACT US
HE67088 MOD1		Single Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	B737;B757	PLEASE CONTACT US
HE67088 MOD2		Single Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	B737;B757	PLEASE CONTACT US
HE67088 MOD4		Single Compartment Oven	L.A.RUMBOLD	OH/REP/TEST	B737;B757	PLEASE CONTACT US
HE67124 L1		Fan Circulated Oven	RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE67124 L7		Fan Circulated Oven	RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE71005		Toilet Water Heater	RUMBOLD	OH/REP/TEST	TBD	PLEASE CONTACT US
HE71009		Toilet Water Heater	HERMAN SMITH	OH/REP/TEST	HS748	PLEASE CONTACT US
HL01400-00		Hydrolok	PL PORTER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
HL10000-100		Hydrolok	PL PORTER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
HL10000-102		Hydrolock	PL PORTER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
HLO1400-31		Hydrolock	PORTER	OH/REP/TEST	B727;B737	PLEASE CONTACT US
HO800		Water Heater	HERMAN SMITH	OH/REP/TEST	HS748	PLEASE CONTACT US
HO801/C/115/105		Water Heater	HERMAN SMITH	OH/REP/TEST	BAC111;HS748	PLEASE CONTACT US
HP367100		Shuttle Valve	TELEDYNE-HYDRA POWER	OH/REP/TEST	C130;L100	PLEASE CONTACT US
HS1000		Hydraulic Snubber	PORTER	OH/REP/TEST	B727;B737;MD83	PLEASE CONTACT US
HTE210014		Single Motor Actuator	FR-HITEMP	OH/REP/TEST	BAE146	PLEASE CONTACT US
HTE530004		Toilet Flush Valve	HIGH TEMP.ENG.	OH/REP/TEST	BAE146	PLEASE CONTACT US
HTE530004/1		Toilet Flush Valve	HIGH TEMP.ENG.	OH/REP/TEST	BAE146	PLEASE CONTACT US
HTE900195		Hydraulic Shut-Off Valve	HTE	OH/REP/TEST	F100	PLEASE CONTACT US
HTE9037		Single Motor Actuator	HI-TEMPERATURE ENGS.	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
HTE9037-1		Single Motor Actuator	HI-TEMPERATURE ENGS.	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
HTE9082-1		Single Motor Actuator	FR-HITEMP	OH/REP/TEST	BAE146	PLEASE CONTACT US
HTE9084		Single Motor Actuator	FR-HITEMP	OH/REP/TEST	BAE146	PLEASE CONTACT US
HTE9531-2		Isolation Valve	FLIGHT REFUELLING	OH/REP/TEST	BAE146	PLEASE CONTACT US
HTE9531-3		Isolation Valve	FLIGHT REFUELLING	OH/REP/TEST	BAE146	PLEASE CONTACT US
I60-45-511	D102740	Brake Fan Motor Assembly	AMETEK AIRSCREW	OH/REP/TEST	BAE146	PLEASE CONTACT US
IN10345-1		Oxygen Filter	NORMALAIR-GARRETT	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
J5071		Uplock Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
J5074		Main Undercarriage Downlock Jack	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
J5075		Nose Undercarriage Downlock Jack	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
J5089		Main Undercarriage Jack	DOWTY	OH/REP/TEST	HS748	PLEASE CONTACT US
JG130A100		Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	F27	PLEASE CONTACT US
JG130A94		Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	F27	PLEASE CONTACT US
JG130A97		Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	F27	PLEASE CONTACT US
JG402A2	695797-1	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG402A3	695797-3	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG402A32	695797-17	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG402A4	695797-5	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG402A52	695797-23	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG402A53	695797-25	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG402A54	695797-27	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG402A55	695797-37	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A1		Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A10	695797-19	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US

JG412A11	695797-21	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A2	695797-9	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A3	695797-11	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A4	695797-13	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A52	695797-31	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A53	695797-33	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A54	695797-35	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A55	695797-39	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG412A56	695797-29	Fuel Qty Indicator	HONEYWELL	OH/REP/TEST	C130;L100	PLEASE CONTACT US
JG603D46		Fuel Quantity Indicator	HONEYWELL	OH/REP/TEST	B747	PLEASE CONTACT US
K-4568-1		Static Pressure Selector Valve	ESSEX PRECISION CONT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
K51004		Elevator Booster Cylinder	THOMPSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
K51004-3		Elevator Booster Cylinder	THOMPSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
K51004-4		Elevator Booster Cylinder	THOMPSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
K51004-6		Elevator Booster Cylinder	THOMPSON	OH/REP/TEST	C130;L100	PLEASE CONTACT US
KAA0806K		Sensitive Altimeter	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
KAA1803K		Sensitive Altimeter	SMITHS	OH/REP/TEST	HELI	PLEASE CONTACT US
KAA2001W		Sensitive Altimeter	SMITHS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
KAB0506K		Airspeed Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
KAB0506W		Airspeed Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
KAB0809W/1		Airspeed Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
KGA0401		Engine Speed Generator	SMITHS	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
KGA0402		Engine Speed Generator	SMITHS	OH/REP/TEST	HS748;GS1	PLEASE CONTACT US
KGA0403		Engine Speed Generator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
KGA0404		Engine Speed Generator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
KGA0406		Engine Speed Generator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
KGA0407		Engine Speed Generator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
KGA0408		Engine Speed Generator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
KGA0409		Engine Speed Generator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
KMA0103		Machmeter	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
KRA-0101W		Rate Of Climb Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
KRA-0202W		Rate Of Climb Indicator	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
KRA-0204W		Rate Of Climb Indicator	SMITHS	OH/REP/TEST	SD330;SD360;SKY;HRLD	PLEASE CONTACT US
KRA1101W		Rate Of Climb Indicator	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
KTD0602K		Indicator Tachometer	SMITHS	OH/REP/TEST	F27;GS1	PLEASE CONTACT US
KTD0602W		Indicator Tachometer	SMITHS	OH/REP/TEST	GS1;HRLD	PLEASE CONTACT US
KTD0616W		Indicator Tachometer	SMITHS	OH/REP/TEST	GS1	PLEASE CONTACT US
KTD0620W		Indicator Tachometer	SMITHS	OH/REP/TEST	GS1	PLEASE CONTACT US
KTD1801W		Tachometer Indicator	SMITHS	OH/REP/TEST	HELI	PLEASE CONTACT US
KTS0409W		Turn And Slip Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
L10-20		Linear Actuator	GEC	OH/REP/TEST	DHC-6	PLEASE CONTACT US
L10-47-1		Linear Actuator	GEC	OH/REP/TEST	DHC-7	PLEASE CONTACT US
L10-70		Linear Actuator	PLESSEY DYNAMICS	OH/REP/TEST	SD360	PLEASE CONTACT US
L16-107	697640-1	Actuator	GEC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
L16-35-2		Linear Actuator	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US

L16-8		Linear Actuator	GEC-MARCONI	OH/REP/TEST	C130;L100	PLEASE CONTACT US
L16-8-1	695807-1	Linear Actuator	GEC-MARCONI	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
L16-8-3	695807-1	Linear Actuator	GEC-MARCONI	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
L16-8-5		Linear Actuator	GEC-MARCONI	OH/REP/TEST	C130;L100	PLEASE CONTACT US
L8602315-1		Heat Exchanger	HONEYWELL	TEST ONLY	B737	PLEASE CONTACT US
L8743039-1		Cooling Turbine Heat Exchanger	AIRESEARCH	TEST ONLY	C130;L100	PLEASE CONTACT US
LA16-2-3		Linear Actuator	PLESSEY AIRBORNE	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
LA16-4-2		Linear Actuator	PLESSEY AIRBORNE	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
LA26		Fuel Contents Amplifier	SMITHS INDUSTRIES	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
LD1206-10/1		DC Motor And Gearbox	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
LD1508 FORM 10		DC Electric Motor	LUCAS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
LD1508 FORM 13		DC Electric Motor	LUCAS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
LD1508 FORM 8-1		DC Electric Motor	BTH	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
LDA200 FORM B16C		Contactora	LUCAS AEROSPACE	OH/REP/TEST	SKY	PLEASE CONTACT US
LDG100Y8/1		Contactora	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
LK151		Fuel Qty Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
LK168		Fuel Qty Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
LK174		Fuel Qty Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
LK191		Fuel Qty Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
LK192		Fuel Qty Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
LK72		Fuel Qty Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
LL1400		Hydrolok	PL PORTER	OH/REP/TEST	B727;B737;DC9	PLEASE CONTACT US
LL1400-06		Hydrolok	PL PORTER	OH/REP/TEST	B727;B737;DC9	PLEASE CONTACT US
LL1400-37		Hydrolok	PORTER	OH/REP/TEST	B727;B737;DC9	PLEASE CONTACT US
LM200-SA1	695298-3	Engine Mounting	LORD	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
LN37838		Anti-Ice Valve	WHITTAKER	OH/REP/TEST	LYNX	PLEASE CONTACT US
LUN1120		Altimeter	MIKROTECHNA PRAHA	OH/REP/TEST	TBD	PLEASE CONTACT US
M1769		Pitot Switch	NEGRETTE	OH/REP/TEST	HS748	PLEASE CONTACT US
M1949EA		Altitude Switch	NEGRETTE	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
M2019		Altitude Switch	MECHANISM	OH/REP/TEST	HS748	PLEASE CONTACT US
M2019U		Altitude Switch	MECHANISM	OH/REP/TEST	BAE125	PLEASE CONTACT US
M2085		Pressure Switch	NEGRETTE	OH/REP/TEST	BAE125	PLEASE CONTACT US
M2086		Power Loss Indicator	NEGRETTE	OH/REP/TEST	BAE125	PLEASE CONTACT US
M2108		Pitot Switch	NEGRETTE	OH/REP/TEST	BAC111;HS748	PLEASE CONTACT US
M2153		Aneroid Switch	NEGRETTE	OH/REP/TEST	BAE125	PLEASE CONTACT US
M2179		Power Loss Indicator	NEGRETTE	OH/REP/TEST	BAE125	PLEASE CONTACT US
M2229		Pitot Switch	NEGRETTE	OH/REP/TEST	HS748	PLEASE CONTACT US
M2601/1		Hand Operated Pump	LUCAS	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
M2605		Hand Operated Pump	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
M2801A-6A		Tubeaxial Fan	DYNAMIC AIR ENG.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
M30183BDC		Motor Assy	DYNAMIC AIR ENG.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
M3251B-6A		Vane Axial Fan	DYNAMIC AIR ENG.	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
M422M15		Motor Assembly	GEC	OH/REP/TEST	BAE146	PLEASE CONTACT US
M422M15-1		Motor Assembly	GEC	OH/REP/TEST	BAE146	PLEASE CONTACT US
M422M15-2		Motor Assembly	GEC	OH/REP/TEST	BAE146	PLEASE CONTACT US

M4941A-1A		Vaneaxial Fan	DYNAMIC AIR ENG.	OH/REP/TEST	F27	PLEASE CONTACT US
M4941Z-1A		Vaneaxial Fan	DYNAMIC AIR ENG.	OH/REP/TEST	F27;JETST	PLEASE CONTACT US
M5921A-1B		Vane Axial Fan	DYNAMIC AIR ENG.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
M913-1		Check Valve	BOBRICK-DELAVAL	OH/REP/TEST	TBD	PLEASE CONTACT US
M9201A-1B	695943-3	Vane Axial Fan	DYNAMIC AIR ENG.	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MAE4935		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	HS748	PLEASE CONTACT US
MAE4936		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	HS748	PLEASE CONTACT US
MAE4968		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	TBD	PLEASE CONTACT US
MAE4994		Fuel Flow Computer	KEARSLEY/AFLO	OH/REP/TEST	TBD	PLEASE CONTACT US
MAE4994MOD01		Fuel Flow Computer	KEARSLEY/AFLO	OH/REP/TEST	TBD	PLEASE CONTACT US
MAE4998		Fuel Flow Computer	KEARSLEY/AFLO	OH/REP/TEST	TBD	PLEASE CONTACT US
MAE4998MOD02		Fuel Flow Computer	KEARSLEY/AFLO	OH/REP/TEST	TBD	PLEASE CONTACT US
MAF4935		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	HS748	PLEASE CONTACT US
MAF4936		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	HS748	PLEASE CONTACT US
MAF4959		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAF4960		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAF4961		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAF4963		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAH4900		Fuel Flow Transmitter	KEARSLEY/AFLO	OH/REP/TEST	TBD	PLEASE CONTACT US
MAH4920		Fuel Flow Transmitter	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAH4930		Fuel Flow Transmitter	KEARSLEY/AFLO	OH/REP/TEST	HS748	PLEASE CONTACT US
MAH4970		Fuel Flow Transmitter	KEARSLEY/AFLO	OH/REP/TEST	MB339	PLEASE CONTACT US
MAJ4900		Fuel Flow Transmitter	KEARSLEY/AFLO	OH/REP/TEST	MB339	PLEASE CONTACT US
MAL4900		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	MB339	PLEASE CONTACT US
MAL4901		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	MB339	PLEASE CONTACT US
MAM4808		Indicator Test Set	KEARSLEY/AFLO	OH/REP/TEST	TBD	PLEASE CONTACT US
MAS4935		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	HS748	PLEASE CONTACT US
MAS4936		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	HS748	PLEASE CONTACT US
MAS4959		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAS4960		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAS4961		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAS4962		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAS4963		Fuel Flow Indicator	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MAS4998		Fuel Flow Computer	KEARSLEY/AFLO	OH/REP/TEST	F27	PLEASE CONTACT US
MB022		Fuel Pump	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
MF30-3913-25ZE5		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF30-3913-25ZE-S656-5		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF30-3913-30S159-2		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF30-3913-30ZE-5	697232-1	Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF30-3913-30ZG-2		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF-3913-2		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF-3913-5		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF60-3913-30ZG5		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF60-3913-S215-2		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MF88-913S395-5A		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US

MF9-3911-30Z-S481		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
MFHA15101		Filter	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
MFHA15700		Filter	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
MFHA2109		Filter	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
MFHA31703		Filter	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
MFHA31705		Filter	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
MFHA4330		Filter	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
MGE23-400	MS17404-2	Motor Generator	LELAND	OH/REP/TEST	C130;L100;L382;GS1	PLEASE CONTACT US
MGE23-400A		Motor Generator	LELAND	OH/REP/TEST	C130;L100;L382;GS1	PLEASE CONTACT US
MGE23-413		Motor Generator	LELAND	OH/REP/TEST	BAE125	PLEASE CONTACT US
MGE23-500A		Motor Generator	LELAND	OH/REP/TEST	C130;L100;L382;GS1	PLEASE CONTACT US
MGH159-100		Motor Generator	LELAND	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
MGH159-200		Motor Generator	LELAND	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
MGH159-500A		Motor Generator	LELAND	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MGH182-100		Motor Generator	LELAND	OH/REP/TEST	BAE125;HS748	PLEASE CONTACT US
MGH182-100A		Motor Generator	LELAND	OH/REP/TEST	BAE125;HS748	PLEASE CONTACT US
MJV69618-400		Check Valve Assembly	MARMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML141.0029		Nose Wheel Assembly	JAY-EM	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-41-0101/1		NLG Strut Assy	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-41-0101/3		Upper Torque Arm	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-41-0111/5		MLG Shock Strut Assembly	ATOS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-41-0113		LH NLG Steering Manifold	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-41-0114		RH NLG Steering Manifold	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-81-367		Fire Detector Control Unit	WALTER KIDDE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-83-1012/11		Engineers Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-83-1012/13		Engineers Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-83-1012/15		Navigator Swivel Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-83-1012/17		Navigator Swivel Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-83-1012/7		Pilot & CO-Pilots Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ML1-83-1012/9		Pilot & Co-Pilots Seat Assembly	AIRCRAFT MECHANICS I	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MPEV3-032-2		Hydraulic Pump & Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MPEV3-032-2		Hydraulic Pump & Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MPEV3-032-2A		Hydraulic Pump & Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MS24478-2	AW1026AE01	Gauge	U.S.GAUGE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
MS28005-2	ST-4J	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MS28005-5	ST-7D	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
MS28010-1	SR-6A	Fuel Pressure Indicator	U.S.GAUGE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
MS28023-1	8DJ48FAL2	Oil Flap Position Indicator	GENERAL ELECTRIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MS28034-1	56B3A	Temperature Bulb	LEWIS ENGINEERING	TEST ONLY	C130;HELI	PLEASE CONTACT US
MS28034-1	102-00000	Temperature Sensor	NORWICH AERO	TEST ONLY	C130;B747	PLEASE CONTACT US
MS28034-3		Temperature Bulb	LEWIS ENGINEERING	TEST ONLY	DC10;HELI	PLEASE CONTACT US
MS28049-1	RC-60	Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MS28075-1	RCS-20-10	Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MS28720-8	50222	Hydraulic Filter	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
MS42-3913S159-2A		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US

MS42-3913S159-2C		Hydraulic Motor Assembly	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
N0413		Alternator	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
N0904/1		AC Generator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
N0904/1C		AC Generator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
N31A05		Non Return Valve	FLIGHT REFUELLING	OH/REP/TEST	BAE125	PLEASE CONTACT US
N400-4B-3		AC Motor	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
N400-4B-4	695140	AC Motor	LUNDY	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
NB25/3		High Energy Ignition Unit	LUCAS	OH/REP/TEST	TBD	PLEASE CONTACT US
NB2503		High Energy Ignition Unit	LUCAS	OH/REP/TEST	TBD	PLEASE CONTACT US
NB34		High Energy Ignition Unit	LUCAS	OH/REP/TEST	GS1	PLEASE CONTACT US
NB38		High Energy Ignition Unit	LUCAS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
NL7510		Aircraft Clock	CAMERER CUSS	OH/REP/TEST	TBD	PLEASE CONTACT US
NO406/2		Alternator	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
NO406/3		Alternator	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
P128-350-1	S271T496-2	Shutoff Toggle Valve	CIRCLE SEAL CONTROLS	OH/REP/TEST	B757;B767	PLEASE CONTACT US
P24-595		Flow Limiting Valve Assembly	CIRCLE SEAL CONTROLS	OH/REP/TEST	B757	PLEASE CONTACT US
P31-595		Flow Limiting Valve Assembly	CIRCLE SEAL CONTROLS	OH/REP/TEST	B757	PLEASE CONTACT US
P32-595		Flow Limiting Valve Assembly	CIRCLE SEAL CONTROLS	OH/REP/TEST	B757	PLEASE CONTACT US
P5394		Clogging Indicator Unit	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
P6601		Transformer	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
P66-526		Automatic Vent Valve	CIRCLE SEAL CONTROLS	OH/REP/TEST	B747	PLEASE CONTACT US
P6955		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310;DC10	PLEASE CONTACT US
P6971A		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310;DC10	PLEASE CONTACT US
P6989 A		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310;DC10	PLEASE CONTACT US
P6990		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310;DC10	PLEASE CONTACT US
P7119HP	71190400010NCOA	Sampling Valve	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
P7244A		Hydraulic Filter	SOFRANCE	OH/REP/TEST	A300;A310	PLEASE CONTACT US
PC-125		Static Inverter	FLITE-TRONICS	OH/REP/TEST	DO328	PLEASE CONTACT US
PC-125-12B		Static Inverter	FLITE-TRONICS	OH/REP/TEST	DO328	PLEASE CONTACT US
PC-15BC		Static Inverter	FLITE TRONICS	OH/REP/TEST	BAND;SD330;SD360;DHC6	PLEASE CONTACT US
PC-17		Static Inverter	FLITE TRONICS	OH/REP/TEST	BEECH KING AIR	PLEASE CONTACT US
PC-250		Static Inverter	FLITE TRONICS	OH/REP/TEST	BAE125;SD360;DC10;SKY	PLEASE CONTACT US
PC-250C		Static Inverter	FLITE TRONICS	OH/REP/TEST	BAE125;SD360;DC10;SKY	PLEASE CONTACT US
PDC1-1B-161		Airspeed Switch	SCOTT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
PH10P-1	697149-1	Low Pressure Switch	LOCKHEED	TEST ONLY	C130;L100;L382	PLEASE CONTACT US
PMP2V-7D		Pump Motor Package	PARKER	TEST ONLY	B727;B737;B747	PLEASE CONTACT US
PTG14/22		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	YS11	PLEASE CONTACT US
PTG14/23		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	YS11	PLEASE CONTACT US
PTG14/31		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	GS1	PLEASE CONTACT US
PTG14/7		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	GS1	PLEASE CONTACT US
PTG14/8		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	GS1	PLEASE CONTACT US
PTG5/1		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
PTG5/60		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
PTG5/61		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
PTG9/9A		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US

PTG9/9B		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
PTG9/9C		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
PTG9/9D		Accessory Gearbox	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
PV3-075-4		Variable Displacement Hydraulic Pump	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
PV3-075-4A		Variable Displacement Hydraulic Pump	VICKERS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
PV3-075-5	328837	Variable Displacement Hydraulic Pump	VICKERS	OH/REP/TEST	YS-11	PLEASE CONTACT US
PV3-075-9UK1A	717091	Variable Displacement Hydraulic Pump	VICKERS	OH/REP/TEST	BAE146	PLEASE CONTACT US
PV3-160-4	371380	Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111;(CofC only);B707;B727;B737	PLEASE CONTACT US
PV3-160-4A	424244	Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111;(CofC only);B707;B727;B737	PLEASE CONTACT US
PV3-160-4B	623337	Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111;(CofC only);B707;B727;B737	PLEASE CONTACT US
PV3-160-4C	623339	Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111;(CofC only);B707;B727;B737	PLEASE CONTACT US
PV3-160-4GB1	776932	Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
PV3-160-5GB1	715144	Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
PV3-160-5GB2	715527	Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
PV3-160-8	569653	Hydraulic Pump	VICKERS	OH/REP/TEST	BAC111;(CofC only);B707;B727;B737	PLEASE CONTACT US
PW/0416KTS/CPM/1		Turn And Slip Indicator	SMITHS INDUSTRIES	OH/REP/TEST	F100	PLEASE CONTACT US
PW/0432KTD/1		Tachometer Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/0432KTD/2		Tachometer Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/0433KTD/1		Tachometer Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/0433KTD/2		Tachometer Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/0810KAB/1		Airspeed Indicator	SMITHS	OH/REP/TEST	SD330;SD360;F27;SKY	PLEASE CONTACT US
PW/0811KAB/1		Airspeed Indicator	SMITHS	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
PW/0811KAB/2		Airspeed Indicator	SMITHS	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
PW/1037PG		Pressure Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
PW/11/12ADR		Press & Temp Indicator	SMITHS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
PW/11/1ADR		Press & Temp Indicator	SMITHS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
PW/1203KTS/BR/1		Turn And Slip Indicator	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
PW/1491PG		Pressure Gauge	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
PW/164RV/BR		Engine Speed Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/170RV/BR		Engine Speed Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/201/AMA/1		Mach Airspeed Indicator	SMITHS INDUSTRIES	OH/REP/TEST	TBD	PLEASE CONTACT US
PW/201FL		Desynn Position Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/259PG		Pressure Gauge	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/323PG		Pressure Gauge	SMITHS	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
PW/631PG		Pressure Gauge	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
PW/879FL		Desynn Position Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
PW/879FL/BU		Desynn Position Indicator	SMITHS	OH/REP/TEST	F27;SD330;SD360;SKY	PLEASE CONTACT US
PW/890FL		Desynn Position Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/911FL		Desynn Position Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW/95RV/SB		Engine Speed Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
PW/V308-326		Clock	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW101ACR/BU/1		Pressure Indicator	SMITHS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
PW101ACR/BU/8		Pressure Indicator	SMITHS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
PW202AMA/1		Mach Air Speed Indicator	SMITHS	OH/REP/TEST	BAE125	PLEASE CONTACT US
PW2172FG		Desynn Contents Indicator	SMITHS	OH/REP/TEST	F27;HRLD	PLEASE CONTACT US

PW2200FG/M		Desynn Contents Indicator	SMITHS	OH/REP/TEST	F27;HRLD	PLEASE CONTACT US
PW26ACR/MB		Oil Pressure Indicator	SMITHS	OH/REP/TEST	GS1	PLEASE CONTACT US
PW302FL/BR		Desynn Position Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW523PG		Desynn Pressure Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW579FL		Desynn Position Indicator	SMITHS	OH/REP/TEST	F27;HRLD	PLEASE CONTACT US
PW579FL/CP		Desynn Position Indicator	SMITHS	OH/REP/TEST	GS1	PLEASE CONTACT US
PW597FL/BR		Desynn Position Indicator	SMITHS	OH/REP/TEST	HS748	PLEASE CONTACT US
PW660PG/SB		Desynn Pressure Indicator	SMITHS	OH/REP/TEST	HS748;F27	PLEASE CONTACT US
PW8ACR/MB		Oil Pressure Indicator	SMITHS	OH/REP/TEST	F27	PLEASE CONTACT US
PYLB51239-1		Oil Cooler Augmentation Valve	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
PYLB51239-2		Oil Cooler Augmentation Valve	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
QA03638		Filter Element Assembly	PALL	OH/REP/TEST	B747	PLEASE CONTACT US
QP122B		Q Feel Pitot	AVIMO	TEST ONLY	BAE146	PLEASE CONTACT US
R1053M18		Limit Mechanism Assembly	GEC	OH/REP/TEST	B737;B747	PLEASE CONTACT US
R1061-2		Right Angle Drive Gearbox	GEC DYNAMICS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
R1061-4		Right Angle Drive Gearbox	GEC DYNAMICS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
R1063M1		Gearbox Assembly	PLESSEY DYNAMICS	OH/REP/TEST	TBD	PLEASE CONTACT US
R1065-4		Gearbox Assembly	GEC	OH/REP/TEST	DC10	PLEASE CONTACT US
R1065M1		Gearbox Assembly	GEC	OH/REP/TEST	DC10	PLEASE CONTACT US
R1071M1		Gearbox Assembly	PLESSEY DYNAMICS	OH/REP/TEST	DC10	PLEASE CONTACT US
R1071M2		Gearbox Assembly	PLESSEY DYNAMICS	OH/REP/TEST	DC10	PLEASE CONTACT US
R1110		Speed Sensing Tachometer	GEC	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
R1110-1		Speed Sensing Tachometer	GEC	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
R1113		Overrunning Clutch	PLESSEY DYNAMICS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
R1143M1-3		Right Angle Gearbox	GEC DYNAMICS	OH/REP/TEST	B757	PLEASE CONTACT US
R1143M1-4		Right Angle Gearbox	GEC DYNAMICS	OH/REP/TEST	B757	PLEASE CONTACT US
R1143M1-5		Right Angle Gearbox	GEC DYNAMICS	OH/REP/TEST	B757	PLEASE CONTACT US
R1143M1-6		Right Angle Gearbox	GEC DYNAMICS	OH/REP/TEST	B757	PLEASE CONTACT US
R1409M13-1		Rotary Actuator	PLESSEY DYNAMICS	OH/REP/TEST	B747	PLEASE CONTACT US
R1409M5-11		Rotary Actuator	PLESSEY DYNAMICS	OH/REP/TEST	B747	PLEASE CONTACT US
R1409M9-1		Rotary Actuator	PLESSEY DYNAMICS	OH/REP/TEST	B747	PLEASE CONTACT US
R15048	10-62026-1	Trim Actuator Assembly	PLESSEY DYNAMICS	OH/REP/TEST	B737	PLEASE CONTACT US
R1584M10-3		Linear Actuator	GEC	OH/REP/TEST	B707	PLEASE CONTACT US
R1584M10-4		Linear Actuator	GEC	OH/REP/TEST	B707	PLEASE CONTACT US
R1596M5		Linear Actuator	PLESSEY UK	OH/REP/TEST	BAE125;ELEC-P3	PLEASE CONTACT US
R5170M34-2		Linear Actuator	GEC DYNAMICS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
R5170M34-3	695838-3	Linear Actuator	GEC DYNAMICS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
R5170M34-4		Linear Actuator	GEC DYNAMICS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
R5192M1		Engine Inlet Actuator	PLESSEY DYNAMICS	OH/REP/TEST	L-1011 TRISTAR	PLEASE CONTACT US
R5303-3		Speed Brake Actuator	SMITHS	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
R5303-5		Speed Brake Actuator	SMITHS	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
R5303-51		Speed Brake Actuator	SMITHS	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
R5303M1	10-61359-3	Speed Brake Actuator	SMITHS	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
R5303M1-1		Speed Brake Actuator	SMITHS	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
R532M58-1		Screwjack Assembly	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US

R532M58-11		Screwjack Assembly	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
R584M62-2		Linear Actuator	GEC	OH/REP/TEST	TBD	PLEASE CONTACT US
R584M67-1		Linear Actuator	PLESSEY DYNAMICS	OH/REP/TEST	SD330	PLEASE CONTACT US
R6166M1	10-61286-1	Rotary Actuator	GEC	OH/REP/TEST	B727;B737	PLEASE CONTACT US
R6200M3-11		APU Inlet Duct Actuator	GEC	OH/REP/TEST	B707;B737	PLEASE CONTACT US
R6200M3-12		APU Inlet Duct Actuator	GEC	OH/REP/TEST	B707;B737	PLEASE CONTACT US
R6200M3-13		APU Inlet Duct Actuator	GEC	OH/REP/TEST	B707;B737	PLEASE CONTACT US
R6200M6		APU Inlet Duct Actuator	GEC	OH/REP/TEST	B707;B737	PLEASE CONTACT US
R6200M7		APU Inlet Duct Actuator	GEC	OH/REP/TEST	B707;B737	PLEASE CONTACT US
R6607A3-173		Pressure Switch (Spec 747700-15)	CONSOLIDATED CONTROLS	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
RC-20-ILB		Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	B727;DC10	PLEASE CONTACT US
RC-30-V-10		Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	HELI	PLEASE CONTACT US
RC-60		Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RC-60-ILB		Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	F27	PLEASE CONTACT US
RC-60MS	MS28049-1	Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RC-60MS-10-3		Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RC-60-VIL-1		Vertical Velocity Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RCS-20-10	MS28075-1	Rate Of Climb Indicator	AEROSONIC	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
RCS-60-1L-10		Vertical Velocity Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RCS-60-1L-10-HI		Vertical Velocity Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RCS-60-AAU-18/A		Vertical Velocity Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RCS-60-IL	MS28075-1	Vertical Velocity Indicator	AEROSONIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
RCS-60-ILW		Vertical Velocity Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RD12-2-3		Rotary Actuator	PLESSEY AIRBORNE	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
RD12-2-4		Rotary Actuator	PLESSEY AIRBORNE	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
RFP/26		Feathering Pump And Motor	DOWTY AEROSPACE	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
RFP/26C		Feathering Pump And Motor	DOWTY AEROSPACE	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
RFP/27E		Feathering Pump And Motor	DOWTY AEROSPACE	OH/REP/TEST	F27	PLEASE CONTACT US
RFP/29		Feathering Pump And Motor	DOWTY AEROSPACE	OH/REP/TEST	HS748;F27;GS1	PLEASE CONTACT US
RG12240		Fuel Booster Pump	CRANE LEAR ROMEC	OH/REP/TEST	HELI	PLEASE CONTACT US
RG15150H		Fuel Transfer Pump	CRANE LEAR ROMEC	OH/REP/TEST	HELI	PLEASE CONTACT US
RG15150L		Fuel Transfer Pump	CRANE LEAR ROMEC	OH/REP/TEST	HELI	PLEASE CONTACT US
RG15150V		Fuel Transfer Pump	CRANE LEAR ROMEC	OH/REP/TEST	HELI	PLEASE CONTACT US
RR11620-2		Fuel Booster Pump	CRANE LEAR ROMEC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RR11620-3		Fuel Booster Pump	CRANE LEAR ROMEC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RR11640A		Fuel Booster Pump	LEAR ROMEC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RR11640D1		Fuel Booster Pump	LEAR ROMEC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RR54860A		Fuel Boost Pump	LOCKHEED	OH/REP/TEST	C130;L100	PLEASE CONTACT US
RYLC51047		Deflector Door Actuator	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S109-3-65		Frequency Meter	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S109-3-65T		Frequency Meter	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S114-6-26		Beam Approach Indicator	WESTON	TEST ONLY	SD330;SD360;SKY	PLEASE CONTACT US
S122-11-80		Pressure Transmitter	WESTON	TEST ONLY	BAC111(CofC only)	PLEASE CONTACT US
S122-4-30		Pressure Transmitter	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S122-6-63		Pressure Transmitter	WESTON	TEST ONLY	BAC111(CofC only);BAE125	PLEASE CONTACT US

S122-6-64		Pressure Transmitter	WESTON	TEST ONLY	BAC111(CofC only);BAE125	PLEASE CONTACT US
S196-1-51		Temperature Indicator	WESTON	TEST ONLY	BAC111(CofC only);BAE125	PLEASE CONTACT US
S218-5-107		Temperature Indicator	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S218-5-14		Temperature Indicator	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S218-5-14T		Temperature Indicator	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S218-5-26		Temperature Indicator	WESTON	TEST ONLY	HS748;F27;GS1	PLEASE CONTACT US
S218-5-26T		Temperature Indicator	WESTON	TEST ONLY	HS748;F27;GS1	PLEASE CONTACT US
S218-5-37		Temperature Indicator	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S218-5-37T		Temperature Indicator	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S369-100		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S369-50		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S4000		Elevator Booster Actuator	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S4000-1		Elevator Booster Actuator	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S4000-2		Elevator Booster Actuator	SARGENT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S4-4500151		Gear Uplock Assy	FWM	OH/REP/TEST	DO228	PLEASE CONTACT US
S462-25		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S462-50		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S463-100		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S463-50		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S477-100		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S477-200		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S477-50		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S512-25		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S-512-50-1		Accumulator Assy	SPRAGUE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
S513-200		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S618-A		Accumulator	SPRAGUE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
S63-4-431		Temperature Indicator	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
S78-3-1235T		DC Ammeter	WESTON	TEST ONLY	HS748	PLEASE CONTACT US
SD113G		Contactora	HARTMAN	TEST ONLY	BAE146	PLEASE CONTACT US
SEL-OC3A		Fuel Pressure Indicator	AMETEK	OH/REP/TEST	B747	PLEASE CONTACT US
SEL-OC4A		Fuel Pressure Indicator	AMETEK	OH/REP/TEST	B747	PLEASE CONTACT US
SEL-OC4AD		Oil Pressure Indicator	AMETEK	OH/REP/TEST	B747	PLEASE CONTACT US
SEL-OC4AE		Oil Pressure Indicator	AMETEK	OH/REP/TEST	B747	PLEASE CONTACT US
SEL-OC4AF		Oil Pressure Indicator	AMETEK	OH/REP/TEST	B747	PLEASE CONTACT US
SEL-OC4T		Oil Pressure Indicator	AMETEK	OH/REP/TEST	B737	PLEASE CONTACT US
SEL-OC4W		Oil Pressure Indicator	AMETEK	OH/REP/TEST	B737	PLEASE CONTACT US
SK-40-10		Airspeed Indicator	AEROSONIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
SK-40-LC		Airspeed Indicator	AEROSONIC	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
SK-40-LC-1		Airspeed Indicator	AEROSONIC	OH/REP/TEST	C130;L100	PLEASE CONTACT US
SL06300-01		Hydrolock	P L PORTER	OH/REP/TEST	B737;DC10	PLEASE CONTACT US
SLZ9039		Vertical Speed Indicator	TELEDYNE AVIONICS	OH/REP/TEST	B707;ELEC	PLEASE CONTACT US
SLZ9065		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	HS748	PLEASE CONTACT US
SLZ9066		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	HS748	PLEASE CONTACT US
SLZ9067		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	HS748	PLEASE CONTACT US
SLZ9068		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	HS748	PLEASE CONTACT US

SLZ9140		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
SLZ9145		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	B737	PLEASE CONTACT US
SLZ9155		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	HS748	PLEASE CONTACT US
SLZ9200		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	BAE125	PLEASE CONTACT US
SLZ9200A-1		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	BAE125	PLEASE CONTACT US
SLZ9211		Vertical Speed Indicator	TELEDYNE	OH/REP/TEST	BAC111;HS748	PLEASE CONTACT US
SNC/16		Corrector Motor	DOWTY	OH/REP/TEST	F27	PLEASE CONTACT US
SNC/20		Corrector Unit	DOWTY	OH/REP/TEST	CANA YS11	PLEASE CONTACT US
SNC/22		Corrector Unit	DOWTY	OH/REP/TEST	CANA YS11	PLEASE CONTACT US
SNC/33		Corrector Unit	DOWTY	OH/REP/TEST	CANA YS11	PLEASE CONTACT US
SPM8/RS/MK1		Water Methanol Pump	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
SPM8/RS/MK2		Water Methanol Pump	GEC	OH/REP/TEST	HS748	PLEASE CONTACT US
SR-015F		Pressure Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
SR-027A		Pressure Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
SR-04E		Pressure Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
SR-07C		Pressure Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
SR-07F		Pressure Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
SR-07G		Pressure Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
SR-07J		Pressure Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
SR-09D		Pressure Indicator	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
SR-150-A		Oil Pressure Indicator	AMETEK	OH/REP/TEST	HELI	PLEASE CONTACT US
SR-151-A		Oil Pressure Indicator	AMETEK	OH/REP/TEST	HELI	PLEASE CONTACT US
SR-152-A		Oil Pressure Indicator	AMETEK	OH/REP/TEST	HELI	PLEASE CONTACT US
SR-4AJ		Torque Pressure Synchro Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
SR-4J		Flap Position Synchro Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
SR-4W		Flap Position Synchro Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
SR-6A	MS28010-1	Fuel Pressure Indicator	U.S.GAUGE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
SR-7A		Hydraulic Pressure Synchro Indicator	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
SRD-27A		Oxygen Pressure Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
SRD-9C		Eng Start Air Pressure Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
SRDL-OC7E	10-3223-43	Dual Hydraulic Pressure Indicator	AMETEK	OH/REP/TEST	B737	PLEASE CONTACT US
SRL-O7BH		Hydraulic Pressure Indicator	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
SRL-OC7EM	10-3223-44	Hydraulic Brake Pressure Indicator	AMETEK	OH/REP/TEST	B737	PLEASE CONTACT US
ST-104A	695420	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
ST-104AB		Oil Pressure Transmitter	AMETEK	OH/REP/TEST	B707;B737	PLEASE CONTACT US
ST-104Y		Oil Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	TBD	PLEASE CONTACT US
ST-104Y-1		Oil Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	TBD	PLEASE CONTACT US
ST-104Z		Pressure Transmitter	AMETEK	OH/REP/TEST	B727;B737	PLEASE CONTACT US
ST-105F		Pressure Transmitter	AMETEK	TEST ONLY	ELECTRA	PLEASE CONTACT US
ST-106AB		Pressure Transmitter	AMETEK	OH/REP/TEST	B727;B737;B747	PLEASE CONTACT US
ST-107R		Pressure Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
ST-109C		Pressure Transmitter	AMETEK	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
ST-12G		Position Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ST-12Q		Position Transmitter	AMETEK	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
ST-207A		Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	TBD	PLEASE CONTACT US

ST-3A	MS28005-4	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
ST-3D		Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-3E		Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-4C	F-3	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-4D	F-3A	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-4E	MS28005-3	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-4H	MS28005-3	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	HELI	PLEASE CONTACT US
ST-4J	MS28005-2	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	HELI	PLEASE CONTACT US
ST-4N		Pressure Transmitter	AMETEK	OH/REP/TEST	B707	PLEASE CONTACT US
ST-53A		Pressure Transmitter	AMETEK	OH/REP/TEST	SIK S-61N	PLEASE CONTACT US
ST-54A		Pressure Transmitter	AMETEK	OH/REP/TEST	TBD	PLEASE CONTACT US
ST-62A	MIL-T-7748	Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	SIK S-61	PLEASE CONTACT US
ST-6C	MS28005-1	Pressure Transmitter	AMETEK	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-7A		Hydraulic Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-7B		Hydraulic Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-7C		Hydraulic Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-7D	MS28005-5	Hydraulic Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
ST-7R	10-3223-2	Hydraulic Pressure Transmitter	AMETEK	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
ST-9A		Pressure Transmitter	U.S.GAUGE	OH/REP/TEST	C130;L100	PLEASE CONTACT US
SYLZ50683-1	697639-35	Temperature Controller	BARBER COLMAN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
SYLZ50684	697639-37	Temperature Controller	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
SYLZ50685	697639-39	Temperature Controller	BARBER COLMAN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
TD1514-1002	60B50058-3	Toilet Timer Switch	LEACH CORP.	OH/REP/TEST	B737	PLEASE CONTACT US
TD1535-1002	60B50058-4	Toilet Timer Switch	LEACH CORP.	OH/REP/TEST	B747	PLEASE CONTACT US
TD1702-1002	60B50058-6	Toilet Timer Switch	LEACH CORP.	OH/REP/TEST	B737;B747	PLEASE CONTACT US
TD1715-1002	60B50058-5	Toilet Timer Switch	LEACH CORP.	OH/REP/TEST	B707;B737	PLEASE CONTACT US
TF11300-2		Fuel Pump	TRW	OH/REP/TEST	TBD	PLEASE CONTACT US
TG255-001		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	HELI	PLEASE CONTACT US
TG255-002		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	HELI	PLEASE CONTACT US
TG255-003		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	HELI	PLEASE CONTACT US
TG255-004		Tachometer Generator	AIRCRAFT APPLIANCES	OH/REP/TEST	HELI	PLEASE CONTACT US
TP26113		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
TP30022		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP30034		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP30047		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP30093		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAE125	PLEASE CONTACT US
TP30124		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP30125/1		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP30129		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP30129/1		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP35068		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
TP35070		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
TP35078		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
TP35098		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
TP35109		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US

TP35115		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
TP36002		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	TBD	PLEASE CONTACT US
TP36115		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	TBD	PLEASE CONTACT US
TP42000		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAE125	PLEASE CONTACT US
TP42001		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAE125	PLEASE CONTACT US
TP42013		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAE125	PLEASE CONTACT US
TP45001		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAC111(CofC only);BAE125	PLEASE CONTACT US
TP451		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	HS748	PLEASE CONTACT US
TP518		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	TBD	PLEASE CONTACT US
TP539		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
TP5953		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP5954		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP5961		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP5978		Pressure Switch	HOWDEN WADE	OH/REP/TEST	HS748	PLEASE CONTACT US
TP798		Pressure Switch	THERMAL CONTROL	OH/REP/TEST	BAC111(CofC only)	PLEASE CONTACT US
TY1757		Flap Actuator	LUCAS	OH/REP/TEST	TBD	PLEASE CONTACT US
U13887		Generator Control Unit	LUCAS	OH/REP/TEST	TUCANO	PLEASE CONTACT US
U3619/2		Voltage Sensing Unit	LUCAS	OH/REP/TEST	HS748;BAE ATP	PLEASE CONTACT US
U3620/1		Overvoltage Unit	LUCAS	OH/REP/TEST	HELI	PLEASE CONTACT US
U3620/2		Overvoltage Unit	LUCAS	OH/REP/TEST	HELI	PLEASE CONTACT US
U3624/2		Voltage Sensing Unit	ROTAX	OH/REP/TEST	BAE125	PLEASE CONTACT US
U3705/1		Control & Protection Unit	LUCAS	OH/REP/TEST	F27	PLEASE CONTACT US
U3709/1		Control And Protection Unit	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
U3715/1		Voltage Control & Protection Unit	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
U3715/1C		Voltage Control & Protection Unit	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
U-520845-4		Fuel Heater And Strainer Assy	UNITED AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
U-520845-401		Fuel Heater And Strainer Assy	UNITED AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
U-520845-7		Fuel Heater And Strainer Assy	UNITED AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
U6106-C		Voltage Regulator.	LUCAS	OH/REP/TEST	HS748	PLEASE CONTACT US
U6112		Voltage Regulator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
U6113/2		Voltage Regulator	LUCAS	OH/REP/TEST	HELI	PLEASE CONTACT US
U6118		Voltage Regulator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
U6119		Voltage Regulator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
U6120		Voltage Regulator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
U6121		Voltage Regulator	LUCAS	OH/REP/TEST	BAE125	PLEASE CONTACT US
U83A		Thrust Reverse Interlock Actuator	MPC	OH/REP/TEST	B757	PLEASE CONTACT US
U83B		Thrust Reverse Interlock Actuator	MPC	OH/REP/TEST	B757	PLEASE CONTACT US
UA524240-1	695810-3	Fuel Heater And Strainer Assy	UNITED AIRCRAFT PROD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
UC7023		Nose U/C Downlock Bracket Assy	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
UC7026		Uplock	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
UC7027		Main Undercarriage Downlock	DOWTY AEROSPACE	OH/REP/TEST	HS748	PLEASE CONTACT US
UMC5010		Hand Pump	APPH	OH/REP/TEST	HS748	PLEASE CONTACT US
V-052-4BA		AC Motor Assembly	LUNDY	OH/REP/TEST	C130;L100	PLEASE CONTACT US
V6-4360		Valve Assembly-Fuse Self Resetting	CIRCLE SEAL CONTROLS	OH/REP/TEST	B747;B757;B767	PLEASE CONTACT US
V6-4360-1		Valve Assembly-Fuse Self Resetting	CIRCLE SEAL CONTROLS	OH/REP/TEST	B747;B757;B767	PLEASE CONTACT US

V6-4360-2		Valve Assembly-Fuse Self Resetting	CIRCLE SEAL CONTROLS	OH/REP/TEST	B747;B757;B767	PLEASE CONTACT US
V8500-19		Shut Off Valve	VALCOR	OH/REP/TEST	HELI	PLEASE CONTACT US
VEH-5-7	VEH5-7	Electrical Oven	VALAD	OH/REP/TEST	C130;L100	PLEASE CONTACT US
W10504		Cold Air Valve	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
W10504-A2		Cold Air Valve	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
W10505		Cold Air Valve	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
W10505-A2		Cold Air Valve	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
W10507		Linkage Assembly	COLT IND.	OH/REP/TEST	B707	PLEASE CONTACT US
W1700-1/8D		Purge Valve	SEATON WILSON	OH/REP/TEST	TBD	PLEASE CONTACT US
W1705-1/8D		Purge Valve	SEATON WILSON	OH/REP/TEST	TBD	PLEASE CONTACT US
W-33-7545-10	A13A-2	Aircraft Clock	WAKMANN	OH/REP/TEST	C130;L100	PLEASE CONTACT US
W-33-7545-10	A13A-2	Aircraft Clock	WAKMANN	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
W7935-1D		Manual Slide Shut Off Valve	WHITTAKER	OH/REP/TEST	C130;F27	PLEASE CONTACT US
WA761		Actuator	WHITTAKER	OH/REP/TEST	F27	PLEASE CONTACT US
WA8003		Electric Actuator	WHITTAKER	OH/REP/TEST	TBD	PLEASE CONTACT US
WD01-68-11389-041		Oil Cooler Radiator	HUGHES TREITLER	OH/REP/TEST	TBD	PLEASE CONTACT US
WE450-1D		Shut Off Valve	WHITTAKER	OH/REP/TEST	F27	PLEASE CONTACT US
WL/102ACR/CP/3		Pressure Indicator	SMITHS	OH/REP/TEST	TBD	PLEASE CONTACT US
WL/235AS/PC/FA/1		Airspeed Indicator	SMITHS INDUSTRIES	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
WL/254AS/MS/1		Airspeed Indicator	SMITHS INDUSTRIES	OH/REP/TEST	SD330;SD360;SKY	PLEASE CONTACT US
WL106AMA20		Mach Airspeed Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL1704AM1		Counter/Pointer Altimeter	SMITHS INDUSTRIES	OH/REP/TEST	BAE146;F100	PLEASE CONTACT US
WL1704AM3		Counter/Pointer Altimeter	SMITHS INDUSTRIES	OH/REP/TEST	BAE146;F100	PLEASE CONTACT US
WL1704AM5		Counter/Pointer Altimeter	SMITHS INDUSTRIES	OH/REP/TEST	BAE146;F100	PLEASE CONTACT US
WL604AMA22		Mach Air Speed Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL604AMA28		Mach Air Speed Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL651RSA1		N2% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL651RSA3		N2% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL651RSA4		N2% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL651RSA5		N2% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL651RSA6		N2% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL656RSA3		N2% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL656RSA4		N2% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL656RSA6		N2% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL702RSA1		N1% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL706RSA3		Tgt Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL706RSA4		Tgt Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL706RSA5		Tgt Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
WL719RSA1		N1% RPM Indicator	SMITHS INDUSTRIES	OH/REP/TEST	BAE146	PLEASE CONTACT US
X702-259		Fan Assembly	JOY	OH/REP/TEST	ELECTRA	PLEASE CONTACT US
X702-275B		Fan Assembly	JOY	OH/REP/TEST	B707;DC8	PLEASE CONTACT US
X702-275C		Fan Assembly	JOY	OH/REP/TEST	B707;DC8	PLEASE CONTACT US
XA9503		De-Icer Pump	T.K.S.	OH/REP/TEST	BAC111(CofC only);BAE125	PLEASE CONTACT US
XA9503C/200		De-Icer Pump	T.K.S.	OH/REP/TEST	BAC111(CofC only);BAE125	PLEASE CONTACT US
XA9503D		De-Icer Pump	T.K.S.	OH/REP/TEST	BAE125	PLEASE CONTACT US

XA9504A/205		De-Icer Pump	T.K.S.	OH/REP/TEST	BAC111(CofC only);BAE125	PLEASE CONTACT US
XRP12A		Circuit Breaker	GEN.ELECTRIC	OH/REP/TEST	DHC-6;F27;F28	PLEASE CONTACT US
XW20058M1	695890-1	Windshield Wiper Motor Assy	ALCO CONTROLS	OH/REP/TEST	C130;L100;L382	PLEASE CONTACT US
XW20101-C-123		Winscreen Wiper System	ALCO CONTROLS	OH/REP/TEST	C130;L100	PLEASE CONTACT US
XW-20173-M1	2311M51-1	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
XW-20173-M1B	2311M51-2	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
XW-20173-M2	2311M51-3	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	BEECH 1900C; BAE125	PLEASE CONTACT US
XW20345-227-46	2312M-30-1	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	TBD	PLEASE CONTACT US
XW20345-252-90	2312M-30-6	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	TBD	PLEASE CONTACT US
XW20345-300-80	2312M-30-11	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	BAE ATP	PLEASE CONTACT US
XW20345-318-46	695890-51	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	C130;L100	PLEASE CONTACT US
XW20548-M1	2311M-69-1	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B707;B727;B737	PLEASE CONTACT US
XW21121-150-58	2312M-41-1	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	DHC-7	PLEASE CONTACT US
XW21132-11		Two Speed Ac Wiper Motor Assy	ALCO	OH/REP/TEST	F28	PLEASE CONTACT US
XW21181-2	2313M-21-1	Windshield Wiper Converter Assy	ROSEMOUNT	OH/REP/TEST	B727;B737	PLEASE CONTACT US
XW21634-1		Motor Converter Assembly	ALCO	OH/REP/TEST	TBD	PLEASE CONTACT US
XW21634-2		Motor Converter Assembly	ALCO	OH/REP/TEST	TBD	PLEASE CONTACT US
XW21795-1		Motor Converter Assembly	ALCO	OH/REP/TEST	TBD	PLEASE CONTACT US
XW21795-2		Motor Converter Assembly	ALCO	OH/REP/TEST	TBD	PLEASE CONTACT US
XW21795-3		Motor Converter Assembly	ALCO	OH/REP/TEST	TBD	PLEASE CONTACT US
XW21795-4		Motor Converter Assembly	ALCO	OH/REP/TEST	TBD	PLEASE CONTACT US
XW21872-11		Two Speed Ac Wiper Motor Assy	ALCO	OH/REP/TEST	F28	PLEASE CONTACT US
XW23827-1	2311M-208-1	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B727;B737;FALCON 50	PLEASE CONTACT US
XW23827-2	2311M-208-2	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B727;B737;FALCON 50	PLEASE CONTACT US
XW23827-3	2311M-208-3	Windshield Wiper Motor Assy	ROSEMOUNT	OH/REP/TEST	B727;B737;FALCON 50	PLEASE CONTACT US